OsmoPCAP VTY Reference

---

osmo-pcap-client

Copyright © 2024

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

COLLABORATORS			
	TITLE : OsmoPCAP VTY Reference		
ACTION	*NAME*	*DATE*	*SIGNATURE*
WRITTEN BY		October 11, 2024	

REVISION HISTORY			
NUMBER	DATE	DESCRIPTION	NAME
DRAFT 0.5.0	2023-Dec-01	Automatically Generated VTY Reference	s.f.m.c.

Contents

1 VTY reference **1**
1.1 Common Commands . . . 1
1.1.1 end . . . 2
1.1.2 exit . . . 2
1.1.3 help . . . 2
1.1.4 list [with-flags] . . . 2
1.1.5 show running-config . . . 3
1.1.6 show vty-attributes . . . 3
1.1.7 show vty-attributes (application|library|global) . . . 3
1.1.8 write . . . 4
1.1.9 write file [PATH] . . . 4
1.1.10 write memory . . . 4
1.1.11 write terminal . . . 5
1.2 view . . . 5
1.2.1 enable [expert-mode] . . . 5
1.2.2 logging color (0|1) . . . 5
1.2.3 logging disable . . . 6
1.2.4 logging enable . . . 6
1.2.5 logging filter all (0|1) . . . 6
1.2.6 logging level (pcap|client|server|vty|tls|l|global|l|lapd|linp|lmux|lmi|lmib|lsms|... . . . 7
1.2.7 logging level force-all (debug|info|notice|error|fatal) . . . 9
1.2.8 logging level set-all (debug|info|notice|error|fatal) . . . 10
1.2.9 logging print category (0|1) . . . 10
1.2.10 logging print category-hex (0|1) . . . 11
1.2.11 logging print extended-timestamp (0|1) . . . 11
1.2.12 logging print file (0|1|basename) [last] . . . 12
1.2.13 logging print level (0|1) . . . 12
1.2.14 logging print thread-id (0|1) . . . 13
1.2.15 logging set-log-mask MASK . . . 13
1.2.16 logging timestamp (0|1) . . . 14

1.2.17 logp (pcap|client|server|vty|tls|l|global|l|lapd|linp|l|mux|l|mi|l|mib|l|sms|l|ctrl|l|gt... . . . 14
1.2.18 no logging level force-all . . . 16
1.2.19 show alarms . . . 17
1.2.20 show asciidoc counters . . . 17
1.2.21 show history . . . 17
1.2.22 show logging vty . . . 18
1.2.23 show online-help . . . 18
1.2.24 show pid . . . 18
1.2.25 show rate-counters [skip-zero] . . . 19
1.2.26 show stats [skip-zero] . . . 19
1.2.27 show stats level (global|peer|subscriber) [skip-zero] . . . 19
1.2.28 show talloc-context (application|global|all) (full|brief|DEPTH) . . . 20
1.2.29 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP . . . 21
1.2.30 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS . . . 21
1.2.31 show uptime . . . 22
1.2.32 show version . . . 22
1.2.33 terminal length <0-512> . . . 23
1.2.34 terminal no length . . . 23
1.2.35 who . . . 23
1.3 enable . . . 24
1.3.1 configure [terminal] . . . 24
1.3.2 copy running-config startup-config . . . 24
1.3.3 disable . . . 24
1.3.4 logging color (0|1) . . . 25
1.3.5 logging disable . . . 25
1.3.6 logging enable . . . 25
1.3.7 logging filter all (0|1) . . . 26
1.3.8 logging level (pcap|client|server|vty|tls|l|global|l|lapd|linp|l|mux|l|mi|l|mib|l|sms|... . . . 26
1.3.9 logging level force-all (debug|info|notice|error|fatal) . . . 29
1.3.10 logging level set-all (debug|info|notice|error|fatal) . . . 29
1.3.11 logging print category (0|1) . . . 30
1.3.12 logging print category-hex (0|1) . . . 30
1.3.13 logging print extended-timestamp (0|1) . . . 31
1.3.14 logging print file (0|1|basename) [last] . . . 31
1.3.15 logging print level (0|1) . . . 32
1.3.16 logging print thread-id (0|1) . . . 32
1.3.17 logging set-log-mask MASK . . . 33
1.3.18 logging timestamp (0|1) . . . 33
1.3.19 logp (pcap|client|server|vty|tls|l|global|l|lapd|linp|l|mux|l|mi|l|mib|l|sms|l|ctrl|l|gt... . . . 34

1.3.20 no logging level force-all . . . 36
1.3.21 show alarms . . . 36
1.3.22 show asciidoc counters . . . 37
1.3.23 show history . . . 37
1.3.24 show logging vty . . . 37
1.3.25 show online-help . . . 38
1.3.26 show rate-counters [skip-zero] . . . 38
1.3.27 show startup-config . . . 38
1.3.28 show stats [skip-zero] . . . 39
1.3.29 show stats level (global|peer|subscriber) [skip-zero] . . . 39
1.3.30 show talloc-context (application|global|all) (full|brief|DEPTH) . . . 40
1.3.31 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP . . . 40
1.3.32 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS . . . 41
1.3.33 show version . . . 42
1.3.34 shutdown . . . 42
1.3.35 stats report . . . 42
1.3.36 stats reset . . . 42
1.3.37 terminal length <0-512> . . . 43
1.3.38 terminal monitor . . . 43
1.3.39 terminal no length . . . 43
1.3.40 terminal no monitor . . . 44
1.3.41 who . . . 44
1.4 config . . . 44
1.4.1 banner motd default . . . 44
1.4.2 banner motd file [FILE] . . . 45
1.4.3 client . . . 45
1.4.4 enable password (8|) WORD . . . 45
1.4.5 enable password LINE . . . 46
1.4.6 hostname WORD . . . 46
1.4.7 line vty . . . 46
1.4.8 log alarms <2-32700> . . . 47
1.4.9 log file FILENAME [blocking-io] . . . 47
1.4.10 log gsmtap [HOSTNAME] . . . 47
1.4.11 log stderr [blocking-io] . . . 48
1.4.12 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp) . . . 48
1.4.13 log syslog local <0-7> . . . 49
1.4.14 log systemd-journal [raw] . . . 49
1.4.15 no banner motd . . . 49
1.4.16 no enable password . . . 50

1.4.17 no hostname [HOSTNAME] . . . 50
1.4.18 no log alarms . . . 50
1.4.19 no log file FILENAME . . . 51
1.4.20 no log gsmtap [HOSTNAME] . . . 51
1.4.21 no log stderr . . . 51
1.4.22 no log syslog . . . 52
1.4.23 no log systemd-journal . . . 52
1.4.24 no service advanced-vty . . . 52
1.4.25 no service terminal-length [<0-512>] . . . 53
1.4.26 no stats reporter log [NAME] . . . 53
1.4.27 no stats reporter statsd [NAME] . . . 54
1.4.28 password (8|) WORD . . . 54
1.4.29 password LINE . . . 54
1.4.30 service advanced-vty . . . 55
1.4.31 service terminal-length <0-512> . . . 55
1.4.32 show history . . . 55
1.4.33 stats interval <0-65535> . . . 56
1.4.34 stats reporter log [NAME] . . . 56
1.4.35 stats reporter statsd [NAME] . . . 56
1.4.36 stats-tcp batch-size <1-65535> . . . 57
1.4.37 stats-tcp interval <0-65535> . . . 57
1.5 config-log . . . 57
1.5.1 logging color (0|1) . . . 58
1.5.2 logging filter all (0|1) . . . 58
1.5.3 logging level (pcap|client|server|vty|tls|lglobal|lapd|linp|lmux|lmi|lmib|lsms|... . . . 59
1.5.4 logging level force-all (debug|info|notice|error|fatal) . . . 61
1.5.5 logging level set-all (debug|info|notice|error|fatal) . . . 62
1.5.6 logging print category (0|1) . . . 62
1.5.7 logging print category-hex (0|1) . . . 63
1.5.8 logging print extended-timestamp (0|1) . . . 63
1.5.9 logging print file (0|1|basename) [last] . . . 64
1.5.10 logging print level (0|1) . . . 64
1.5.11 logging print thread-id (0|1) . . . 65
1.5.12 logging timestamp (0|1) . . . 65
1.5.13 no logging level force-all . . . 66
1.6 config-stats . . . 66
1.6.1 disable . . . 66
1.6.2 enable . . . 66
1.6.3 flush-period <0-65535> . . . 67

1.6.4 level (global|peer|subscriber) . . . 67
1.6.5 local-ip ADDR . . . 67
1.6.6 mtu <100-65535> . . . 68
1.6.7 no local-ip . . . 68
1.6.8 no mtu . . . 68
1.6.9 no prefix . . . 69
1.6.10 prefix PREFIX . . . 69
1.6.11 remote-ip ADDR . . . 69
1.6.12 remote-port <1-65535> . . . 70
1.7 config-line . . . 70
1.7.1 bind A.B.C.D [<0-65535>] . . . 70
1.7.2 login . . . 70
1.7.3 no login . . . 71
1.8 client . . . 71
1.8.1 disable tls . . . 71
1.8.2 enable tls . . . 71
1.8.3 no pcap add-filter gprs . . . 72
1.8.4 no pcap-store-connection .NAME . . . 72
1.8.5 no tls capath . . . 72
1.8.6 no tls client-cert . . . 73
1.8.7 no tls client-key . . . 73
1.8.8 no tls hostname . . . 73
1.8.9 no tls priority . . . 74
1.8.10 no tls verify-cert . . . 74
1.8.11 pcap add-filter gprs . . . 74
1.8.12 pcap detect-loop (0|1) . . . 75
1.8.13 pcap device NAME . . . 75
1.8.14 pcap filter .NAME . . . 75
1.8.15 pcap snaplen <1-262144> . . . 76
1.8.16 pcap-store-connection .NAME . . . 76
1.8.17 protocol (osmo-pcap|ipip) . . . 76
1.8.18 server ip A.B.C.D . . . 77
1.8.19 server port <1-65535> . . . 77
1.8.20 source ip A.B.C.D . . . 77
1.8.21 tls capath .PATH . . . 78
1.8.22 tls client-cert .PATH . . . 78
1.8.23 tls client-key .PATH . . . 78
1.8.24 tls hostname NAME . . . 79
1.8.25 tls log-level <0-255> . . . 79

1.8.26 tls priority STR . . . 79
1.8.27 tls verify-cert . . . 80
1.8.28 wqueue max-length <1-4294967295> . . . 80
1.9 server . . . 80
1.9.1 connect . . . 80
1.9.2 disable tls . . . 81
1.9.3 disconnect . . . 81
1.9.4 enable tls . . . 81
1.9.5 no tls capath . . . 82
1.9.6 no tls client-cert . . . 82
1.9.7 no tls client-key . . . 82
1.9.8 no tls hostname . . . 83
1.9.9 no tls priority . . . 83
1.9.10 no tls verify-cert . . . 83
1.9.11 protocol (osmo-pcaplipip) . . . 84
1.9.12 server ip A.B.C.D . . . 84
1.9.13 server port <1-65535> . . . 84
1.9.14 source ip A.B.C.D . . . 85
1.9.15 tls capath .PATH . . . 85
1.9.16 tls client-cert .PATH . . . 85
1.9.17 tls client-key .PATH . . . 86
1.9.18 tls hostname NAME . . . 86
1.9.19 tls log-level <0-255> . . . 86
1.9.20 tls priority STR . . . 87
1.9.21 tls verify-cert . . . 87

List of Tables

1.1 VTY Parameter Patterns 1
1.2 VTY port numbers 1

Chapter 1

VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA|OptionB|OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

1.1.1 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

1.1.2 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

1.1.3 help

Command

```
help
```

Parameters

help

Description of the interactive help system

1.1.4 list [with-flags]

Command

```
list [with-flags]
```

Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

1.1.5 show running-config

Command

```
show running-config
```

Parameters

show
: Show running system information

running-config
: running configuration

1.1.6 show vty-attributes

Command

```
show vty-attributes
```

Parameters

show
: Show running system information

vty-attributes
: List of VTY attributes

1.1.7 show vty-attributes (application|library|global)

Command

```
show vty-attributes (application|library|global)
```

Parameters

show
: Show running system information

vty-attributes
: List of VTY attributes

application
: Application specific attributes only

library
: Library specific attributes only

global
: Global attributes only

1.1.8 write

Command

```
write
```

Parameters

write
: Write running configuration to memory, network, or terminal

1.1.9 write file [PATH]

Command

```
write file [PATH]
```

Parameters

write
: Write running configuration to memory, network, or terminal

file
: Write to configuration file

[PATH]
: Set file path to store the config, or replace if already exists

1.1.10 write memory

Command

```
write memory
```

Parameters

write
: Write running configuration to memory, network, or terminal

memory
: Write configuration to the file (same as write file)

1.1.11 write terminal

Command

```
write terminal
```

Parameters

write
: Write running configuration to memory, network, or terminal

terminal
: Write to terminal

1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

1.2.1 enable [expert-mode]

Command

```
enable [expert-mode]
```

Parameters

enable
: Turn on privileged mode command

[expert-mode]
: Enable the expert mode (show hidden commands)

1.2.2 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging
: Configure logging

color
: Configure color-printing for log messages

0
: Don't use color for printing messages

1
: Use color for printing messages

1.2.3 logging disable

Command

```
logging disable
```

Parameters

logging
: Configure logging

disable
: Disables logging to this vty

1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging
: Configure logging

enable
: Enables logging to this vty

1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging
: Configure logging

filter
: Filter log messages

all
: Do you want to log all messages?

0
: Only print messages matched by other filters

1
: Bypass filter and print all messages

1.2.6 logging level (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|...

Command

```
logging level (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl| ↩
    lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata ↩
    |lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

pcap
: PCAP related functionality

client
: Client related functionality

server
: Server related functionality

vty
: VTY code

tls
: TLS code

lglobal
: Library-internal global log family

llapd
: LAPD in libosmogsm

linp
: A-bis Intput Subsystem

lmux
: A-bis B-Subchannel TRAU Frame Multiplex

lmi
: A-bis Input Driver for Signalling

lmib
: A-bis Input Driver for B-Channels (voice)

lsms
: Layer3 Short Message Service (SMS)

lctrl
: Control Interface

lgtp
: GPRS GTP library

lstats
: Statistics messages and logging

lgsup
: Generic Subscriber Update Protocol

loap
: Osmocom Authentication Protocol

lss7
: libosmo-sigtran Signalling System 7

lsccp
: libosmo-sigtran SCCP Implementation

lsua
: libosmo-sigtran SCCP User Adaptation

lm3ua
: libosmo-sigtran MTP3 User Adaptation

lmgcp
: libosmo-mgcp Media Gateway Control Protocol

ljibuf
: libosmo-netif Jitter Buffer

lrspro
: Remote SIM protocol

lns
: GPRS NS layer

lbssgp
: GPRS BSSGP layer

lnsdata
: GPRS NS layer data PDU

lnssignal
: GPRS NS layer signal PDU

liuup
: Iu UP layer

lpfcp
: libosmo-pfcp Packet Forwarding Control Protocol

lcsn1
: libosmo-csn1 Concrete Syntax Notation 1 codec

lio
: libosmocore IO Subsystem

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.2.7 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

force-all
: Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.2.8 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

set-all
: Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.2.9 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

category
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with category/subsystem name

1.2.10 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

category-hex
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with category/subsystem nr in hex ('<000b>')

1.2.11 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

extended-timestamp
: Configure log message timestamping

0
: Don't prefix each log message

1
: Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

1.2.12 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging
: Configure logging

print
: Log output settings

file
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with the source file and line

basename
: Prefix each log message with the source file's basename (strip leading paths) and line

[last]
: Log source file info at the end of a log line. If omitted, log source file info just before the log text.

1.2.13 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

level
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with the log level name

1.2.14 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

thread-id
: Configure log message logging Thread ID

0
: Don't prefix each log message

1
: Prefix each log message with current Thread ID

1.2.15 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging
: Configure logging

set-log-mask
: Set the logmask of this logging target

MASK
: List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

1.2.16 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging
: Configure logging

timestamp
: Configure log message timestamping

0
: Don't prefix each log message

1
: Prefix each log message with current timestamp

1.2.17 logp (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgt...

Command

```
logp (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp| ↩
    lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ↩
    lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal) .LOGMESSAGE
```

Parameters

logp
: Print a message on all log outputs; useful for placing markers in test logs

pcap
: PCAP related functionality

client
: Client related functionality

server
: Server related functionality

vty
: VTY code

tls
: TLS code

lglobal
: Library-internal global log family

llapd
: LAPD in libosmogsm

linp
: A-bis Intput Subsystem

lmux
: A-bis B-Subchannel TRAU Frame Multiplex

lmi
: A-bis Input Driver for Signalling

lmib
: A-bis Input Driver for B-Channels (voice)

lsms
: Layer3 Short Message Service (SMS)

lctrl
: Control Interface

lgtp
: GPRS GTP library

lstats
: Statistics messages and logging

lgsup
: Generic Subscriber Update Protocol

loap
: Osmocom Authentication Protocol

lss7
: libosmo-sigtran Signalling System 7

lsccp
: libosmo-sigtran SCCP Implementation

lsua
: libosmo-sigtran SCCP User Adaptation

lm3ua
: libosmo-sigtran MTP3 User Adaptation

lmgcp
: libosmo-mgcp Media Gateway Control Protocol

ljibuf
: libosmo-netif Jitter Buffer

lrspro
: Remote SIM protocol

lns
: GPRS NS layer

lbssgp
: GPRS BSSGP layer

lnsdata
: GPRS NS layer data PDU

lnssignal
: GPRS NS layer signal PDU

liuup
: Iu UP layer

lpfcp
: libosmo-pfcp Packet Forwarding Control Protocol

lcsn1
: libosmo-csn1 Concrete Syntax Notation 1 codec

lio
: libosmocore IO Subsystem

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

.LOGMESSAGE
: Arbitrary message to log on given category and log level

1.2.18 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no
: Negate a command or set its defaults

logging
: Configure logging

level
: Set the log level for a specified category

force-all
: Release any globally forced log level set with 'logging level force-all <level>'

1.2.19 show alarms

Command

```
show alarms
```

Parameters

show
: Show running system information

alarms
: Show current logging configuration

1.2.20 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show
: Show running system information

asciidoc
: Asciidoc generation

counters
: Generate table of all registered counters

1.2.21 show history

Command

```
show history
```

Parameters

show
: Show running system information

history
: Display the session command history

1.2.22 show logging vty

Command

```
show logging vty
```

Parameters

show
: Show running system information

logging
: Show current logging configuration

vty
: Show current logging configuration for this vty

1.2.23 show online-help

Command

```
show online-help
```

Parameters

show
: Show running system information

online-help
: Online help

1.2.24 show pid

Command

```
show pid
```

Parameters

show
: Show running system information

pid
: Displays the process ID

1.2.25 show rate-counters [skip-zero]

Command

```
show rate-counters [skip-zero]
```

Parameters

show
: Show running system information

rate-counters
: Show all rate counters

[skip-zero]
: Skip items with total count zero

1.2.26 show stats [skip-zero]

Command

```
show stats [skip-zero]
```

Parameters

show
: Show running system information

stats
: Show statistical values

[skip-zero]
: Skip items with total count zero

1.2.27 show stats level (global|peer|subscriber) [skip-zero]

Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

Parameters

show
: Show running system information

stats
: Show statistical values

level
: Set the maximum group level

global
: Show global groups only

peer
: Show global and network peer related groups

subscriber
: Show global, peer, and subscriber groups

[skip-zero]
: Skip items with total count zero

1.2.28 show talloc-context (application|global|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

Parameters

show
: Show running system information

talloc-context
: Show talloc memory hierarchy

application
: Application's context

global
: Global context (OTC_GLOBAL)

all
: All contexts, if NULL-context tracking is enabled

full
: Display a full talloc memory hierarchy

brief
: Display a brief talloc memory hierarchy

DEPTH
: Specify required maximal depth value

1.2.29 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show
: Show running system information

talloc-context
: Show talloc memory hierarchy

application
: Application's context

global
: Global context (OTC_GLOBAL)

all
: All contexts, if NULL-context tracking is enabled

full
: Display a full talloc memory hierarchy

brief
: Display a brief talloc memory hierarchy

DEPTH
: Specify required maximal depth value

filter
: Filter chunks using regular expression

REGEXP
: Regular expression

1.2.30 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show
: Show running system information

talloc-context
: Show talloc memory hierarchy

application
: Application's context

global
: Global context (OTC_GLOBAL)

all
: All contexts, if NULL-context tracking is enabled

full
: Display a full talloc memory hierarchy

brief
: Display a brief talloc memory hierarchy

DEPTH
: Specify required maximal depth value

tree
: Display only a specific memory chunk

ADDRESS
: Chunk address (e.g. 0xdeadbeef)

1.2.31 show uptime

Command

```
show uptime
```

Parameters

show
: Show running system information

uptime
: Displays how long the program has been running

1.2.32 show version

Command

```
show version
```

Parameters

show
: Show running system information

version
: Displays program version

1.2.33 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal
: Set terminal line parameters

length
: Set number of lines on a screen

<0-512>
: Number of lines on screen (0 for no pausing)

1.2.34 terminal no length

Command

```
terminal no length
```

Parameters

terminal
: Set terminal line parameters

no
: Negate a command or set its defaults

length
: Set number of lines on a screen

1.2.35 who

Command

```
who
```

Parameters

who
: Display who is on vty

1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

1.3.1 configure [terminal]

Command

```
configure [terminal]
```

Parameters

configure
: Configuration from vty interface

[terminal]
: Configuration terminal

1.3.2 copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy
: Copy configuration

running-config
: Copy running config to...

startup-config
: Copy running config to startup config (same as write file)

1.3.3 disable

Command

```
disable
```

Parameters

disable
: Turn off privileged mode command

1.3.4 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging
: Configure logging

color
: Configure color-printing for log messages

0
: Don't use color for printing messages

1
: Use color for printing messages

1.3.5 logging disable

Command

```
logging disable
```

Parameters

logging
: Configure logging

disable
: Disables logging to this vty

1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging
: Configure logging

enable
: Enables logging to this vty

1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging
: Configure logging

filter
: Filter log messages

all
: Do you want to log all messages?

0
: Only print messages matched by other filters

1
: Bypass filter and print all messages

1.3.8 logging level (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|...

Command

```
logging level (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl| ↩
    lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata ↩
    |lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

pcap
: PCAP related functionality

client
: Client related functionality

server
: Server related functionality

vty
: VTY code

tls
: TLS code

lglobal
: Library-internal global log family

llapd
: LAPD in libosmogsm

linp
: A-bis Intput Subsystem

lmux
: A-bis B-Subchannel TRAU Frame Multiplex

lmi
: A-bis Input Driver for Signalling

lmib
: A-bis Input Driver for B-Channels (voice)

lsms
: Layer3 Short Message Service (SMS)

lctrl
: Control Interface

lgtp
: GPRS GTP library

lstats
: Statistics messages and logging

lgsup
: Generic Subscriber Update Protocol

loap
: Osmocom Authentication Protocol

lss7
: libosmo-sigtran Signalling System 7

lsccp
: libosmo-sigtran SCCP Implementation

lsua
: libosmo-sigtran SCCP User Adaptation

lm3ua
: libosmo-sigtran MTP3 User Adaptation

lmgcp
: libosmo-mgcp Media Gateway Control Protocol

ljibuf
: libosmo-netif Jitter Buffer

lrspro
: Remote SIM protocol

lns
: GPRS NS layer

lbssgp
: GPRS BSSGP layer

lnsdata
: GPRS NS layer data PDU

lnssignal
: GPRS NS layer signal PDU

liuup
: Iu UP layer

lpfcp
: libosmo-pfcp Packet Forwarding Control Protocol

lcsn1
: libosmo-csn1 Concrete Syntax Notation 1 codec

lio
: libosmocore IO Subsystem

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.3.9 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

force-all
: Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.3.10 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

set-all
: Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.3.11 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

category
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with category/subsystem name

1.3.12 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

category-hex
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with category/subsystem nr in hex ('<000b>')

1.3.13 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

extended-timestamp
: Configure log message timestamping

0
: Don't prefix each log message

1
: Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

1.3.14 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging
: Configure logging

print
: Log output settings

file
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with the source file and line

basename
: Prefix each log message with the source file's basename (strip leading paths) and line

[last]
: Log source file info at the end of a log line. If omitted, log source file info just before the log text.

1.3.15 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

level
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with the log level name

1.3.16 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

thread-id
: Configure log message logging Thread ID

0
: Don't prefix each log message

1
: Prefix each log message with current Thread ID

1.3.17 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging
: Configure logging

set-log-mask
: Set the logmask of this logging target

MASK
: List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

1.3.18 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging
: Configure logging

timestamp
: Configure log message timestamping

0
: Don't prefix each log message

1
: Prefix each log message with current timestamp

1.3.19 logp (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgt...

Command

```
logp (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp| ↩
    lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ↩
    lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal) .LOGMESSAGE
```

Parameters

logp
: Print a message on all log outputs; useful for placing markers in test logs

pcap
: PCAP related functionality

client
: Client related functionality

server
: Server related functionality

vty
: VTY code

tls
: TLS code

lglobal
: Library-internal global log family

llapd
: LAPD in libosmogsm

linp
: A-bis Intput Subsystem

lmux
: A-bis B-Subchannel TRAU Frame Multiplex

lmi
: A-bis Input Driver for Signalling

lmib
: A-bis Input Driver for B-Channels (voice)

lsms
: Layer3 Short Message Service (SMS)

lctrl
: Control Interface

lgtp
: GPRS GTP library

lstats
: Statistics messages and logging

lgsup
: Generic Subscriber Update Protocol

loap
: Osmocom Authentication Protocol

lss7
: libosmo-sigtran Signalling System 7

lsccp
: libosmo-sigtran SCCP Implementation

lsua
: libosmo-sigtran SCCP User Adaptation

lm3ua
: libosmo-sigtran MTP3 User Adaptation

lmgcp
: libosmo-mgcp Media Gateway Control Protocol

ljibuf
: libosmo-netif Jitter Buffer

lrspro
: Remote SIM protocol

lns
: GPRS NS layer

lbssgp
: GPRS BSSGP layer

lnsdata
: GPRS NS layer data PDU

lnssignal
: GPRS NS layer signal PDU

liuup
: Iu UP layer

lpfcp
: libosmo-pfcp Packet Forwarding Control Protocol

lcsn1
: libosmo-csn1 Concrete Syntax Notation 1 codec

lio
: libosmocore IO Subsystem

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

.LOGMESSAGE
: Arbitrary message to log on given category and log level

1.3.20 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no
: Negate a command or set its defaults

logging
: Configure logging

level
: Set the log level for a specified category

force-all
: Release any globally forced log level set with 'logging level force-all <level>'

1.3.21 show alarms

Command

```
show alarms
```

Parameters

show
: Show running system information

alarms
: Show current logging configuration

1.3.22 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show
: Show running system information

asciidoc
: Asciidoc generation

counters
: Generate table of all registered counters

1.3.23 show history

Command

```
show history
```

Parameters

show
: Show running system information

history
: Display the session command history

1.3.24 show logging vty

Command

```
show logging vty
```

Parameters

show
: Show running system information

logging
: Show current logging configuration

vty
: Show current logging configuration for this vty

1.3.25 show online-help

Command

```
show online-help
```

Parameters

show
: Show running system information

online-help
: Online help

1.3.26 show rate-counters [skip-zero]

Command

```
show rate-counters [skip-zero]
```

Parameters

show
: Show running system information

rate-counters
: Show all rate counters

[skip-zero]
: Skip items with total count zero

1.3.27 show startup-config

Command

```
show startup-config
```

Parameters

show
: Show running system information

startup-config
: Contentes of startup configuration

1.3.28 show stats [skip-zero]

Command

```
show stats [skip-zero]
```

Parameters

show
: Show running system information

stats
: Show statistical values

[skip-zero]
: Skip items with total count zero

1.3.29 show stats level (global|peer|subscriber) [skip-zero]

Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

Parameters

show
: Show running system information

stats
: Show statistical values

level
: Set the maximum group level

global
: Show global groups only

peer
: Show global and network peer related groups

subscriber
: Show global, peer, and subscriber groups

[skip-zero]
: Skip items with total count zero

1.3.30 show talloc-context (application|global|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

Parameters

show
: Show running system information

talloc-context
: Show talloc memory hierarchy

application
: Application's context

global
: Global context (OTC_GLOBAL)

all
: All contexts, if NULL-context tracking is enabled

full
: Display a full talloc memory hierarchy

brief
: Display a brief talloc memory hierarchy

DEPTH
: Specify required maximal depth value

1.3.31 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show
: Show running system information

talloc-context
: Show talloc memory hierarchy

application
: Application's context

global
: Global context (OTC_GLOBAL)

all
: All contexts, if NULL-context tracking is enabled

full
: Display a full talloc memory hierarchy

brief
: Display a brief talloc memory hierarchy

DEPTH
: Specify required maximal depth value

filter
: Filter chunks using regular expression

REGEXP
: Regular expression

1.3.32 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show
: Show running system information

talloc-context
: Show talloc memory hierarchy

application
: Application's context

global
: Global context (OTC_GLOBAL)

all
: All contexts, if NULL-context tracking is enabled

full
: Display a full talloc memory hierarchy

brief
: Display a brief talloc memory hierarchy

DEPTH
: Specify required maximal depth value

tree
: Display only a specific memory chunk

ADDRESS
: Chunk address (e.g. 0xdeadbeef)

1.3.33 show version

Command

```
show version
```

Parameters

show
: Show running system information

version
: Displays program version

1.3.34 shutdown

Command

```
shutdown
```

Parameters

shutdown
: Request a shutdown of the program

1.3.35 stats report

Command

```
stats report
```

Parameters

stats
: Stats related commands

report
: Manurally trigger reporting of stats

1.3.36 stats reset

Command

```
stats reset
```

Parameters

stats
: Stats related commands

reset
: Reset all rate counter stats

1.3.37 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal
: Set terminal line parameters

length
: Set number of lines on a screen

<0-512>
: Number of lines on screen (0 for no pausing)

1.3.38 terminal monitor

Command

```
terminal monitor
```

Parameters

terminal
: Set terminal line parameters

monitor
: Copy debug output to the current terminal line

1.3.39 terminal no length

Command

```
terminal no length
```

Parameters

terminal
: Set terminal line parameters

no
: Negate a command or set its defaults

length
: Set number of lines on a screen

1.3.40 terminal no monitor

Command

```
terminal no monitor
```

Parameters

terminal
: Set terminal line parameters

no
: Negate a command or set its defaults

monitor
: Copy debug output to the current terminal line

1.3.41 who

Command

```
who
```

Parameters

who
: Display who is on vty

1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

1.4.1 banner motd default

Command

```
banner motd default
```

Parameters

banner
: Set banner string

motd
: Strings for motd

default
: Default string

1.4.2 banner motd file [FILE]

Command

```
banner motd file [FILE]
```

Parameters

banner
: Set banner

motd
: Banner for motd

file
: Banner from a file

[FILE]
: Filename

1.4.3 client

Command

```
client
```

Parameters

client
: Enter the client configuration

1.4.4 enable password (8|) WORD

Command

```
enable password (8|) WORD
```

Parameters

enable
: Modify enable password parameters

password
: Assign the privileged level password

8
: Specifies a HIDDEN password will follow

dummy string

WORD
: The HIDDEN 'enable' password string

1.4.5 enable password LINE

Command

```
enable password LINE
```

Parameters

enable
: Modify enable password parameters

password
: Assign the privileged level password

LINE
: The UNENCRYPTED (cleartext) 'enable' password

1.4.6 hostname WORD

Command

```
hostname WORD
```

Parameters

hostname
: Set system's network name

WORD
: This system's network name

1.4.7 line vty

Command

```
line vty
```

Parameters

line
: Configure a terminal line

vty
: Virtual terminal

1.4.8 log alarms <2-32700>

Command

```
log alarms <2-32700>
```

Parameters

log
: Configure logging sub-system

alarms
: Logging alarms to osmo_strrb

<2-32700>
: Maximum number of messages to log

1.4.9 log file FILENAME [blocking-io]

Command

```
log file FILENAME [blocking-io]
```

Parameters

log
: Configure logging sub-system

file
: Logging to text file

FILENAME
: Filename

[blocking-io]
: Use blocking, synchronous I/O

1.4.10 log gsmtap [HOSTNAME]

Command

```
log gsmtap [HOSTNAME]
```

Parameters

log
: Configure logging sub-system

gsmtap
: Logging via GSMTAP

[HOSTNAME]
: Host name to send the GSMTAP logging to (UDP port 4729)

1.4.11 log stderr [blocking-io]

Command

```
log stderr [blocking-io]
```

Parameters

log
: Configure logging sub-system

stderr
: Logging via STDERR of the process

[blocking-io]
: Use blocking, synchronous I/O

1.4.12 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

Parameters

log
: Configure logging sub-system

syslog
: Logging via syslog

authpriv
: Security/authorization messages facility

cron
: Clock daemon (cron/at) facility

daemon
: General system daemon facility

ftp
: Ftp daemon facility

lpr
: Line printer facility

mail
: Mail facility

news
: News facility

user
: Generic facility

uucp
: UUCP facility

1.4.13 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log
: Configure logging sub-system

syslog
: Logging via syslog

local
: Syslog LOCAL facility

<0-7>
: Local facility number

1.4.14 log systemd-journal [raw]

Command

```
log systemd-journal [raw]
```

Parameters

log
: Configure logging sub-system

systemd-journal
: Logging to systemd-journal

[raw]
: Offload rendering of the meta information (location, category) to systemd

1.4.15 no banner motd

Command

```
no banner motd
```

Parameters

no
: Negate a command or set its defaults

banner
: Set banner string

motd
: Strings for motd

1.4.16 no enable password

Command

```
no enable password
```

Parameters

no
: Negate a command or set its defaults

enable
: Modify enable password parameters

password
: Assign the privileged level password

1.4.17 no hostname [HOSTNAME]

Command

```
no hostname [HOSTNAME]
```

Parameters

no
: Negate a command or set its defaults

hostname
: Reset system's network name

[HOSTNAME]
: Host name of this router

1.4.18 no log alarms

Command

```
no log alarms
```

Parameters

no
: Negate a command or set its defaults

log
: Configure logging sub-system

alarms
: Logging alarms to osmo_strrb

1.4.19 no log file FILENAME

Command

```
no log file FILENAME
```

Parameters

no
: Negate a command or set its defaults

log
: Configure logging sub-system

file
: Logging to text file

FILENAME
: Filename

1.4.20 no log gsmtap [HOSTNAME]

Command

```
no log gsmtap [HOSTNAME]
```

Parameters

no
: Negate a command or set its defaults

log
: Configure logging sub-system

gsmtap
: Logging via GSMTAP

[HOSTNAME]
: Host name to send the GSMTAP logging to (UDP port 4729)

1.4.21 no log stderr

Command

```
no log stderr
```

Parameters

no
: Negate a command or set its defaults

log
: Configure logging sub-system

stderr
: Logging via STDERR of the process

1.4.22 no log syslog

Command

```
no log syslog
```

Parameters

no
: Negate a command or set its defaults

log
: Configure logging sub-system

syslog
: Logging via syslog

1.4.23 no log systemd-journal

Command

```
no log systemd-journal
```

Parameters

no
: Negate a command or set its defaults

log
: Configure logging sub-system

systemd-journal
: Logging to systemd-journal

1.4.24 no service advanced-vty

Command

```
no service advanced-vty
```

Parameters

no
: Negate a command or set its defaults

service
: Set up miscellaneous service

advanced-vty
: Enable advanced mode vty interface

1.4.25 no service terminal-length [<0-512>]

Command

```
no service terminal-length [<0-512>]
```

Parameters

no
: Negate a command or set its defaults

service
: Set up miscellaneous service

terminal-length
: System wide terminal length configuration

[<0-512>]
: Number of lines of VTY (0 means no line control)

1.4.26 no stats reporter log [NAME]

Command

```
no stats reporter log [NAME]
```

Parameters

no
: Negate a command or set its defaults

stats
: Configure stats sub-system

reporter
: Configure a stats reporter

log
: Report to the logger

[NAME]
: Name of the reporter

1.4.27 no stats reporter statsd [NAME]

Command

```
no stats reporter statsd [NAME]
```

Parameters

no
: Negate a command or set its defaults

stats
: Configure stats sub-system

reporter
: Configure a stats reporter

statsd
: Report to a STATSD server

[NAME]
: Name of the reporter

1.4.28 password (8|) WORD

Command

```
password (8|) WORD
```

Parameters

password
: Assign the terminal connection password

8
: Specifies a HIDDEN password will follow

dummy string

WORD
: The HIDDEN line password string

1.4.29 password LINE

Command

```
password LINE
```

Parameters

password
: Assign the terminal connection password

LINE
: The UNENCRYPTED (cleartext) line password

1.4.30 service advanced-vty

Command

```
service advanced-vty
```

Parameters

service
: Set up miscellaneous service

advanced-vty
: Enable advanced mode vty interface

1.4.31 service terminal-length <0-512>

Command

```
service terminal-length <0-512>
```

Parameters

service
: Set up miscellaneous service

terminal-length
: System wide terminal length configuration

<0-512>
: Number of lines of VTY (0 means no line control)

1.4.32 show history

Command

```
show history
```

Parameters

show
: Show running system information

history
: Display the session command history

1.4.33 stats interval <0-65535>

Command

```
stats interval <0-65535>
```

Parameters

stats
: Configure stats sub-system

interval
: Set the reporting interval

<0-65535>
: Interval in seconds (0 disables the reporting interval)

1.4.34 stats reporter log [NAME]

Command

```
stats reporter log [NAME]
```

Parameters

stats
: Configure stats sub-system

reporter
: Configure a stats reporter

log
: Report to the logger

[NAME]
: Name of the reporter

1.4.35 stats reporter statsd [NAME]

Command

```
stats reporter statsd [NAME]
```

Parameters

stats
: Configure stats sub-system

reporter
: Configure a stats reporter

statsd
: Report to a STATSD server

[NAME]
: Name of the reporter

1.4.36 stats-tcp batch-size <1-65535>

Command

```
stats-tcp batch-size <1-65535>
```

Parameters

stats-tcp
: Configure stats sub-system

batch-size
: Set the number of tcp sockets that are processed per stats polling interval

<1-65535>
: Number of sockets per interval

1.4.37 stats-tcp interval <0-65535>

Command

```
stats-tcp interval <0-65535>
```

Parameters

stats-tcp
: Configure stats sub-system

interval
: Set the tcp socket stats polling interval

<0-65535>
: Interval in seconds (0 disables the polling interval)

1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

1.5.1 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging
: Configure logging

color
: Configure color-printing for log messages

0
: Don't use color for printing messages

1
: Use color for printing messages

1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging
: Configure logging

filter
: Filter log messages

all
: Do you want to log all messages?

0
: Only print messages matched by other filters

1
: Bypass filter and print all messages

1.5.3 logging level (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|...

Command

```
logging level (pcap|client|server|vty|tls|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl| ↩
    lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata ↩
    |lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

pcap
: PCAP related functionality

client
: Client related functionality

server
: Server related functionality

vty
: VTY code

tls
: TLS code

lglobal
: Library-internal global log family

llapd
: LAPD in libosmogsm

linp
: A-bis Intput Subsystem

lmux
: A-bis B-Subchannel TRAU Frame Multiplex

lmi
: A-bis Input Driver for Signalling

lmib
: A-bis Input Driver for B-Channels (voice)

lsms
: Layer3 Short Message Service (SMS)

lctrl
: Control Interface

lgtp
: GPRS GTP library

lstats
: Statistics messages and logging

lgsup
: Generic Subscriber Update Protocol

loap
: Osmocom Authentication Protocol

lss7
: libosmo-sigtran Signalling System 7

lsccp
: libosmo-sigtran SCCP Implementation

lsua
: libosmo-sigtran SCCP User Adaptation

lm3ua
: libosmo-sigtran MTP3 User Adaptation

lmgcp
: libosmo-mgcp Media Gateway Control Protocol

ljibuf
: libosmo-netif Jitter Buffer

lrspro
: Remote SIM protocol

lns
: GPRS NS layer

lbssgp
: GPRS BSSGP layer

lnsdata
: GPRS NS layer data PDU

lnssignal
: GPRS NS layer signal PDU

liuup
: Iu UP layer

lpfcp
: libosmo-pfcp Packet Forwarding Control Protocol

lcsn1
: libosmo-csn1 Concrete Syntax Notation 1 codec

lio
: libosmocore IO Subsystem

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.5.4 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

force-all
: Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.5.5 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging
: Configure logging

level
: Set the log level for a specified category

set-all
: Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug
: Log debug messages and higher levels

info
: Log informational messages and higher levels

notice
: Log noticeable messages and higher levels

error
: Log error messages and higher levels

fatal
: Log only fatal messages

1.5.6 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

category
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with category/subsystem name

1.5.7 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

category-hex
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with category/subsystem nr in hex ('<000b>')

1.5.8 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

extended-timestamp
: Configure log message timestamping

0
: Don't prefix each log message

1
: Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

1.5.9 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging
: Configure logging

print
: Log output settings

file
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with the source file and line

basename
: Prefix each log message with the source file's basename (strip leading paths) and line

[last]
: Log source file info at the end of a log line. If omitted, log source file info just before the log text.

1.5.10 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

level
: Configure log message

0
: Don't prefix each log message

1
: Prefix each log message with the log level name

1.5.11 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging
: Configure logging

print
: Log output settings

thread-id
: Configure log message logging Thread ID

0
: Don't prefix each log message

1
: Prefix each log message with current Thread ID

1.5.12 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging
: Configure logging

timestamp
: Configure log message timestamping

0
: Don't prefix each log message

1
: Prefix each log message with current timestamp

1.5.13 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no
: Negate a command or set its defaults

logging
: Configure logging

level
: Set the log level for a specified category

force-all
: Release any globally forced log level set with 'logging level force-all <level>'

1.6 config-stats

1.6.1 disable

Command

```
disable
```

Parameters

disable
: Disable the reporter

1.6.2 enable

Command

```
enable
```

Parameters

enable
: Enable the reporter

1.6.3 flush-period <0-65535>

Command

```
flush-period <0-65535>
```

Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush)every N-th reporting interval. Set to 0 to disable regular flush (default).

1.6.4 level (global|peer|subscriber)

Command

```
level (global|peer|subscriber)
```

Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

1.6.5 local-ip ADDR

Command

```
local-ip ADDR
```

Parameters

local-ip

Set the IP address to which we bind locally

ADDR

IP Address

1.6.6 mtu <100-65535>

Command

```
mtu <100-65535>
```

Parameters

mtu
: Set the maximum packet size

<100-65535>
: Size in byte

1.6.7 no local-ip

Command

```
no local-ip
```

Parameters

no
: Negate a command or set its defaults

local-ip
: Set the IP address to which we bind locally

1.6.8 no mtu

Command

```
no mtu
```

Parameters

no
: Negate a command or set its defaults

mtu
: Set the maximum packet size

1.6.9 no prefix

Command

```
no prefix
```

Parameters

no
: Negate a command or set its defaults

prefix
: Set the item name prefix

1.6.10 prefix PREFIX

Command

```
prefix PREFIX
```

Parameters

prefix
: Set the item name prefix

PREFIX
: The prefix string

1.6.11 remote-ip ADDR

Command

```
remote-ip ADDR
```

Parameters

remote-ip
: Set the remote IP address to which we connect

ADDR
: IP Address

1.6.12 remote-port <1-65535>

Command

```
remote-port <1-65535>
```

Parameters

remote-port
: Set the remote port to which we connect

<1-65535>
: Remote port number

1.7 config-line

1.7.1 bind A.B.C.D [<0-65535>]

Command

```
bind A.B.C.D [<0-65535>]
```

Parameters

bind
: Accept VTY telnet connections on local interface

A.B.C.D
: Local interface IP address (default: 127.0.0.1)

[<0-65535>]
: Local TCP port number

1.7.2 login

Command

```
login
```

Parameters

login
: Enable password checking

1.7.3 no login

Command

```
no login
```

Parameters

no
: Negate a command or set its defaults

login
: Enable password checking

1.8 client

1.8.1 disable tls

Command

```
disable tls
```

Parameters

disable
: Disable

tls
: Transport Layer Security

1.8.2 enable tls

Command

```
enable tls
```

Parameters

enable
: Enable

tls
: Transport Layer Security

1.8.3 no pcap add-filter gprs

Command

```
no pcap add-filter gprs
```

Parameters

no
: Negate a command or set its defaults

pcap
: PCAP related functions

add-filter
: Add-filter

gprs
: Custom filter for GPRS

1.8.4 no pcap-store-connection .NAME

Command

```
no pcap-store-connection .NAME
```

Parameters

no
: Negate a command or set its defaults

pcap-store-connection
: Configure additional PCAP store server

.NAME
: Name of server

1.8.5 no tls capath

Command

```
no tls capath
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

capath
: Trusted root certificates

1.8.6 no tls client-cert

Command

```
no tls client-cert
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

client-cert
: Client certificate for authentication

1.8.7 no tls client-key

Command

```
no tls client-key
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

client-key
: Client private key

1.8.8 no tls hostname

Command

```
no tls hostname
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

hostname
: hostname for certificate validation

1.8.9 no tls priority

Command

```
no tls priority
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

priority
: Priority string for GNUtls

1.8.10 no tls verify-cert

Command

```
no tls verify-cert
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

verify-cert
: Verify certificates

1.8.11 pcap add-filter gprs

Command

```
pcap add-filter gprs
```

Parameters

pcap
: PCAP related functions

add-filter
: Add-filter

gprs
: Custom filtering for GPRS

1.8.12 pcap detect-loop (0|1)

Command

```
pcap detect-loop (0|1)
```

Parameters

pcap
: PCAP related functions

detect-loop
: detect loop and drop

0
: No detection

1
: Detection

1.8.13 pcap device NAME

Command

```
pcap device NAME
```

Parameters

pcap
: PCAP related functions

device
: the device to filter

NAME
: device name

1.8.14 pcap filter .NAME

Command

```
pcap filter .NAME
```

Parameters

pcap
: PCAP related functions

filter
: filter string in pcap syntax

.NAME
: filter

1.8.15 pcap snaplen <1-262144>

Command

```
pcap snaplen <1-262144>
```

Parameters

pcap
: PCAP related functions

snaplen
: snapshot length

<1-262144>
: Bytes

1.8.16 pcap-store-connection .NAME

Command

```
pcap-store-connection .NAME
```

Parameters

pcap-store-connection
: Configure additional PCAP store server

.NAME
: Name of server

1.8.17 protocol (osmo-pcap|ipip)

Command

```
protocol (osmo-pcap|ipip)
```

Parameters

protocol
: Configure the Protocol used for transfer

osmo-pcap
: OsmoPCAP protocol (over TCP)

ipip
: IPIP encapsulation (for real-time streaming to wireshark)

1.8.18 server ip A.B.C.D

Command

```
server ip A.B.C.D
```

Parameters

server
: Server string

ip
: IP Address of the server

A.B.C.D
: IP

1.8.19 server port <1-65535>

Command

```
server port <1-65535>
```

Parameters

server
: Server string

port
: Port

<1-65535>
: Number

1.8.20 source ip A.B.C.D

Command

```
source ip A.B.C.D
```

Parameters

source
: Server string

ip
: Source IP Address

A.B.C.D
: IP

1.8.21 tls capath .PATH

Command

```
tls capath .PATH
```

Parameters

tls
: Transport Layer Security

capath
: Trusted root certificates

.PATH
: Filename

1.8.22 tls client-cert .PATH

Command

```
tls client-cert .PATH
```

Parameters

tls
: Transport Layer Security

client-cert
: Client certificate for authentication

.PATH
: Filename

1.8.23 tls client-key .PATH

Command

```
tls client-key .PATH
```

Parameters

tls
: Transport Layer Security

client-key
: Client private key

.PATH
: Filename

1.8.24 tls hostname NAME

Command

```
tls hostname NAME
```

Parameters

tls
: Transport Layer Security

hostname
: hostname for certificate validation

NAME
: name

1.8.25 tls log-level <0-255>

Command

```
tls log-level <0-255>
```

Parameters

tls
: Transport Layer Security

log-level
: Log-level

<0-255>
: GNUtls debug level

1.8.26 tls priority STR

Command

```
tls priority STR
```

Parameters

tls
: Transport Layer Security

priority
: Priority string for GNUtls

STR
: Priority string

1.8.27 tls verify-cert

Command

```
tls verify-cert
```

Parameters

tls
: Transport Layer Security

verify-cert
: Verify certificates

1.8.28 wqueue max-length <1-4294967295>

Command

```
wqueue max-length <1-4294967295>
```

Parameters

wqueue
: Configure the write-queue used for transfer

max-length
: Configure the maximum amount of packets to be stored in the write-queue

<1-4294967295>
: Maximum amount of packets before dropping starts

1.9 server

1.9.1 connect

Command

```
connect
```

Parameters

connect
: Connect to the storage

1.9.2 disable tls

Command

```
disable tls
```

Parameters

disable

Disable

tls

Transport Layer Security

1.9.3 disconnect

Command

```
disconnect
```

Parameters

disconnect

Disconnect to the storage

1.9.4 enable tls

Command

```
enable tls
```

Parameters

enable

Enable

tls

Transport Layer Security

1.9.5 no tls capath

Command

```
no tls capath
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

capath
: Trusted root certificates

1.9.6 no tls client-cert

Command

```
no tls client-cert
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

client-cert
: Client certificate for authentication

1.9.7 no tls client-key

Command

```
no tls client-key
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

client-key
: Client private key

1.9.8 no tls hostname

Command

```
no tls hostname
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

hostname
: hostname for certificate validation

1.9.9 no tls priority

Command

```
no tls priority
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

priority
: Priority string for GNUtls

1.9.10 no tls verify-cert

Command

```
no tls verify-cert
```

Parameters

no
: Negate a command or set its defaults

tls
: Transport Layer Security

verify-cert
: Verify certificates

1.9.11 protocol (osmo-pcap|ipip)

Command

```
protocol (osmo-pcap|ipip)
```

Parameters

protocol
: Configure the Protocol used for transfer

osmo-pcap
: OsmoPCAP protocol (over TCP)

ipip
: IPIP encapsulation (for real-time streaming to wireshark)

1.9.12 server ip A.B.C.D

Command

```
server ip A.B.C.D
```

Parameters

server
: Server string

ip
: IP Address of the server

A.B.C.D
: IP

1.9.13 server port <1-65535>

Command

```
server port <1-65535>
```

Parameters

server
: Server string

port
: Port

<1-65535>
: Number

1.9.14 source ip A.B.C.D

Command

```
source ip A.B.C.D
```

Parameters

source
: Server string

ip
: Source IP Address

A.B.C.D
: IP

1.9.15 tls capath .PATH

Command

```
tls capath .PATH
```

Parameters

tls
: Transport Layer Security

capath
: Trusted root certificates

.PATH
: Filename

1.9.16 tls client-cert .PATH

Command

```
tls client-cert .PATH
```

Parameters

tls
: Transport Layer Security

client-cert
: Client certificate for authentication

.PATH
: Filename

1.9.17 tls client-key .PATH

Command

```
tls client-key .PATH
```

Parameters

tls
: Transport Layer Security

client-key
: Client private key

.PATH
: Filename

1.9.18 tls hostname NAME

Command

```
tls hostname NAME
```

Parameters

tls
: Transport Layer Security

hostname
: hostname for certificate validation

NAME
: name

1.9.19 tls log-level <0-255>

Command

```
tls log-level <0-255>
```

Parameters

tls
: Transport Layer Security

log-level
: Log-level

<0-255>
: GNUtls debug level

1.9.20 tls priority STR

Command

```
tls priority STR
```

Parameters

tls
: Transport Layer Security

priority
: Priority string for GNUtls

STR
: Priority string

1.9.21 tls verify-cert

Command

```
tls verify-cert
```

Parameters

tls
: Transport Layer Security

verify-cert
: Verify certificates