

OsmoMSC VTY Reference

Copyright © 2017

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

COLLABORATORS

	<i>TITLE :</i> OsmoMSC VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		May 21, 2018	

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
v1	18th September 2017	Initial	nh

Contents

1	VTY reference	1
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list	2
1.1.5	show running-config	3
1.1.6	write	3
1.1.7	write file	3
1.1.8	write memory	3
1.1.9	write terminal	4
1.2	view	4
1.2.1	echo .MESSAGE	4
1.2.2	enable	4
1.2.3	logging color (01)	5
1.2.4	logging disable	5
1.2.5	logging enable	5
1.2.6	logging filter all (01)	6
1.2.7	logging filter imsi IMSI	6
1.2.8	logging level (all rl cl mml rr mncc pag mssc mgcp holdb reflctrl smppl ranap vrl...)	7
1.2.9	logging print category (01)	9
1.2.10	logging print category-hex (01)	10
1.2.11	logging print extended-timestamp (01)	10
1.2.12	logging print file (01 basename)	11
1.2.13	logging print level (01)	11
1.2.14	logging set log mask MASK	12
1.2.15	logging set-log-mask MASK	12
1.2.16	logging timestamp (01)	12
1.2.17	show alarms	13
1.2.18	show asciidoc counters	13

1.2.19	show connection	13
1.2.20	show cs7 (sualm3ualipa) [<0-65534>]	14
1.2.21	show cs7 instance <0-15> as (activelalllm3ualsua)	14
1.2.22	show cs7 instance <0-15> asp	15
1.2.23	show cs7 instance <0-15> users	15
1.2.24	show fsm NAME	16
1.2.25	show fsm all	16
1.2.26	show fsm-instances NAME	16
1.2.27	show fsm-instances all	17
1.2.28	show history	17
1.2.29	show logging vty	17
1.2.30	show online-help	18
1.2.31	show smpp esme	18
1.2.32	show sms-queue	18
1.2.33	show statistics	19
1.2.34	show stats	19
1.2.35	show stats level (globalpeerlsubscriber)	19
1.2.36	show subscriber (extensionlimsiltmsilid) ID	20
1.2.37	show subscriber cache	20
1.2.38	show talloc-context (applicationlall) (fullbrieflDEPTH)	21
1.2.39	show talloc-context (applicationlall) (fullbrieflDEPTH) filter REGEXP	21
1.2.40	show talloc-context (applicationlall) (fullbrieflDEPTH) tree ADDRESS	22
1.2.41	show transaction	22
1.2.42	show version	23
1.2.43	sms delete expired	23
1.2.44	sms send pending	23
1.2.45	subscriber (extensionlimsiltmsilid) ID ms-test close-loop (alblcldeflfi)	24
1.2.46	subscriber (extensionlimsiltmsilid) ID ms-test open-loop	25
1.2.47	subscriber (extensionlimsiltmsilid) ID silent-call start (anyltch/fltch/anylsdcc...	25
1.2.48	subscriber (extensionlimsiltmsilid) ID silent-call stop	26
1.2.49	subscriber (extensionlimsiltmsilid) ID silent-sms sender (extensionlimsiltmsilid...	27
1.2.50	subscriber (extensionlimsiltmsilid) ID sms sender (extensionlimsiltmsilid) SENDE...	28
1.2.51	subscriber (extensionlimsiltmsilid) ID update	29
1.2.52	subscriber (extensionlimsiltmsilid) ID ussd-notify (0l1l2) .TEXT	29
1.2.53	subscriber create imsi ID	30
1.2.54	terminal length <0-512>	30
1.2.55	terminal no length	31
1.2.56	who	31
1.3	enable	31

1.3.1	configure terminal	31
1.3.2	copy running-config startup-config	32
1.3.3	disable	32
1.3.4	echo .MESSAGE	32
1.3.5	logging color (0 1)	33
1.3.6	logging disable	33
1.3.7	logging enable	33
1.3.8	logging filter all (0 1)	34
1.3.9	logging filter imsi IMSI	34
1.3.10	logging level (all rl lcl mml rr mnccl pag mssc mgcpl holdb reflect rl smpp ranapl v rl...	35
1.3.11	logging print category (0 1)	37
1.3.12	logging print category-hex (0 1)	38
1.3.13	logging print extended-timestamp (0 1)	38
1.3.14	logging print file (0 1 basename)	39
1.3.15	logging print level (0 1)	39
1.3.16	logging set log mask MASK	40
1.3.17	logging set-log-mask MASK	40
1.3.18	logging timestamp (0 1)	40
1.3.19	show alarms	41
1.3.20	show asciidoc counters	41
1.3.21	show connection	41
1.3.22	show cs7 (sualm3ualipa) [<0-65534>]	42
1.3.23	show cs7 instance <0-15> as (active all m3ualsua)	42
1.3.24	show cs7 instance <0-15> asp	43
1.3.25	show cs7 instance <0-15> users	43
1.3.26	show fsm NAME	44
1.3.27	show fsm all	44
1.3.28	show fsm-instances NAME	44
1.3.29	show fsm-instances all	45
1.3.30	show history	45
1.3.31	show logging vty	45
1.3.32	show online-help	46
1.3.33	show smpp esme	46
1.3.34	show sms-queue	46
1.3.35	show startup-config	47
1.3.36	show statistics	47
1.3.37	show stats	47
1.3.38	show stats level (global peer subscriber)	48
1.3.39	show subscriber (extension ims tms id) ID	48

1.3.40	show subscriber cache	49
1.3.41	show talloc-context (applicationall) (fullbrief DEPTH)	49
1.3.42	show talloc-context (applicationall) (fullbrief DEPTH) filter REGEXP	50
1.3.43	show talloc-context (applicationall) (fullbrief DEPTH) tree ADDRESS	50
1.3.44	show transaction	51
1.3.45	show version	51
1.3.46	sms delete expired	52
1.3.47	sms send pending	52
1.3.48	sms-queue clear	52
1.3.49	sms-queue max-failure <1-500>	53
1.3.50	sms-queue max-pending <1-500>	53
1.3.51	sms-queue trigger	53
1.3.52	subscriber (extensionlimsiltmsilid) ID a3a8 (nonelxorlcomp128v1) [KI]	54
1.3.53	subscriber (extensionlimsiltmsilid) ID expire	54
1.3.54	subscriber (extensionlimsiltmsilid) ID ms-test close-loop (ablcldlelfi)	55
1.3.55	subscriber (extensionlimsiltmsilid) ID ms-test open-loop	56
1.3.56	subscriber (extensionlimsiltmsilid) ID silent-call start (anyltch/fltch/anylsdcc...	56
1.3.57	subscriber (extensionlimsiltmsilid) ID silent-call stop	57
1.3.58	subscriber (extensionlimsiltmsilid) ID silent-sms sender (extensionlimsiltmsilid...	58
1.3.59	subscriber (extensionlimsiltmsilid) ID sms pending-send	59
1.3.60	subscriber (extensionlimsiltmsilid) ID sms sender (extensionlimsiltmsilid) SENDE...	59
1.3.61	subscriber (extensionlimsiltmsilid) ID update	60
1.3.62	subscriber (extensionlimsiltmsilid) ID ussd-notify (0 1 2) .TEXT	61
1.3.63	subscriber create imsi ID	62
1.3.64	terminal length <0-512>	62
1.3.65	terminal monitor	62
1.3.66	terminal no length	63
1.3.67	terminal no monitor	63
1.3.68	who	63
1.4	config	63
1.4.1	banner motd default	64
1.4.2	banner motd file [FILE]	64
1.4.3	cs7 instance <0-15>	64
1.4.4	ctrl	65
1.4.5	enable password (8) WORD	65
1.4.6	enable password LINE	65
1.4.7	hlr	66
1.4.8	hostname WORD	66
1.4.9	line vty	66

1.4.10	log alarms <2-32700>	66
1.4.11	log file .FILENAME	67
1.4.12	log gsmzap [HOSTNAME]	67
1.4.13	log stderr	67
1.4.14	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	68
1.4.15	log syslog local <0-7>	68
1.4.16	mncc-int	69
1.4.17	msc	69
1.4.18	network	69
1.4.19	no banner motd	69
1.4.20	no enable password	70
1.4.21	no hostname [HOSTNAME]	70
1.4.22	no log alarms	70
1.4.23	no log file .FILENAME	71
1.4.24	no log stderr	71
1.4.25	no log syslog	71
1.4.26	no service advanced-vty	72
1.4.27	no service terminal-length [<0-512>]	72
1.4.28	no stats reporter log	72
1.4.29	no stats reporter statsd	73
1.4.30	password (8) WORD	73
1.4.31	password LINE	73
1.4.32	service advanced-vty	74
1.4.33	service terminal-length <0-512>	74
1.4.34	show history	74
1.4.35	smpp	75
1.4.36	stats interval <1-65535>	75
1.4.37	stats reporter log	75
1.4.38	stats reporter statsd	76
1.5	config-log	76
1.5.1	logging color (01)	76
1.5.2	logging filter all (01)	77
1.5.3	logging filter imsi IMSI	77
1.5.4	logging level (all rl lcl mml rr mncc pag msc mgcp holdb reflctr l smpp ranap vrl ...	78
1.5.5	logging print category (01)	80
1.5.6	logging print category-hex (01)	81
1.5.7	logging print extended-timestamp (01)	81
1.5.8	logging print file (01 basename)	82
1.5.9	logging print level (01)	82

1.5.10	logging timestamp (01)	83
1.6	config-stats	83
1.6.1	disable	83
1.6.2	enable	83
1.6.3	level (globalpeersubscriber)	84
1.6.4	local-ip ADDR	84
1.6.5	mtu <100-65535>	84
1.6.6	no local-ip	85
1.6.7	no mtu	85
1.6.8	no prefix	85
1.6.9	prefix PREFIX	85
1.6.10	remote-ip ADDR	86
1.6.11	remote-port <1-65535>	86
1.7	config-line	86
1.7.1	bind A.B.C.D	86
1.7.2	login	87
1.7.3	no login	87
1.8	config-ctrl	87
1.8.1	bind A.B.C.D	87
1.9	config-cs7	88
1.9.1	as NAME (sualm3ualipa)	88
1.9.2	asp NAME <0-65535> <0-65535> (sualm3ualipa)	88
1.9.3	description .TEXT	89
1.9.4	network-indicator (international national reserved spare)	89
1.9.5	no as NAME	89
1.9.6	no asp NAME	90
1.9.7	no sccp-address NAME	90
1.9.8	point-code POINT_CODE	90
1.9.9	point-code delimiter (defaultldash)	91
1.9.10	point-code format <1-24> [<1-23>] [<1-22>]	91
1.9.11	point-code format default	91
1.9.12	sccp-address NAME	92
1.9.13	show cs7 instance <0-15> sccp-addressbook	92
1.9.14	xua rkm routing-key-allocation (static-only dynamic-permitted)	93
1.10	config-cs7-as	93
1.10.1	asp NAME	93
1.10.2	description .TEXT	93
1.10.3	no asp NAME	94
1.10.4	point-code override dpc PC	94

1.10.5	qos-class <0-255>	94
1.10.6	recovery-timeout <1-2000>	95
1.10.7	routing-key RCONTEXT DPC	95
1.10.8	routing-key RCONTEXT DPC si (aal2lbicclb-isuplh248lisuplsat-isuplsceptup)	95
1.10.9	routing-key RCONTEXT DPC si (aal2lbicclb-isuplh248lisuplsat-isuplsceptup) ssn S...	96
1.10.10	routing-key RCONTEXT DPC ssn SSN	97
1.10.11	traffic-mode (broadcast loadshare roundrobin override)	97
1.11	config-cs7-asp	98
1.11.1	block	98
1.11.2	description .TEXT	98
1.11.3	local-ip A.B.C.D	98
1.11.4	qos-class <0-255>	99
1.11.5	remote-ip A.B.C.D	99
1.11.6	shutdown	99
1.12	config-cs7-sccpaddr	99
1.12.1	global-title	99
1.12.2	no global-title	100
1.12.3	no point-code	100
1.12.4	no subsystem-number	100
1.12.5	point-code POINT_CODE	100
1.12.6	routing-indicator (GTIPCIIP)	101
1.12.7	subsystem-number <0-4294967295>	101
1.13	config-cs7-sccpaddr-gt	101
1.13.1	digits DIGITS	101
1.13.2	global-title-indicator <0-15>	102
1.13.3	nature-of-address-indicator <0-127>	102
1.13.4	numbering-plan-indicator <0-15>	102
1.13.5	translation-type <0-255>	102
1.14	config-net	103
1.14.1	authentication (optional required)	103
1.14.2	encryption a5 <0-3> [<0-3>] [<0-3>] [<0-3>]	103
1.14.3	long name NAME	104
1.14.4	mm info (011)	104
1.14.5	mobile network code <0-999>	104
1.14.6	network country code <1-999>	105
1.14.7	no periodic location update	105
1.14.8	no timezone	105
1.14.9	periodic location update <6-1530>	106
1.14.10	rrlp mode (nonelms-based lms-preferred lass-preferred)	106

1.14.11 short name NAME	107
1.14.12 timezone <-19-19> (0115130145)	107
1.14.13 timezone <-19-19> (0115130145) <0-2>	107
1.15 config-msc	108
1.15.1 asn1 debug (110)	108
1.15.2 asn1 xer-print (110)	108
1.15.3 assign-tmsi	109
1.15.4 auth-tuple-max-reuse-count <-1-2147483647>	109
1.15.5 auth-tuple-reuse-on-error (011)	109
1.15.6 cs7-instance-a <0-15>	110
1.15.7 cs7-instance-iu <0-15>	110
1.15.8 emergency-call route-to-msisdn MSISDN	110
1.15.9 iu rab-assign-addr-enc (x213lv4raw)	111
1.15.10 mgcpwgw bts-base <0-65534>	111
1.15.11 mgcpwgw endpoint-range <1-65534> <1-65534>	111
1.15.12 mgcpwgw local-ip A.B.C.D	112
1.15.13 mgcpwgw local-port <0-65535>	112
1.15.14 mgcpwgw remote-ip A.B.C.D	112
1.15.15 mgcpwgw remote-port <0-65535>	113
1.15.16 mgw bts-base <0-65534>	113
1.15.17 mgw endpoint-range <1-65534> <1-65534>	113
1.15.18 mgw local-ip A.B.C.D	114
1.15.19 mgw local-port <0-65535>	114
1.15.20 mgw remote-ip A.B.C.D	114
1.15.21 mgw remote-port <0-65535>	115
1.15.22 no assign-tmsi	115
1.15.23 paging response-timer (default<1-65535>)	115
1.16 config-mncc-int	116
1.16.1 default-codec tch-f (frleflamr)	116
1.16.2 default-codec tch-h (hrlamr)	116
1.17 config-smpp	116
1.17.1 esme NAME	117
1.17.2 local-tcp-ip A.B.C.D <1-65535>	117
1.17.3 local-tcp-port <1-65535>	117
1.17.4 no esme NAME	118
1.17.5 no smpp-first	118
1.17.6 policy (accept-allclosed)	118
1.17.7 smpp-first	119
1.17.8 system-id ID	119

1.18	config-smpp-esme	119
1.18.1	dcs-transparent	119
1.18.2	default-route	119
1.18.3	deliver-src-imsi	120
1.18.4	no dcs-transparent	120
1.18.5	no default-route	120
1.18.6	no deliver-src-imsi	120
1.18.7	no osmocom-extensions	121
1.18.8	no password	121
1.18.9	no route prefix (unknown international national network subscriber alpha abbrev)...	121
1.18.10	osmocom-extensions	122
1.18.11	password PASSWORD	123
1.18.12	route prefix (unknown international national network subscriber alpha abbrev) (u...	123
1.19	config-hlr	124
1.19.1	remote-ip A.B.C.D	124
1.19.2	remote-port <1-65535>	125

List of Tables

1.1	VTY Parameter Patterns	1
1.2	VTY port numbers	1

Chapter 1

VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sismocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

1.1.1 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

1.1.2 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

1.1.3 help

Command

```
help
```

Parameters

help

Description of the interactive help system

1.1.4 list

Command

```
list
```

Parameters

list

Print command list

1.1.5 show running-config

Command

```
show running-config
```

Parameters

show

Show running system information

running-config

running configuration

1.1.6 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

1.1.7 write file

Command

```
write file
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

1.1.8 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

1.1.9 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

1.2.1 echo .MESSAGE

Command

```
echo .MESSAGE
```

Parameters

echo

Echo a message back to the vty

.MESSAGE

The message to echo

1.2.2 enable

Command

```
enable
```

Parameters

enable

Turn on privileged mode command

1.2.3 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

1.2.4 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

1.2.5 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

1.2.6 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

1.2.7 logging filter imsi IMSI

Command

```
logging filter imsi IMSI
```

Parameters

logging

Configure logging

filter

Filter log messages

imsi

Filter log messages by IMSI

IMSI

IMSI to be used as filter

1.2.8 logging level (all|rll|cc|mm|rr|mncc|pag|msc|mgcp|ho|db|ref|ctrl|smpp|ranap|vlr|...)

Command

```
logging level (all|rll|cc|mm|rr|mncc|pag|msc|mgcp|ho|db|ref|ctrl|smpp|ranap|vlr|iucs| ↔  
bssap|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp ↔  
|lsua|lm3ua|lmgcp|ljibuf) (everything|debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

all

Global setting for all subsystems

rll

A-bis Radio Link Layer (RLL)

cc

Layer3 Call Control (CC)

mm

Layer3 Mobility Management (MM)

rr

Layer3 Radio Resource (RR)

mncc

MNCC API for Call Control application

pag

Paging Subsystem

msc

Mobile Switching Center

mgcp

Media Gateway Control Protocol

ho

Hand-Over

db

Database Layer

ref

Reference Counting

ctrl

Control interface

smpp
SMPP interface for external SMS apps

ranap
Radio Access Network Application Part Protocol

vlr
Visitor Location Register

iucs
Iu-CS Protocol

bssap
BSSAP Protocol (A Interface)

lglobal
Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lscpp
libosmo-sigtran SCCP Implementation

lsua	libosmo-sigtran SCCP User Adaptation
lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol
ljibuf	libosmo-netif Jitter Buffer
everything	Don't use. It doesn't log anything
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

1.2.9 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

1.2.10 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

1.2.11 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnn

1.2.12 logging print file (0|1|basename)

Command

```
logging print file (0|1|basename)
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

1.2.13 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

1.2.14 logging set log mask MASK

Command

```
logging set log mask MASK
```

Parameters

logging

Configure logging

set

Decide which categories to output.

log

Log commands

mask

Mask commands

MASK

'set log mask' is deprecated, please refer to the docs of 'set-log-mask' instead

1.2.15 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

1.2.16 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

1.2.17 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

1.2.18 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

1.2.19 show connection

Command

```
show connection
```

Parameters

show

Show running system information

connection

Subscriber Connections

1.2.20 show cs7 (sua|m3ua|ipa) [<0-65534>]

Command

```
show cs7 (sua|m3ua|ipa) [<0-65534>]
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

[<0-65534>]

Port Number

1.2.21 show cs7 instance <0-15> as (active|all|m3ua|sua)

Command

```
show cs7 instance <0-15> as (active|all|m3ua|sua)
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

as

Application Server (AS)

active

Display all active ASs

all

Display all ASs (default)

m3ua

Display all m3ua ASs

sua

Display all SUA ASs

1.2.22 show cs7 instance <0-15> asp

Command

```
show cs7 instance <0-15> asp
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

asp

Application Server Process (ASP)

1.2.23 show cs7 instance <0-15> users

Command

```
show cs7 instance <0-15> users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

users

User Table

1.2.24 show fsm NAME

Command

```
show fsm NAME
```

Parameters

show

Show running system information

fsm

Show information about finite state machines

NAME

Display information about a single named finite state machine

1.2.25 show fsm all

Command

```
show fsm all
```

Parameters

show

Show running system information

fsm

Show information about finite state machines

all

Display a list of all registered finite state machines

1.2.26 show fsm-instances NAME

Command

```
show fsm-instances NAME
```

Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

NAME

Display a list of all FSM instances of the named finite state machine

1.2.27 show fsm-instances all

Command

```
show fsm-instances all
```

Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

all

Display a list of all FSM instances of all finite state machine

1.2.28 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

1.2.29 show logging vty

Command

```
show logging vty
```

Parameters

show

Show running system information

logging

Show current logging configuration

vty

Show current logging configuration for this vty

1.2.30 show online-help

Command

```
show online-help
```

Parameters

show

Show running system information

online-help

Online help

1.2.31 show smpp esme

Command

```
show smpp esme
```

Parameters

show

Show running system information

smpp

SMPP Interface

esme

SMPP Extrenal SMS Entity

1.2.32 show sms-queue

Command

```
show sms-queue
```

Parameters

show

Show running system information

sms-queue

Display SMSqueue statistics

1.2.33 show statistics

Command

```
show statistics
```

Parameters

show

Show running system information

statistics

Display network statistics

1.2.34 show stats

Command

```
show stats
```

Parameters

show

Show running system information

stats

Show statistical values

1.2.35 show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

1.2.36 show subscriber (extension|imsi|tmsi|id) ID

Command

```
show subscriber (extension|imsi|tmsi|id) ID
```

Parameters

show

Show running system information

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

1.2.37 show subscriber cache

Command

```
show subscriber cache
```

Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

1.2.38 show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

1.2.39 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

1.2.40 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS**Command**

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters**show**

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

1.2.41 show transaction**Command**

```
show transaction
```

Parameters**show**

Show running system information

transaction

Transactions

1.2.42 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

1.2.43 sms delete expired

Command

```
sms delete expired
```

Parameters

sms

SMS related commands

delete

SMS Database related commands

expired

Delete all expired SMS

1.2.44 sms send pending

Command

```
sms send pending
```

Parameters

sms

SMS related commands

send

SMS Sending related commands

pending

Send all pending SMS

1.2.45 subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)

Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ms-test

Send a TS 04.14 MS Test Command to subscriber

close-loop

Close a TCH Loop inside the MS

a

Loop Type A

b

Loop Type B

c

Loop Type C

d

Loop Type D

e

Loop Type E

f

Loop Type F

i

Loop Type I

1.2.46 subscriber (extension|imsi|tmsi|id) ID ms-test open-loop

Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test open-loop
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ms-test

Send a TS 04.14 MS Test Command to subscriber

open-loop

Open a TCH Loop inside the MS

1.2.47 subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-call

Silent call operation

start

Start silent call

any

Any channel

tch/f

TCH/F channel

tch/any

Any TCH channel

sdccch

SDCCCH channel

1.2.48 subscriber (extension|imsi|tmsi|id) ID silent-call stop

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-call stop
```

Parameters**subscriber**

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-call

Silent call operation

stop

Stop silent call

1.2.49 subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id...

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id) ←  
SENDER_ID send .LINE
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-sms

Silent SMS Operations

sender

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

SENDER_ID

Identifier for the subscriber

send

Send SMS

.LINE

Actual SMS Text

1.2.50 subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDE...

Command

```
subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDER_ID ↔  
send .LINE
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

sms

SMS Operations

sender

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

SENDER_ID

Identifier for the subscriber

send

Send SMS

.LINE

Actual SMS Text

1.2.51 subscriber (extension|imsi|tmsi|id) ID update

Command

```
subscriber (extension|imsi|tmsi|id) ID update
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

update

Update the subscriber data from the dabase.

1.2.52 subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT

Command

```
subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ussd-notify

Send a USSD notify to the subscriber

0

Alerting Level 0

1

Alerting Level 1

2

Alerting Level 2

.TEXT

Text of USSD message to send

1.2.53 subscriber create imsi ID

Command

```
subscriber create imsi ID
```

Parameters

subscriber

Operations on a Subscriber

create

Create new subscriber

imsi

Identify the subscriber by his IMSI

ID

Identifier for the subscriber

1.2.54 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

1.2.55 terminal no length

Command

```
terminal no length
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

length

Set number of lines on a screen

1.2.56 who

Command

```
who
```

Parameters

who

Display who is on vty

1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

1.3.1 configure terminal

Command

```
configure terminal
```

Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

1.3.2 copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)

1.3.3 disable

Command

```
disable
```

Parameters

disable

Turn off privileged mode command

1.3.4 echo .MESSAGE

Command

```
echo .MESSAGE
```

Parameters

echo

Echo a message back to the vty

.MESSAGE

The message to echo

1.3.5 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

1.3.6 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

1.3.7 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

1.3.8 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

1.3.9 logging filter imsi IMSI

Command

```
logging filter imsi IMSI
```

Parameters

logging

Configure logging

filter

Filter log messages

imsi

Filter log messages by IMSI

IMSI

IMSI to be used as filter

1.3.10 logging level (all|rll|cc|mm|rr|mncc|pag|msc|mgcp|ho|db|ref|ctrl|smpp|ranap|vlr|...

Command

```
logging level (all|rll|cc|mm|rr|mncc|pag|msc|mgcp|ho|db|ref|ctrl|smpp|ranap|vlr|iucs| ↔  
bssap|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp ↔  
|lsua|lm3ua|lmgcp|ljibuf) (everything|debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

all

Global setting for all subsystems

rll

A-bis Radio Link Layer (RLL)

cc

Layer3 Call Control (CC)

mm

Layer3 Mobility Management (MM)

rr

Layer3 Radio Resource (RR)

mncc

MNCC API for Call Control application

pag

Paging Subsystem

msc

Mobile Switching Center

mgcp

Media Gateway Control Protocol

ho

Hand-Over

db

Database Layer

ref

Reference Counting

ctrl

Control interface

smpp
SMPP interface for external SMS apps

ranap
Radio Access Network Application Part Protocol

vlr
Visitor Location Register

iucs
Iu-CS Protocol

bssap
BSSAP Protocol (A Interface)

lglobal
Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lscpp
libosmo-sigtran SCCP Implementation

lsua	libosmo-sigtran SCCP User Adaptation
lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol
ljibuf	libosmo-netif Jitter Buffer
everything	Don't use. It doesn't log anything
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

1.3.11 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

1.3.12 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

1.3.13 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnn

1.3.14 logging print file (0|1|basename)

Command

```
logging print file (0|1|basename)
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

1.3.15 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

1.3.16 logging set log mask MASK

Command

```
logging set log mask MASK
```

Parameters

logging

Configure logging

set

Decide which categories to output.

log

Log commands

mask

Mask commands

MASK

'set log mask' is deprecated, please refer to the docs of 'set-log-mask' instead

1.3.17 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

1.3.18 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

1.3.19 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

1.3.20 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

1.3.21 show connection

Command

```
show connection
```

Parameters

show

Show running system information

connection

Subscriber Connections

1.3.22 show cs7 (sua|m3ua|ipa) [<0-65534>]

Command

```
show cs7 (sua|m3ua|ipa) [<0-65534>]
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

[<0-65534>]

Port Number

1.3.23 show cs7 instance <0-15> as (active|all|m3ua|sua)

Command

```
show cs7 instance <0-15> as (active|all|m3ua|sua)
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

as

Application Server (AS)

active

Display all active ASs

all

Display all ASs (default)

m3ua

Display all m3ua ASs

sua

Display all SUA ASs

1.3.24 show cs7 instance <0-15> asp

Command

```
show cs7 instance <0-15> asp
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

asp

Application Server Process (ASP)

1.3.25 show cs7 instance <0-15> users

Command

```
show cs7 instance <0-15> users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

users

User Table

1.3.26 show fsm NAME

Command

```
show fsm NAME
```

Parameters

show

Show running system information

fsm

Show information about finite state machines

NAME

Display information about a single named finite state machine

1.3.27 show fsm all

Command

```
show fsm all
```

Parameters

show

Show running system information

fsm

Show information about finite state machines

all

Display a list of all registered finite state machines

1.3.28 show fsm-instances NAME

Command

```
show fsm-instances NAME
```

Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

NAME

Display a list of all FSM instances of the named finite state machine

1.3.29 show fsm-instances all

Command

```
show fsm-instances all
```

Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

all

Display a list of all FSM instances of all finite state machine

1.3.30 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

1.3.31 show logging vty

Command

```
show logging vty
```

Parameters

show

Show running system information

logging

Show current logging configuration

vty

Show current logging configuration for this vty

1.3.32 show online-help

Command

```
show online-help
```

Parameters

show

Show running system information

online-help

Online help

1.3.33 show smpp esme

Command

```
show smpp esme
```

Parameters

show

Show running system information

smpp

SMPP Interface

esme

SMPP Extrenal SMS Entity

1.3.34 show sms-queue

Command

```
show sms-queue
```

Parameters

show

Show running system information

sms-queue

Display SMSqueue statistics

1.3.35 show startup-config

Command

```
show startup-config
```

Parameters

show

Show running system information

startup-config

Contentes of startup configuration

1.3.36 show statistics

Command

```
show statistics
```

Parameters

show

Show running system information

statistics

Display network statistics

1.3.37 show stats

Command

```
show stats
```

Parameters

show

Show running system information

stats

Show statistical values

1.3.38 show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

1.3.39 show subscriber (extension|imsi|tmsi|id) ID

Command

```
show subscriber (extension|imsi|tmsi|id) ID
```

Parameters

show

Show running system information

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

1.3.40 show subscriber cache

Command

```
show subscriber cache
```

Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

1.3.41 show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

1.3.42 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

1.3.43 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

1.3.44 show transaction

Command

```
show transaction
```

Parameters

show

Show running system information

transaction

Transactions

1.3.45 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

1.3.46 sms delete expired

Command

```
sms delete expired
```

Parameters

sms

SMS related commands

delete

SMS Database related commands

expired

Delete all expired SMS

1.3.47 sms send pending

Command

```
sms send pending
```

Parameters

sms

SMS related commands

send

SMS Sending related commands

pending

Send all pending SMS

1.3.48 sms-queue clear

Command

```
sms-queue clear
```

Parameters

sms-queue

SMS Queue

clear

Clear the queue of pending SMS

1.3.49 sms-queue max-failure <1-500>

Command

```
sms-queue max-failure <1-500>
```

Parameters

sms-queue

SMS Queue

max-failure

Maximum amount of delivery failures

<1-500>

Amount

1.3.50 sms-queue max-pending <1-500>

Command

```
sms-queue max-pending <1-500>
```

Parameters

sms-queue

SMS Queue

max-pending

SMS to deliver in parallel

<1-500>

Amount

1.3.51 sms-queue trigger

Command

```
sms-queue trigger
```

Parameters

sms-queue

SMS Queue

trigger

Trigger sending messages

1.3.52 subscriber (extension|imsi|tmsi|id) ID a3a8 (none|xor|comp128v1) [KI]

Command

```
subscriber (extension|imsi|tmsi|id) ID a3a8 (none|xor|comp128v1) [KI]
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

a3a8

Set a3a8 parameters for the subscriber

none

Use No A3A8 algorithm

xor

Use XOR algorithm

comp128v1

Use COMP128v1 algorithm

[KI]

Encryption Key Ki

1.3.53 subscriber (extension|imsi|tmsi|id) ID expire

Command

```
subscriber (extension|imsi|tmsi|id) ID expire
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

expire

Expire the subscriber Now

1.3.54 subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)

Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ms-test

Send a TS 04.14 MS Test Command to subscriber

close-loop

Close a TCH Loop inside the MS

a

Loop Type A

b

Loop Type B

c

Loop Type C

- d
Loop Type D
- e
Loop Type E
- f
Loop Type F
- i
Loop Type I

1.3.55 subscriber (extension|imsi|tmsi|id) ID ms-test open-loop

Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test open-loop
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ms-test

Send a TS 04.14 MS Test Command to subscriber

open-loop

Open a TCH Loop inside the MS

1.3.56 subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-call

Silent call operation

start

Start silent call

any

Any channel

tch/f

TCH/F channel

tch/any

Any TCH channel

sdccch

SDCCH channel

1.3.57 subscriber (extension|imsi|tmsi|id) ID silent-call stop**Command**

```
subscriber (extension|imsi|tmsi|id) ID silent-call stop
```

Parameters**subscriber**

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id
Identify subscriber by database ID

ID
Identifier for the subscriber

silent-call
Silent call operation

stop
Stop silent call

1.3.58 subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id...

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id) ←  
SENDER_ID send .LINE
```

Parameters

subscriber
Operations on a Subscriber

extension
Identify subscriber by extension (phone number)

imsi
Identify subscriber by IMSI

tmsi
Identify subscriber by TMSI

id
Identify subscriber by database ID

ID
Identifier for the subscriber

silent-sms
Silent SMS Operations

sender
Operations on a Subscriber

extension
Identify subscriber by extension (phone number)

imsi
Identify subscriber by IMSI

tmsi
Identify subscriber by TMSI

id
Identify subscriber by database ID

SENDER_ID
Identifier for the subscriber

send
Send SMS

.LINE
Actual SMS Text

1.3.59 subscriber (extension|imsi|tmsi|id) ID sms pending-send

Command

```
subscriber (extension|imsi|tmsi|id) ID sms pending-send
```

Parameters

subscriber
Operations on a Subscriber

extension
Identify subscriber by extension (phone number)

imsi
Identify subscriber by IMSI

tmsi
Identify subscriber by TMSI

id
Identify subscriber by database ID

ID
Identifier for the subscriber

sms
SMS Operations

pending-send
Send pending SMS

1.3.60 subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDE...

Command

```
subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDER_ID ↔  
send .LINE
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

sms

SMS Operations

sender

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

SENDER_ID

Identifier for the subscriber

send

Send SMS

.LINE

Actual SMS Text

1.3.61 subscriber (extension|imsi|tmsi|id) ID update

Command

```
subscriber (extension|imsi|tmsi|id) ID update
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

update

Update the subscriber data from the dabase.

1.3.62 subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT

Command

```
subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT
```

Parameters**subscriber**

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ussd-notify

Send a USSD notify to the subscriber

0

Alerting Level 0

1

Alerting Level 1

2

Alerting Level 2

.TEXT

Text of USSD message to send

1.3.63 subscriber create imsi ID

Command

```
subscriber create imsi ID
```

Parameters

subscriber

Operations on a Subscriber

create

Create new subscriber

imsi

Identify the subscriber by his IMSI

ID

Identifier for the subscriber

1.3.64 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

1.3.65 terminal monitor

Command

```
terminal monitor
```

Parameters

terminal

Set terminal line parameters

monitor

Copy debug output to the current terminal line

1.3.66 terminal no length

Command

```
terminal no length
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

length

Set number of lines on a screen

1.3.67 terminal no monitor

Command

```
terminal no monitor
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

monitor

Copy debug output to the current terminal line

1.3.68 who

Command

```
who
```

Parameters

who

Display who is on vty

1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

1.4.1 banner motd default

Command

```
banner motd default
```

Parameters

banner

Set banner string

motd

Strings for motd

default

Default string

1.4.2 banner motd file [FILE]

Command

```
banner motd file [FILE]
```

Parameters

banner

Set banner

motd

Banner for motd

file

Banner from a file

[FILE]

Filename

1.4.3 cs7 instance <0-15>

Command

```
cs7 instance <0-15>
```

Parameters

cs7

ITU-T Signaling System 7

instance

Configure a SS7 Instance

<0-15>

An instance of the SS7 stack

1.4.4 ctrl

Command

```
ctrl
```

Parameters

ctrl

Configure the Control Interface

1.4.5 enable password (8|) WORD

Command

```
enable password (8|) WORD
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN 'enable' password string

1.4.6 enable password LINE

Command

```
enable password LINE
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

LINE

The UNENCRYPTED (cleartext) 'enable' password

1.4.7 hlr

Command

```
hlr
```

Parameters

hlr

Configure connection to the HLR

1.4.8 hostname WORD

Command

```
hostname WORD
```

Parameters

hostname

Set system's network name

WORD

This system's network name

1.4.9 line vty

Command

```
line vty
```

Parameters

line

Configure a terminal line

vtv

Virtual terminal

1.4.10 log alarms <2-32700>

Command

```
log alarms <2-32700>
```

Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo_strrb

<2-32700>

Maximum number of messages to log

1.4.11 log file .FILENAME

Command

```
log file .FILENAME
```

Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

1.4.12 log gsmtap [HOSTNAME]

Command

```
log gsmtap [HOSTNAME]
```

Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

1.4.13 log stderr

Command

```
log stderr
```

Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

1.4.14 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

1.4.15 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

1.4.16 mncc-int

Command

```
mncc-int
```

Parameters

mncc-int

Configure internal MNCC handler

1.4.17 msc

Command

```
msc
```

Parameters

msc

Configure MSC options

1.4.18 network

Command

```
network
```

Parameters

network

Configure the GSM network

1.4.19 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

1.4.20 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

1.4.21 no hostname [HOSTNAME]

Command

```
no hostname [HOSTNAME]
```

Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

1.4.22 no log alarms

Command

```
no log alarms
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo_strrb

1.4.23 no log file .FILENAME

Command

```
no log file .FILENAME
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

1.4.24 no log stderr

Command

```
no log stderr
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

1.4.25 no log syslog

Command

```
no log syslog
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

1.4.26 no service advanced-vty

Command

```
no service advanced-vty
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

1.4.27 no service terminal-length [<0-512>]

Command

```
no service terminal-length [<0-512>]
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

1.4.28 no stats reporter log

Command

```
no stats reporter log
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

1.4.29 no stats reporter statsd

Command

```
no stats reporter statsd
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

1.4.30 password (8|) WORD

Command

```
password (8|) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

1.4.31 password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

1.4.32 service advanced-vty

Command

```
service advanced-vty
```

Parameters

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

1.4.33 service terminal-length <0-512>

Command

```
service terminal-length <0-512>
```

Parameters

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

<0-512>

Number of lines of VTY (0 means no line control)

1.4.34 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

1.4.35 smpp

Command

```
smpp
```

Parameters

smpp

Configure SMPP SMS Interface

1.4.36 stats interval <1-65535>

Command

```
stats interval <1-65535>
```

Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<1-65535>

Interval in seconds

1.4.37 stats reporter log

Command

```
stats reporter log
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

1.4.38 stats reporter statsd

Command

```
stats reporter statsd
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

1.5.1 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

1.5.3 logging filter imsi IMSI

Command

```
logging filter imsi IMSI
```

Parameters

logging

Configure logging

filter

Filter log messages

imsi

Filter log messages by IMSI

IMSI

IMSI to be used as filter

1.5.4 logging level (all|rll|cc|mm|rr|mncc|pag|msc|mgcp|ho|db|ref|ctrl|smpp|ranap|vlr|...)

Command

```
logging level (all|rll|cc|mm|rr|mncc|pag|msc|mgcp|ho|db|ref|ctrl|smpp|ranap|vlr|iucs| ↔  
bssap|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp ↔  
|lsua|lm3ua|lmgcp|ljibuf) (everything|debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

all

Global setting for all subsystems

rll

A-bis Radio Link Layer (RLL)

cc

Layer3 Call Control (CC)

mm

Layer3 Mobility Management (MM)

rr

Layer3 Radio Resource (RR)

mncc

MNCC API for Call Control application

pag

Paging Subsystem

msc

Mobile Switching Center

mgcp

Media Gateway Control Protocol

ho

Hand-Over

db

Database Layer

ref

Reference Counting

ctrl

Control interface

smpp
SMPP interface for external SMS apps

ranap
Radio Access Network Application Part Protocol

vlr
Visitor Location Register

iucs
Iu-CS Protocol

bssap
BSSAP Protocol (A Interface)

lglobal
Library-internal global log family

llapd
LAPD in libosmogsm

linp
A-bis Input Subsystem

lmux
A-bis B-Subchannel TRAU Frame Multiplex

lmi
A-bis Input Driver for Signalling

lmib
A-bis Input Driver for B-Channels (voice)

lsms
Layer3 Short Message Service (SMS)

lctrl
Control Interface

lgtp
GPRS GTP library

lstats
Statistics messages and logging

lgsup
Generic Subscriber Update Protocol

loap
Osmocom Authentication Protocol

lss7
libosmo-sigtran Signalling System 7

lscpp
libosmo-sigtran SCCP Implementation

lsua	libosmo-sigtran SCCP User Adaptation
lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol
ljibuf	libosmo-netif Jitter Buffer
everything	Don't use. It doesn't log anything
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

1.5.5 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

1.5.6 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

1.5.7 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnn

1.5.8 logging print file (0|1|basename)

Command

```
logging print file (0|1|basename)
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

1.5.9 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

1.5.10 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

1.6 config-stats

1.6.1 disable

Command

```
disable
```

Parameters

disable

Disable the reporter

1.6.2 enable

Command

```
enable
```

Parameters

enable

Enable the reporter

1.6.3 level (global|peer|subscriber)

Command

```
level (global|peer|subscriber)
```

Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

1.6.4 local-ip ADDR

Command

```
local-ip ADDR
```

Parameters

local-ip

Set the IP address to which we bind locally

ADDR

IP Address

1.6.5 mtu <100-65535>

Command

```
mtu <100-65535>
```

Parameters

mtu

Set the maximum packet size

<100-65535>

Size in byte

1.6.6 no local-ip

Command

```
no local-ip
```

Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

1.6.7 no mtu

Command

```
no mtu
```

Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

1.6.8 no prefix

Command

```
no prefix
```

Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

1.6.9 prefix PREFIX

Command

```
prefix PREFIX
```

Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

1.6.10 remote-ip ADDR

Command

```
remote-ip ADDR
```

Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

1.6.11 remote-port <1-65535>

Command

```
remote-port <1-65535>
```

Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

1.7 config-line

1.7.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

1.7.2 login

Command

```
login
```

Parameters

login

Enable password checking

1.7.3 no login

Command

```
no login
```

Parameters

no

Negate a command or set its defaults

login

Enable password checking

1.8 config-ctrl

1.8.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

bind

Set bind address to listen for Control connections

A.B.C.D

Local IP address (default 127.0.0.1)

1.9 config-cs7

1.9.1 as NAME (sua|m3ua|ipa)

Command

```
as NAME (sua|m3ua|ipa)
```

Parameters

as

Configure an Application Server

NAME

Name of the Application Server

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

1.9.2 asp NAME <0-65535> <0-65535> (sua|m3ua|ipa)

Command

```
asp NAME <0-65535> <0-65535> (sua|m3ua|ipa)
```

Parameters

asp

Configure Application Server Process

NAME

Name of ASP

<0-65535>

Remote SCTP port number

<0-65535>

Local SCTP port number

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

1.9.3 description .TEXT

Command

```
description .TEXT
```

Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

1.9.4 network-indicator (international | national | reserved | spare)

Command

```
network-indicator (international | national | reserved | spare)
```

Parameters

network-indicator

Configure the Network Indicator

international

International Network

national

National Network

reserved

Reserved Network

spare

Spare Network

1.9.5 no as NAME

Command

```
no as NAME
```

Parameters

no

Negate a command or set its defaults

as

Disable Application Server

NAME

Name of AS

1.9.6 no asp NAME

Command

```
no asp NAME
```

Parameters

no

Negate a command or set its defaults

asp

Disable Application Server Process

NAME

Name of ASP

1.9.7 no sccp-address NAME

Command

```
no sccp-address NAME
```

Parameters

no

Negate a command or set its defaults

sccp-address

Delete an SCCP addressbook entry

NAME

Name of the SCCP Address

1.9.8 point-code POINT_CODE

Command

```
point-code POINT_CODE
```

Parameters

point-code

Configure the local Point Code

POINT_CODE

Point Code

1.9.9 point-code delimiter (default|dash)

Command

```
point-code delimiter (default|dash)
```

Parameters

point-code

Point Code

delimiter

Configure Point Code Delimiter

default

Use dot as delimiter

dash

User dash as delimiter

1.9.10 point-code format <1-24> [<1-23>] [<1-22>]

Command

```
point-code format <1-24> [<1-23>] [<1-22>]
```

Parameters

point-code

Point Code

format

Configure Point Code Format

<1-24>

Length of first PC component

[<1-23>]

Length of second PC component

[<1-22>]

Length of third PC component

1.9.11 point-code format default

Command

```
point-code format default
```

Parameters

point-code

Point Code

format

Configure Point Code Format

default

Default Point Code Format (3.8.3)

1.9.12 sccp-address NAME

Command

```
sccp-address NAME
```

Parameters

sccp-address

Create/Modify an SCCP addressbook entry

NAME

Name of the SCCP Address

1.9.13 show cs7 instance <0-15> sccp-addressbook

Command

```
show cs7 instance <0-15> sccp-addressbook
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp-addressbook

List all SCCP addressbook entries

1.9.14 xua rkm routing-key-allocation (static-only|dynamic-permitted)

Command

```
xua rkm routing-key-allocation (static-only|dynamic-permitted)
```

Parameters

xua

SIGTRAN xxxUA related

rkm

Routing Key Management

routing-key-allocation

Routing Key Management Allocation Policy

static-only

Only static (pre-configured) Routing Keys permitted

dynamic-permitted

Dynamically allocate Routing Keys for what ASPs request

1.10 config-cs7-as

1.10.1 asp NAME

Command

```
asp NAME
```

Parameters

asp

Specify that a given ASP is part of this AS

NAME

Name of ASP to be added to AS

1.10.2 description .TEXT

Command

```
description .TEXT
```

Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

1.10.3 no asp NAME

Command

```
no asp NAME
```

Parameters

no

Negate a command or set its defaults

asp

Specify ASP to be removed from this AS

NAME

Name of ASP to be removed

1.10.4 point-code override dpc PC

Command

```
point-code override dpc PC
```

Parameters

point-code

Point Code Specific Features

override

Override (force) a point-code to hard-coded value

dpc

Override Source Point Code

PC

Override Destination Point Code

1.10.5 qos-class <0-255>

Command

```
qos-class <0-255>
```

Parameters

qos-class

Specity QoS Class of AS

<0-255>

QoS Class of AS

1.10.6 recovery-timeout <1-2000>

Command

```
recovery-timeout <1-2000>
```

Parameters

recovery-timeout

Specifies the recovery timeout value in milliseconds

<1-2000>

Recovery Timeout in Milliseconds

1.10.7 routing-key RCONTEXT DPC

Command

```
routing-key RCONTEXT DPC
```

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

1.10.8 routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup)

Command

```
routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup)
```

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

si

Match on Service Indicator

aal2
ATM Adaption Layer 2

bicc
Bearer Independent Call Control

b-isup
Broadband ISDN User Part

h248
H.248

isup
ISDN User Part

sat-isup
Sattelite ISDN User Part

sccp
Signalling Connection Control Part

tup
Telephony User Part

1.10.9 routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup) ssn S...

Command

```
routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup) ssn SSN
```

Parameters

routing-key
Define a routing key

RCONTEXT
Routing context number

DPC
Destination Point Code

si
Match on Service Indicator

aal2
ATM Adaption Layer 2

bicc
Bearer Independent Call Control

b-isup
Broadband ISDN User Part

h248
H.248

isup

ISDN User Part

sat-isup

Sattelite ISDN User Part

sccp

Signalling Connection Control Part

tup

Telephony User Part

ssn

Match on Sub-System Number

SSN

Sub-System Number to match on

1.10.10 routing-key RCONTEXT DPC ssn SSN

Command

```
routing-key RCONTEXT DPC ssn SSN
```

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

ssn

Match on Sub-System Number

SSN

Sub-System Number to match on

1.10.11 traffic-mode (broadcast | loadshare | roundrobin | override)

Command

```
traffic-mode (broadcast | loadshare | roundrobin | override)
```

Parameters

traffic-mode

Specifies traffic mode of operation of the ASP within the AS

broadcast

Broadcast to all ASP within AS

loadshare

Share Load among all ASP within AS

roundrobin

Round-Robin between all ASP within AS

override

Override

1.11 config-cs7-asp

1.11.1 block

Command

```
block
```

Parameters

block

Allows a SCTP Association with ASP, but doesn't let it become active

1.11.2 description .TEXT

Command

```
description .TEXT
```

Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

1.11.3 local-ip A.B.C.D

Command

```
local-ip A.B.C.D
```

Parameters

local-ip

Specify Local IP Address from which to contact ASP

A.B.C.D

Local IP Address from which to contact of ASP

1.11.4 qos-class <0-255>

Command

```
qos-class <0-255>
```

Parameters

qos-class

Specify QoS Class of ASP

<0-255>

QoS Class of ASP

1.11.5 remote-ip A.B.C.D

Command

```
remote-ip A.B.C.D
```

Parameters

remote-ip

Specify Remote IP Address of ASP

A.B.C.D

Remote IP Address of ASP

1.11.6 shutdown

Command

```
shutdown
```

Parameters

shutdown

Terminates SCTP association; New associations will be rejected

1.12 config-cs7-sccpaddr

1.12.1 global-title

Command

```
global-title
```

Parameters

global-title

Add/Modify Global Title

1.12.2 no global-title

Command

```
no global-title
```

Parameters

no

Negate a command or set its defaults

global-title

Remove Global Title

1.12.3 no point-code

Command

```
no point-code
```

Parameters

no

Negate a command or set its defaults

point-code

Remove point-code Number

1.12.4 no subsystem-number

Command

```
no subsystem-number
```

Parameters

no

Negate a command or set its defaults

subsystem-number

Remove Subsystem Number

1.12.5 point-code POINT_CODE

Command

```
point-code POINT_CODE
```

Parameters

point-code

Add point-code Number

POINT_CODE

PC

1.12.6 routing-indicator (GT|PC|IP)

Command

```
routing-indicator (GT|PC|IP)
```

Parameters

routing-indicator

Add Routing Indicator

GT

by global-title

PC

by point-code

IP

by ip-address

1.12.7 subsystem-number <0-4294967295>

Command

```
subsystem-number <0-4294967295>
```

Parameters

subsystem-number

Add Subsystem Number

<0-4294967295>

SSN

1.13 config-cs7-sccpaddr-gt

1.13.1 digits DIGITS

Command

```
digits DIGITS
```

Parameters

digits

Set Global Title Digits

DIGITS

Number digits

1.13.2 global-title-indicator <0-15>

Command

```
global-title-indicator <0-15>
```

Parameters

global-title-indicator

Set Global Title Indicator

<0-15>

GTI

1.13.3 nature-of-address-indicator <0-127>

Command

```
nature-of-address-indicator <0-127>
```

Parameters

nature-of-address-indicator

Set Global Title Nature of Address Indicator

<0-127>

NAI

1.13.4 numbering-plan-indicator <0-15>

Command

```
numbering-plan-indicator <0-15>
```

Parameters

numbering-plan-indicator

Set Global Title Numbering Plan Indicator

<0-15>

NPI

1.13.5 translation-type <0-255>

Command

```
translation-type <0-255>
```

Parameters

translation-type

Set Global Title Translation Type

<0-255>

TT

1.14 config-net

1.14.1 authentication (optional|required)

Command

```
authentication (optional|required)
```

Parameters

authentication

Whether to enforce MS authentication in 2G

optional

Allow MS to attach via 2G BSC without authentication

required

Always do authentication

1.14.2 encryption a5 <0-3> [<0-3>] [<0-3>] [<0-3>]

Command

```
encryption a5 <0-3> [<0-3>] [<0-3>] [<0-3>]
```

Parameters

encryption

Encryption options

a5

GSM A5 Air Interface Encryption

<0-3>

A5/n Algorithm Number

[<0-3>]

A5/n Algorithm Number

[<0-3>]

A5/n Algorithm Number

[<0-3>]

A5/n Algorithm Number

1.14.3 long name NAME

Command

```
long name NAME
```

Parameters

long

Set the long GSM network name

name

Name Commands

NAME

Name to use

1.14.4 mm info (0|1)

Command

```
mm info (0|1)
```

Parameters

mm

Mobility Management

info

Send MM INFO after LOC UPD ACCEPT

0

Disable

1

Enable

1.14.5 mobile network code <0-999>

Command

```
mobile network code <0-999>
```

Parameters

mobile

Set the GSM mobile network code

network

Network Commands

code

Code commands

<0-999>

Mobile Network Code to use

1.14.6 network country code <1-999>

Command

```
network country code <1-999>
```

Parameters

network

Set the GSM network country code

country

Country commands

code

Code commands

<1-999>

Network Country Code to use

1.14.7 no periodic location update

Command

```
no periodic location update
```

Parameters

no

Negate a command or set its defaults

periodic

Periodic Location Updating Interval

location

Periodic Location Updating Interval

update

Periodic Location Updating Interval

1.14.8 no timezone

Command

```
no timezone
```

Parameters

no

Negate a command or set its defaults

timezone

Disable network timezone override, use system tz

1.14.9 periodic location update <6-1530>

Command

```
periodic location update <6-1530>
```

Parameters

periodic

Periodic Location Updating Interval

location

Periodic Location Updating Interval

update

Periodic Location Updating Interval

<6-1530>

Periodic Location Updating Interval in Minutes

1.14.10 rrlp mode (none|ms-based|ms-preferred|ass-preferred)

Command

```
rrlp mode (none|ms-based|ms-preferred|ass-preferred)
```

Parameters

rrlp

Radio Resource Location Protocol

mode

Set the Radio Resource Location Protocol Mode

none

Don't send RRLP request

ms-based

Request MS-based location

ms-preferred

Request any location, prefer MS-based

ass-preferred

Request any location, prefer MS-assisted

1.14.11 short name NAME

Command

```
short name NAME
```

Parameters

short

Set the short GSM network name

name

Name Commands

NAME

Name to use

1.14.12 timezone <-19-19> (0|15|30|45)

Command

```
timezone <-19-19> (0|15|30|45)
```

Parameters

timezone

Set the Timezone Offset of the network

<-19-19>

Timezone offset (hours)

0

Timezone offset (00 minutes)

15

Timezone offset (15 minutes)

30

Timezone offset (30 minutes)

45

Timezone offset (45 minutes)

1.14.13 timezone <-19-19> (0|15|30|45) <0-2>

Command

```
timezone <-19-19> (0|15|30|45) <0-2>
```

Parameters

timezone

Set the Timezone Offset of the network

<-19-19>

Timezone offset (hours)

0

Timezone offset (00 minutes)

15

Timezone offset (15 minutes)

30

Timezone offset (30 minutes)

45

Timezone offset (45 minutes)

<0-2>

DST offset (hours)

1.15 config-msc

1.15.1 asn1 debug (1|0)

Command

```
asn1 debug (1|0)
```

Parameters

asn1

ASN.1 settings

debug

Enable ASN.1 debug messages

1

Log ASN.1 debug messages to stderr

0

Do not log ASN.1 debug messages to stderr

1.15.2 asn1 xer-print (1|0)

Command

```
asn1 xer-print (1|0)
```

Parameters

asn1

ASN.1 settings

xer-print

Log human readable representations of all ASN.1 messages to stderr

1

Log XML representation of all ASN.1 messages to stderr

0

Do not log decoded ASN.1 messages to stderr

1.15.3 assign-tmsi

Command

```
assign-tmsi
```

Parameters

assign-tmsi

Assign TMSI during Location Updating.

1.15.4 auth-tuple-max-reuse-count <-1-2147483647>

Command

```
auth-tuple-max-reuse-count <-1-2147483647>
```

Parameters

auth-tuple-max-reuse-count

Configure authentication tuple re-use

<-1-2147483647>

0 to use each auth tuple at most once (default), >0 to limit re-use, -1 to re-use infinitely (vulnerable!).

1.15.5 auth-tuple-reuse-on-error (0|1)

Command

```
auth-tuple-reuse-on-error (0|1)
```

Parameters

auth-tuple-reuse-on-error

Configure authentication tuple re-use when HLR is not responsive

0

0 = never re-use auth tuples beyond auth-tuple-max-reuse-count (default)

1

1 = if the HLR does not deliver new tuples, do re-use already available old ones.

1.15.6 cs7-instance-a <0-15>

Command

```
cs7-instance-a <0-15>
```

Parameters

cs7-instance-a

Set SS7 to be used by the A-Interface.

<0-15>

SS7 instance reference number

1.15.7 cs7-instance-iu <0-15>

Command

```
cs7-instance-iu <0-15>
```

Parameters

cs7-instance-iu

Set SS7 to be used by the Iu-Interface.

<0-15>

SS7 instance reference number

1.15.8 emergency-call route-to-msisdn MSISDN

Command

```
emergency-call route-to-msisdn MSISDN
```

Parameters

emergency-call

Configure Emergency Call Behaviour

route-to-msisdn

MSISDN to which Emergency Calls are Dispatched

MSISDN

MSISDN (E.164 Phone Number)

1.15.9 iu rab-assign-addr-enc (x213|v4raw)

Command

```
iu rab-assign-addr-enc (x213|v4raw)
```

Parameters

iu

Iu interface protocol options

rab-assign-addr-enc

Choose RAB Assignment's Transport Layer Address encoding

x213

ITU-T X.213 compliant address encoding (default)

v4raw

32bit length raw IPv4 address (for ip.access nano3G)

1.15.10 mgcpgw bts-base <0-65534>

Command

```
mgcpgw bts-base <0-65534>
```

Parameters

mgcpgw

Configure MGCP connection to Media Gateway

bts-base

First UDP port allocated for the BTS side

<0-65534>

UDP Port number

1.15.11 mgcpgw endpoint-range <1-65534> <1-65534>

Command

```
mgcpgw endpoint-range <1-65534> <1-65534>
```

Parameters

mgcpgw

Configure MGCP connection to Media Gateway

endpoint-range

usable range of endpoint identifiers

<1-65534>

set first useable endpoint identifier

<1-65534>

set the last useable endpoint identifier

1.15.12 mgcpgw local-ip A.B.C.D

Command

```
mgcpgw local-ip A.B.C.D
```

Parameters

mgcpgw

Configure MGCP connection to Media Gateway

local-ip

local bind to connect to MGCP gateway with

A.B.C.D

local bind IP address

1.15.13 mgcpgw local-port <0-65535>

Command

```
mgcpgw local-port <0-65535>
```

Parameters

mgcpgw

Configure MGCP connection to Media Gateway

local-port

local bind to connect to MGCP gateway with

<0-65535>

local bind port

1.15.14 mgcpgw remote-ip A.B.C.D

Command

```
mgcpgw remote-ip A.B.C.D
```

Parameters

mgcpgw

Configure MGCP connection to Media Gateway

remote-ip

remote bind to connect to MGCP gateway with

A.B.C.D

remote bind IP address

1.15.15 mgcpgw remote-port <0-65535>

Command

```
mgcpgw remote-port <0-65535>
```

Parameters

mgcpgw

Configure MGCP connection to Media Gateway

remote-port

remote bind to connect to MGCP gateway with

<0-65535>

remote bind port

1.15.16 mgw bts-base <0-65534>

Command

```
mgw bts-base <0-65534>
```

Parameters

mgw

Configure MGCP connection to Media Gateway

bts-base

First UDP port allocated for the BTS side

<0-65534>

UDP Port number

1.15.17 mgw endpoint-range <1-65534> <1-65534>

Command

```
mgw endpoint-range <1-65534> <1-65534>
```

Parameters

mgw

Configure MGCP connection to Media Gateway

endpoint-range

usable range of endpoint identifiers

<1-65534>

set first usable endpoint identifier

<1-65534>

set last usable endpoint identifier

1.15.18 mgw local-ip A.B.C.D

Command

```
mgw local-ip A.B.C.D
```

Parameters

mgw

Configure MGCP connection to Media Gateway

local-ip

local bind to connect to MGW from

A.B.C.D

local bind IP address

1.15.19 mgw local-port <0-65535>

Command

```
mgw local-port <0-65535>
```

Parameters

mgw

Configure MGCP connection to Media Gateway

local-port

local port to connect to MGW from

<0-65535>

local bind port

1.15.20 mgw remote-ip A.B.C.D

Command

```
mgw remote-ip A.B.C.D
```

Parameters

mgw

Configure MGCP connection to Media Gateway

remote-ip

remote IP address to reach the MGW at

A.B.C.D

remote IP address

1.15.21 mgw remote-port <0-65535>

Command

```
mgw remote-port <0-65535>
```

Parameters

mgw

Configure MGCP connection to Media Gateway

remote-port

remote port to reach the MGW at

<0-65535>

remote port

1.15.22 no assign-tmsi

Command

```
no assign-tmsi
```

Parameters

no

Negate a command or set its defaults

assign-tmsi

Assign TMSI during Location Updating.

1.15.23 paging response-timer (default|<1-65535>)

Command

```
paging response-timer (default|<1-65535>)
```

Parameters

paging

Configure Paging

response-timer

Set Paging timeout, the minimum time to pass between (unsuccessful) Pagings sent towards BSS or RNC

default

Set to default timeout (10 seconds)

<1-65535>

Set paging timeout in seconds

1.16 config-mncc-int

This node allows to configure the default codecs for the internal call control handling.

1.16.1 default-codec tch-f (fr|efr|amr)

Command

```
default-codec tch-f (fr|efr|amr)
```

Parameters

default-codec

Set default codec

tch-f

Codec for TCH/F

fr

Full-Rate

efr

Enhanced Full-Rate

amr

Adaptive Multi-Rate

1.16.2 default-codec tch-h (hr|amr)

Command

```
default-codec tch-h (hr|amr)
```

Parameters

default-codec

Set default codec

tch-h

Codec for TCH/H

hr

Half-Rate

amr

Adaptive Multi-Rate

1.17 config-smpp

This node allows to configure the SMPP interface for interfacing with external SMS applications. This section contains generic/common SMPP related configuration, and no per-ESME specific parameters.

1.17.1 esme NAME

Command

```
esme NAME
```

Parameters

esme

Configure a particular ESME

NAME

Alphanumeric System ID of the ESME to be configured

1.17.2 local-tcp-ip A.B.C.D <1-65535>

Command

```
local-tcp-ip A.B.C.D <1-65535>
```

Parameters

local-tcp-ip

Set the local IP address and TCP port on which we listen for SMPP

A.B.C.D

Local IP address

<1-65535>

TCP port number

1.17.3 local-tcp-port <1-65535>

Command

```
local-tcp-port <1-65535>
```

Parameters

local-tcp-port

Set the local TCP port on which we listen for SMPP

<1-65535>

TCP port number

1.17.4 no esme NAME

Command

```
no esme NAME
```

Parameters

no

Negate a command or set its defaults

esme

Remove ESME configuration

NAME

Alphanumeric System ID of the ESME to be removed

1.17.5 no smpp-first

Command

```
no smpp-first
```

Parameters

no

Negate a command or set its defaults

smpp-first

Try SMPP before routes before the subscriber DB

1.17.6 policy (accept-all|closed)

Command

```
policy (accept-all|closed)
```

Parameters

policy

Set the authentication policy of this SMSC

accept-all

Accept all SMPP connections independent of system ID / passwd

closed

Accept only SMPP connections from ESMEs explicitly configured

1.17.7 smpp-first

Command

```
smpp-first
```

Parameters

smpp-first

Try SMPP routes before the subscriber DB

1.17.8 system-id ID

Command

```
system-id ID
```

Parameters

system-id

Set the System ID of this SMSC

ID

Alphanumeric SMSC System ID

1.18 config-smpp-esme

This node allows to configure one particular SMPP ESME, which is an External SMS Entity such as a SMS based application server. You can define any number of ESME within the SMPP node of the OsmoNITB VTY.

1.18.1 dcs-transparent

Command

```
dcs-transparent
```

Parameters

dcs-transparent

Enable the transparent pass-through of TP-DCS to SMPP DataCoding

1.18.2 default-route

Command

```
default-route
```

Parameters

default-route

Set this ESME as default-route for all SMS to unknown destinations

1.18.3 deliver-src-imsi

Command

```
deliver-src-imsi
```

Parameters

deliver-src-imsi

Enable the use of IMSI as source address in DELIVER

1.18.4 no dcs-transparent

Command

```
no dcs-transparent
```

Parameters

no

Negate a command or set its defaults

dcs-transparent

Disable the transparent pass-through of TP-DCS to SMPP DataCoding

1.18.5 no default-route

Command

```
no default-route
```

Parameters

no

Negate a command or set its defaults

default-route

Remove this ESME as default-route for all SMS to unknown destinations

1.18.6 no deliver-src-imsi

Command

```
no deliver-src-imsi
```

Parameters

no

Negate a command or set its defaults

deliver-src-imsi

Disable the use of IMSI as source address in DELIVER

1.18.7 no osmocom-extensions

Command

```
no osmocom-extensions
```

Parameters

no

Negate a command or set its defaults

osmocom-extensions

Disable the use of Osmocom SMPP Extensions for this ESME

1.18.8 no password

Command

```
no password
```

Parameters

no

Negate a command or set its defaults

password

Remove the password for this ESME

1.18.9 no route prefix (unknown|international|national|network|subscriber|alpha|abbrev)...

Command

```
no route prefix (unknown|international|national|network|subscriber|alpha|abbrev) ( ←  
unknown|isdn|x121|f69|e212|national|private|ermes|ip|wap) PREFIX
```

Parameters

no

Negate a command or set its defaults

route

Configure a route for MO-SMS to be sent to this ESME

prefix

Prefix-match route

unknown

Unknown type-of-number

international

International type-of-number

national
 National type-of-number

network
 Network specific type-of-number

subscriber
 Subscriber type-of-number

alpha
 Alphanumeric type-of-number

abbrev
 Abbreviated type-of-number

unknown
 Unknown numbering plan

isdn
 ISDN (E.164) numbering plan

x121
 X.121 numbering plan

f69
 F.69 numbering plan

e212
 E.212 numbering plan

national
 National numbering plan

private
 Private numbering plan

ermes
 ERMES numbering plan

ip
 IP numbering plan

wap
 WAP numbeing plan

PREFIX
 Destination number prefix

1.18.10 osmocom-extensions

Command

```
osmocom-extensions
```

Parameters

osmocom-extensions

Enable the use of Osmocom SMPP Extensions for this ESME

1.18.11 password PASSWORD

Command

```
password PASSWORD
```

Parameters

password

Set the password for this ESME

PASSWORD

Alphanumeric password string

1.18.12 route prefix (unknown|international|national|network|subscriber|alpha|abbrev) (u...

Command

```
route prefix (unknown|international|national|network|subscriber|alpha|abbrev) (unknown| ↔  
isdn|x121|f69|e212|national|private|ermes|ip|wap) PREFIX
```

Parameters

route

Configure a route for MO-SMS to be sent to this ESME

prefix

Prefix-match route

unknown

Unknown type-of-number

international

International type-of-number

national

National type-of-number

network

Network specific type-of-number

subscriber

Subscriber type-of-number

alpha

Alphanumeric type-of-number

abbrev

Abbreviated type-of-number

unknown

Unknown numbering plan

isdn
ISDN (E.164) numbering plan

x121
X.121 numbering plan

f69
F.69 numbering plan

e212
E.212 numbering plan

national
National numbering plan

private
Private numbering plan

ermes
ERMES numbering plan

ip
IP numbering plan

wap
WAP numbeing plan

PREFIX
Destination number prefix

1.19 config-hlr

1.19.1 remote-ip A.B.C.D

Command

```
remote-ip A.B.C.D
```

Parameters

remote-ip

Remote GSUP address of the HLR

A.B.C.D

Remote GSUP address (default: 127.0.0.1)

1.19.2 remote-port <1-65535>

Command

```
remote-port <1-65535>
```

Parameters

remote-port

Remote GSUP port of the HLR

<1-65535>

Remote GSUP port (default: MSC_HLR_REMOTE_PORT_DEFAULT)
