

# OsmoSGSN VTY Reference

---

Copyright © 2013-2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

---

**COLLABORATORS**

	<i>TITLE :</i> OsmoSGSN VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		February 22, 2018	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v1	13th January 2013	Initial	hw
v2	5th March 2014	Update to match osmo-bsc version 0.13.0-305	hf

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	.....	1
1.1.1	bssgp bvc nsei <0-65535> bvci <0-65535> reset	1
1.1.2	echo .MESSAGE	2
1.1.3	enable	2
1.1.4	exit	3
1.1.5	help	3
1.1.6	list	3
1.1.7	logging color (01)	3
1.1.8	logging disable	4
1.1.9	logging enable	4
1.1.10	logging filter all (01)	4
1.1.11	logging filter bvc nsei <0-65535> bvci <0-65535>	5
1.1.12	logging filter nsvc (nseilnsvci) <0-65535>	5
1.1.13	logging level (allmmlpaglmeasreflgrprslnslbssgplllclsndcplslhclranaplsualv42bis...	6
1.1.14	logging print category (01)	8
1.1.15	logging print extended-timestamp (01)	8
1.1.16	logging set log mask MASK	9
1.1.17	logging set-log-mask MASK	9
1.1.18	logging timestamp (01)	9
1.1.19	show alarms	10
1.1.20	show asciidoc counters	10
1.1.21	show bssgp	10
1.1.22	show bssgp nsei <0-65535> [stats]	11
1.1.23	show bssgp stats	11
1.1.24	show history	11
1.1.25	show llc	12
1.1.26	show logging vty	12
1.1.27	show mm-context all [pdp]	12
1.1.28	show mm-context imsi IMSI [pdp]	13

1.1.29	show ns	13
1.1.30	show ns (nseilnsvc) <0-65535> [stats]	13
1.1.31	show ns stats	14
1.1.32	show online-help	14
1.1.33	show pdp-context all	15
1.1.34	show sgsn	15
1.1.35	show sndcp	15
1.1.36	show stats	16
1.1.37	show stats level (globalpeerlsubscriber)	16
1.1.38	show subscriber cache	16
1.1.39	show version	17
1.1.40	terminal length <0-512>	17
1.1.41	terminal no length	17
1.1.42	who	18
1.2		18
1.2.1	bssgp bvc nsei <0-65535> bvci <0-65535> reset	18
1.2.2	configure terminal	18
1.2.3	copy running-config startup-config	19
1.2.4	disable	19
1.2.5	echo .MESSAGE	19
1.2.6	exit	19
1.2.7	help	20
1.2.8	list	20
1.2.9	logging color (01)	20
1.2.10	logging disable	20
1.2.11	logging enable	21
1.2.12	logging filter all (01)	21
1.2.13	logging filter bvc nsei <0-65535> bvci <0-65535>	21
1.2.14	logging filter nsvc (nseilnsvci) <0-65535>	22
1.2.15	logging level (allmmlpaglmeasreflgrprslnslbssgp1llclsndcplslhclranapsualv42bis...	23
1.2.16	logging print category (01)	25
1.2.17	logging print extended-timestamp (01)	25
1.2.18	logging set log mask MASK	26
1.2.19	logging set-log-mask MASK	26
1.2.20	logging timestamp (01)	26
1.2.21	nsvc (nseilnsvci) <0-65535> (blocklunblocklreset)	27
1.2.22	show alarms	27
1.2.23	show asciidoc counters	28
1.2.24	show bssgp	28

1.2.25	show bssgp nsei <0-65535> [stats]	28
1.2.26	show bssgp stats	29
1.2.27	show history	29
1.2.28	show llc	29
1.2.29	show logging vty	30
1.2.30	show mm-context all [pdp]	30
1.2.31	show mm-context imsi IMSI [pdp]	30
1.2.32	show ns	31
1.2.33	show ns (nseilnsvc) <0-65535> [stats]	31
1.2.34	show ns stats	32
1.2.35	show online-help	32
1.2.36	show pdp-context all	32
1.2.37	show running-config	33
1.2.38	show sgsn	33
1.2.39	show sndcp	33
1.2.40	show startup-config	33
1.2.41	show stats	34
1.2.42	show stats level (globalpeerlsubscriber)	34
1.2.43	show subscriber cache	34
1.2.44	show version	35
1.2.45	terminal length <0-512>	35
1.2.46	terminal monitor	35
1.2.47	terminal no length	36
1.2.48	terminal no monitor	36
1.2.49	update-subscriber imsi IMSI cancel (update-procedurelsubscription-withdraw)	36
1.2.50	update-subscriber imsi IMSI create	37
1.2.51	update-subscriber imsi IMSI destroy	37
1.2.52	update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC	38
1.2.53	update-subscriber imsi IMSI update-auth-info	38
1.2.54	update-subscriber imsi IMSI update-location-result (oklssystem-failureldata-missi...	39
1.2.55	who	40
1.2.56	write	40
1.2.57	write file	40
1.2.58	write memory	40
1.2.59	write terminal	41
1.3		41
1.3.1	banner motd default	41
1.3.2	banner motd file [FILE]	41
1.3.3	bssgp	42

1.3.4	ctrl	42
1.3.5	enable password (8l) WORD	42
1.3.6	enable password LINE	43
1.3.7	end	43
1.3.8	exit	43
1.3.9	help	43
1.3.10	hostname WORD	44
1.3.11	line vty	44
1.3.12	list	44
1.3.13	log alarms <2-32700>	44
1.3.14	log file .FILENAME	45
1.3.15	log gsmmap [HOSTNAME]	45
1.3.16	log stderr	45
1.3.17	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	46
1.3.18	log syslog local <0-7>	46
1.3.19	no banner motd	47
1.3.20	no enable password	47
1.3.21	no hostname [HOSTNAME]	47
1.3.22	no log alarms	48
1.3.23	no log file .FILENAME	48
1.3.24	no log stderr	48
1.3.25	no log syslog	49
1.3.26	no service advanced-vty	49
1.3.27	no service terminal-length [<0-512>]	49
1.3.28	no stats reporter log	50
1.3.29	no stats reporter statsd	50
1.3.30	ns	50
1.3.31	password (8l) WORD	51
1.3.32	password LINE	51
1.3.33	service advanced-vty	51
1.3.34	service terminal-length <0-512>	52
1.3.35	sgsn	52
1.3.36	show history	52
1.3.37	show running-config	52
1.3.38	stats interval <1-65535>	53
1.3.39	stats reporter log	53
1.3.40	stats reporter statsd	53
1.3.41	write	54
1.3.42	write file	54

1.3.43	write memory . . . . .	54
1.3.44	write terminal . . . . .	54
1.4	. . . . .	55
1.4.1	end . . . . .	55
1.4.2	exit . . . . .	55
1.4.3	help . . . . .	55
1.4.4	list . . . . .	55
1.4.5	logging color (01) . . . . .	56
1.4.6	logging filter all (01) . . . . .	56
1.4.7	logging filter bvc nsei <0-65535> bvci <0-65535> . . . . .	57
1.4.8	logging filter nsvc (nseilnsvci) <0-65535> . . . . .	57
1.4.9	logging level (allmm paglmeasrefl gpr ns bssgp llc s ndc pls h clran plsualv42bis... . . . . .	58
1.4.10	logging print category (01) . . . . .	60
1.4.11	logging print extended-timestamp (01) . . . . .	60
1.4.12	logging timestamp (01) . . . . .	61
1.4.13	show running-config . . . . .	61
1.4.14	write . . . . .	61
1.4.15	write file . . . . .	62
1.4.16	write memory . . . . .	62
1.4.17	write terminal . . . . .	62
1.5	E1/J1/T1 Configuration Node . . . . .	62
1.5.1	bind A.B.C.D . . . . .	63
1.5.2	end . . . . .	63
1.5.3	exit . . . . .	63
1.5.4	help . . . . .	63
1.5.5	list . . . . .	64
1.5.6	login . . . . .	64
1.5.7	no login . . . . .	64
1.5.8	show running-config . . . . .	64
1.5.9	write . . . . .	65
1.5.10	write file . . . . .	65
1.5.11	write memory . . . . .	65
1.5.12	write terminal . . . . .	65
1.6	. . . . .	66
1.6.1	encapsulation framerelay-gre enabled (110) . . . . .	66
1.6.2	encapsulation framerelay-gre local-ip A.B.C.D . . . . .	66
1.6.3	encapsulation udp dscp <0-255> . . . . .	67
1.6.4	encapsulation udp local-ip A.B.C.D . . . . .	67
1.6.5	encapsulation udp local-port <0-65535> . . . . .	67



1.6.6	end	68
1.6.7	exit	68
1.6.8	help	68
1.6.9	list	68
1.6.10	no nse <0-65535>	69
1.6.11	nse <0-65535> encapsulation (udplframerelay-gre)	69
1.6.12	nse <0-65535> fr-dlci <16-1007>	69
1.6.13	nse <0-65535> nsvci <0-65534>	70
1.6.14	nse <0-65535> remote-ip A.B.C.D	70
1.6.15	nse <0-65535> remote-port <0-65535>	71
1.6.16	nse <0-65535> remote-role (sgsnlbss)	71
1.6.17	show running-config	71
1.6.18	timer (tns-block tns-block-retries tns-reset tns-reset-retries tns-test tns-aliv...	72
1.6.19	write	72
1.6.20	write file	73
1.6.21	write memory	73
1.6.22	write terminal	73
1.7		73
1.7.1	end	73
1.7.2	exit	74
1.7.3	help	74
1.7.4	list	74
1.7.5	show running-config	74
1.7.6	write	75
1.7.7	write file	75
1.7.8	write memory	75
1.7.9	write terminal	75
1.8		76
1.8.1	bind A.B.C.D	76
1.9	SGSN Configuration Node	76
1.9.1	access-point-name NAME	76
1.9.2	access-point-name NAME	76
1.9.3	apn APNAME ggsn <0-255>	77
1.9.4	apn APNAME ggsn <0-255>	77
1.9.5	apn APNAME imsi-prefix IMSIPRE ggsn <0-255>	77
1.9.6	apn APNAME imsi-prefix IMSIPRE ggsn <0-255>	78
1.9.7	auth-policy (accept-all closed acl-only remote)	78
1.9.8	auth-policy (accept-all closed acl-only remote)	78
1.9.9	cdr filename NAME	79

---

1.9.10	cdr filename NAME	79
1.9.11	cdr interval <1-2147483647>	79
1.9.12	cdr interval <1-2147483647>	80
1.9.13	compression rfc1144 active slots <1-256>	80
1.9.14	compression rfc1144 passive	80
1.9.15	compression v42bis active direction (mslsgsnlboth) codewords <512-65535> strlen ...	81
1.9.16	compression v42bis passive	81
1.9.17	encryption (GEA0 GEA1 GEA2 GEA3 GEA4)	82
1.9.18	end	82
1.9.19	exit	82
1.9.20	ggsn <0-255> gtp-version (0 1)	83
1.9.21	ggsn <0-255> gtp-version (0 1)	83
1.9.22	ggsn <0-255> remote-ip A.B.C.D	83
1.9.23	ggsn <0-255> remote-ip A.B.C.D	84
1.9.24	ggsn dynamic	84
1.9.25	ggsn dynamic	84
1.9.26	grx-dns-add A.B.C.D	84
1.9.27	grx-dns-add A.B.C.D	85
1.9.28	gsup oap-id <0-65535>	85
1.9.29	gsup oap-id <0-65535>	85
1.9.30	gsup oap-k K	85
1.9.31	gsup oap-k K	86
1.9.32	gsup oap-opc OPC	86
1.9.33	gsup oap-opc OPC	86
1.9.34	gsup remote-ip A.B.C.D	86
1.9.35	gsup remote-ip A.B.C.D	87
1.9.36	gsup remote-port <0-65535>	87
1.9.37	gtp local-ip A.B.C.D	87
1.9.38	gtp local-ip A.B.C.D	88
1.9.39	help	88
1.9.40	imsi-acl (add del) IMSI	88
1.9.41	imsi-acl (add del) IMSI	88
1.9.42	list	89
1.9.43	no access-point-name NAME	89
1.9.44	no cdr filename	89
1.9.45	no compression rfc1144	90
1.9.46	no compression v42bis	90
1.9.47	show running-config	90
1.9.48	timer t3312 <0-65535>	91

---

1.9.49	timer t3313 <0-65535>	91
1.9.50	timer t3314 <0-65535>	91
1.9.51	timer t3316 <0-65535>	92
1.9.52	timer t3322 <0-65535>	92
1.9.53	timer t3350 <0-65535>	92
1.9.54	timer t3360 <0-65535>	93
1.9.55	timer t3370 <0-65535>	93
1.9.56	timer t3385 <0-65535>	93
1.9.57	timer t3386 <0-65535>	94
1.9.58	timer t3395 <0-65535>	94
1.9.59	timer t3397 <0-65535>	94
1.9.60	write	95
1.9.61	write file	95
1.9.62	write memory	95
1.9.63	write terminal	95

---

# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sismocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1

#### 1.1.1 bssgp bvc nsei <0-65535> bvci <0-65535> reset

## Command

```
bssgp bvc nsei <0-65535> bvci <0-65535> reset
```

## Parameters

### bssgp

Initiate BVC RESET procedure for a given NSEI and BVCI

### bvc

Filter based on BSSGP Virtual Connection

### nsei

NSEI of the BVC to be filtered

### <0-65535>

Network Service Entity Identifier (NSEI)

### bvci

BVCI of the BVC to be filtered

### <0-65535>

BSSGP Virtual Connection Identifier (BVCI)

### reset

Perform reset procedure

## 1.1.2 echo .MESSAGE

## Command

```
echo .MESSAGE
```

## Parameters

### echo

Echo a message back to the vty

### .MESSAGE

The message to echo

## 1.1.3 enable

## Command

```
enable
```

## Parameters

### enable

Turn on privileged mode command

### 1.1.4 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.5 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.6 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.1.7 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

logging

Configure log message to this terminal

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

---

### 1.1.8 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure log message to this terminal

##### disable

Disables logging to this vty

### 1.1.9 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure log message to this terminal

##### enable

Enables logging to this vty

### 1.1.10 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages



### 1.1.11 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

### 1.1.12 logging filter nsvc (nsei|nsvci) <0-65535>

#### Command

```
logging filter nsvc (nsei|nsvci) <0-65535>
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### nsvc

Filter based on NS Virtual Connection

##### nsei

Identify NS-VC by NSEI

##### nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

### 1.1.13 logging level (all|mm|pag|meas|ref|gprs|ns|bssgp|llc|sndcp|slhc|ranap|sua|v42bis...

#### Command

```
logging level (all|mm|pag|meas|ref|gprs|ns|bssgp|llc|sndcp|slhc|ranap|sua|v42bis| ↵  
lglobal|llapd|linp|lmux|lmi|lmib|lms|lctrl|lgtp|lstats) (everything|debug|info| ↵  
notice|error|fatal)
```

#### Parameters

##### logging

Configure log message to this terminal

##### level

Set the log level for a specified category

##### all

Global setting for all subsystems

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### ns

GPRS Network Service (NS)

##### bssgp

GPRS BSS Gateway Protocol (BSSGP)

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SNDCP)

##### slhc

RFC1144 TCP/IP Header compression (SLHC)

##### ranap

RAN Application Part (RANAP)

##### sua

SCCP User Adaptation (SUA)

---

v42bis  
V.42bis data compression (SNDTCP)

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

everything  
Don't use. It doesn't log anything

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.1.14 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.1.15 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnn

### 1.1.16 logging set log mask MASK

#### Command

```
logging set log mask MASK
```

#### Parameters

##### logging

Configure log message to this terminal

##### set

Decide which categories to output.

##### log

Log commands

##### mask

Mask commands

##### MASK

The logmask to use

### 1.1.17 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure log message to this terminal

##### set-log-mask

Set the logmask of this logging target

##### MASK

The logmask to use

### 1.1.18 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

---

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.1.19 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.1.20 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.1.21 show bssgp

Command

```
show bssgp
```

Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

### 1.1.22 show bssgp nsei <0-65535> [stats]

#### Command

```
show bssgp nsei <0-65535> [stats]
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

nsei

Show all BVCs on one NSE

<0-65535>

The NSEI

[stats]

Include Statistics

### 1.1.23 show bssgp stats

#### Command

```
show bssgp stats
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

stats

Include statistics

### 1.1.24 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.1.25 show llc

#### Command

```
show llc
```

#### Parameters

show

Show running system information

llc

Display information about the LLC protocol

### 1.1.26 show logging vty

#### Command

```
show logging vty
```

#### Parameters

show

Show running system information

logging

Show current logging configuration

vtty

Show current logging configuration for this vty

### 1.1.27 show mm-context all [pdp]

#### Command

```
show mm-context all [pdp]
```

#### Parameters

show

Show running system information

mm-context

MM Context

all

All MM Contexts

[pdp]

Include PDP Context Information

---



### 1.1.28 show mm-context imsi IMSI [pdp]

#### Command

```
show mm-context imsi IMSI [pdp]
```

#### Parameters

show

Show running system information

mm-context

MM Context

imsi

Identify by IMSI

IMSI

IMSI of the MM Context

[pdp]

Include PDP Context Information

### 1.1.29 show ns

#### Command

```
show ns
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

### 1.1.30 show ns (nsei|nsvc) <0-65535> [stats]

#### Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

---

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

### 1.1.31 show ns stats

Command

```
show ns stats
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

stats

Include statistics

### 1.1.32 show online-help

Command

```
show online-help
```

Parameters

show

Show running system information

online-help

Online help

### 1.1.33 show pdp-context all

#### Command

```
show pdp-context all
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

all

Show everything

### 1.1.34 show sgsn

#### Command

```
show sgsn
```

#### Parameters

show

Show running system information

sgsn

Display information about the SGSN

### 1.1.35 show sndcp

#### Command

```
show sndcp
```

#### Parameters

show

Show running system information

sndcp

Display information about the SNDTCP protocol

### 1.1.36 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values

### 1.1.37 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.1.38 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

### 1.1.39 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.1.40 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.1.41 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---

### 1.1.42 who

#### Command

```
who
```

#### Parameters

who

Display who is on vty

## 1.2

### 1.2.1 bssgp bvc nsei <0-65535> bvci <0-65535> reset

#### Command

```
bssgp bvc nsei <0-65535> bvci <0-65535> reset
```

#### Parameters

bssgp

Initiate BVC RESET procedure for a given NSEI and BVCI

bvc

Filter based on BSSGP Virtual Connection

nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

reset

Perform reset procedure

### 1.2.2 configure terminal

#### Command

```
configure terminal
```

#### Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

### 1.2.3 copy running-config startup-config

#### Command

```
copy running-config startup-config
```

#### Parameters

##### copy

Copy configuration

##### running-config

Copy running config to...

##### startup-config

Copy running config to startup config (same as write file)

### 1.2.4 disable

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

### 1.2.5 echo .MESSAGE

#### Command

```
echo .MESSAGE
```

#### Parameters

##### echo

Echo a message back to the vty

##### .MESSAGE

The message to echo

### 1.2.6 exit

#### Command

```
exit
```

#### Parameters

##### exit

Exit current mode and down to previous mode

---

### 1.2.7 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.2.8 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.2.9 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

logging

Configure log message to this terminal

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.10 logging disable

#### Command

```
logging disable
```

#### Parameters

logging

Configure log message to this terminal

disable

Disables logging to this vty

---



### 1.2.11 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure log message to this terminal

##### enable

Enables logging to this vty

### 1.2.12 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.2.13 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

---

**logging**

Configure log message to this terminal

**filter**

Filter log messages

**bvc**

Filter based on BSSGP Virtual Connection

**nsei**

NSEI of the BVC to be filtered

**<0-65535>**

Network Service Entity Identifier (NSEI)

**bvci**

BVCI of the BVC to be filtered

**<0-65535>**

BSSGP Virtual Connection Identifier (BVCI)

### 1.2.14 logging filter nsvc (nsei|nsvci) <0-65535>

**Command**

```
logging filter nsvc (nsei|nsvci) <0-65535>
```

**Parameters****logging**

Configure log message to this terminal

**filter**

Filter log messages

**nsvc**

Filter based on NS Virtual Connection

**nsei**

Identify NS-VC by NSEI

**nsvci**

Identify NS-VC by NSVCI

**<0-65535>**

Numeric identifier

---

## 1.2.15 logging level (all|mm|pag|meas|ref|gprs|ns|bssgp|llc|sndcp|slhc|ranap|sua|v42bis...

### Command

```
logging level (all|mm|pag|meas|ref|gprs|ns|bssgp|llc|sndcp|slhc|ranap|sua|v42bis| ↵
              lglobal|llapd|linp|lmux|lmi|lmib|lms|lctrl|lgtp|lstats) (everything|debug|info| ↵
              notice|error|fatal)
```

### Parameters

#### logging

Configure log message to this terminal

#### level

Set the log level for a specified category

#### all

Global setting for all subsystems

#### mm

Layer3 Mobility Management (MM)

#### pag

Paging Subsystem

#### meas

Radio Measurement Processing

#### ref

Reference Counting

#### gprs

GPRS Packet Service

#### ns

GPRS Network Service (NS)

#### bssgp

GPRS BSS Gateway Protocol (BSSGP)

#### llc

GPRS Logical Link Control Protocol (LLC)

#### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

#### slhc

RFC1144 TCP/IP Header compression (SLHC)

#### ranap

RAN Application Part (RANAP)

#### sua

SCCP User Adaptation (SUA)

---

v42bis  
V.42bis data compression (SNDTCP)

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

everything  
Don't use. It doesn't log anything

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.2.16 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.2.17 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.18 logging set log mask MASK

#### Command

```
logging set log mask MASK
```

#### Parameters

##### logging

Configure log message to this terminal

##### set

Decide which categories to output.

##### log

Log commands

##### mask

Mask commands

##### MASK

The logmask to use

### 1.2.19 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure log message to this terminal

##### set-log-mask

Set the logmask of this logging target

##### MASK

The logmask to use

### 1.2.20 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

---

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.21 nsvc (nsei|nsvci) <0-65535> (block|unblock|reset)

Command

```
nsvc (nsei|nsvci) <0-65535> (block|unblock|reset)
```

Parameters

nsvc

Perform an operation on a NSVC

nsei

NSEI to identify NS-VC Identifier (NS-VCI)

nsvci

NS-VC Identifier (NS-VCI)

<0-65535>

The NSEI

block

Initiate BLOCK procedure

unblock

Initiate UNBLOCK procedure

reset

Initiate RESET procedure

### 1.2.22 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.23 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.2.24 show bssgp

#### Command

```
show bssgp
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

### 1.2.25 show bssgp nsei <0-65535> [stats]

#### Command

```
show bssgp nsei <0-65535> [stats]
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

nsei

Show all BVCs on one NSE

<0-65535>

The NSEI

[stats]

Include Statistics



### 1.2.26 show bssgp stats

#### Command

```
show bssgp stats
```

#### Parameters

##### show

Show running system information

##### bssgp

Show information about the BSSGP protocol

##### stats

Include statistics

### 1.2.27 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.2.28 show llc

#### Command

```
show llc
```

#### Parameters

##### show

Show running system information

##### llc

Display information about the LLC protocol

---

### 1.2.29 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.2.30 show mm-context all [pdp]

#### Command

```
show mm-context all [pdp]
```

#### Parameters

##### show

Show running system information

##### mm-context

MM Context

##### all

All MM Contexts

##### [pdp]

Include PDP Context Information

### 1.2.31 show mm-context imsi IMSI [pdp]

#### Command

```
show mm-context imsi IMSI [pdp]
```

#### Parameters

##### show

Show running system information

##### mm-context

MM Context

---

imsi

Identify by IMSI

IMSI

IMSI of the MM Context

[pdp]

Include PDP Context Information

### 1.2.32 show ns

Command

```
show ns
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

### 1.2.33 show ns (nsei|nsvc) <0-65535> [stats]

Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

### 1.2.34 show ns stats

#### Command

```
show ns stats
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

stats

Include statistics

### 1.2.35 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.2.36 show pdp-context all

#### Command

```
show pdp-context all
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

all

Show everything

### 1.2.37 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.2.38 show sgsn

#### Command

```
show sgsn
```

#### Parameters

show

Show running system information

sgsn

Display information about the SGSN

### 1.2.39 show sndcp

#### Command

```
show sndcp
```

#### Parameters

show

Show running system information

sndcp

Display information about the SNDCCP protocol

### 1.2.40 show startup-config

#### Command

```
show startup-config
```

#### Parameters

show

Show running system information

startup-config

Contentes of startup configuration

### 1.2.41 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values

### 1.2.42 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.2.43 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

### 1.2.44 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.2.45 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.46 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

---

### 1.2.47 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.2.48 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.2.49 update-subscriber imsi IMSI cancel (update-procedure|subscription-withdraw)

#### Command

```
update-subscriber imsi IMSI cancel (update-procedure|subscription-withdraw)
```

#### Parameters

##### update-subscriber

Update subscriber list

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

---



cancel

Cancel (remove) subscriber record

update-procedure

The MS moved to another SGSN

subscription-withdraw

The subscription is no longer valid

### 1.2.50 update-subscriber imsi IMSI create

Command

```
update-subscriber imsi IMSI create
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

create

Create a subscriber entry

### 1.2.51 update-subscriber imsi IMSI destroy

Command

```
update-subscriber imsi IMSI destroy
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

destroy

Destroy a subscriber entry

### 1.2.52 update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC

#### Command

```
update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC
```

#### Parameters

##### update-subscriber

Update subscriber list

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

##### insert

Insert data into the subscriber record

##### auth-triplet

Update authentication triplet

##### <1-5>

Triplet index

##### sres

Set SRES value

##### SRES

SRES value (4 byte) in hex

##### rand

Set RAND value

##### RAND

RAND value (16 byte) in hex

##### kc

Set Kc value

##### KC

Kc value (8 byte) in hex

### 1.2.53 update-subscriber imsi IMSI update-auth-info

#### Command

```
update-subscriber imsi IMSI update-auth-info
```

#### Parameters

##### update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

update-auth-info

Complete the send authentication info procedure

### 1.2.54 update-subscriber imsi IMSI update-location-result (ok|system-failure|data-missi...

Command

```
update-subscriber imsi IMSI update-location-result (ok|system-failure|data-missing| ←  
unexpected-data-value|unknown-subscriber|roaming-not-allowed)
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

update-location-result

Complete the update location procedure

ok

The update location request succeeded

system-failure

Force error code SystemFailure

data-missing

Force error code DataMissing

unexpected-data-value

Force error code UnexpectedDataValue

unknown-subscriber

Force error code UnknownSubscriber

roaming-not-allowed

Force error code RoamingNotAllowed

### 1.2.55 who

#### Command

```
who
```

#### Parameters

who

Display who is on vty

### 1.2.56 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.2.57 write file

#### Command

```
write file
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.2.58 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

---

## 1.2.59 write terminal

### Command

```
write terminal
```

### Parameters

#### write

Write running configuration to memory, network, or terminal

#### terminal

Write to terminal

## 1.3

### 1.3.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

### 1.3.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

##### banner

Set banner

##### motd

Banner for motd

##### file

Banner from a file

##### [FILE]

Filename

---

### 1.3.3 bssgp

#### Command

```
bssgp
```

#### Parameters

bssgp

Configure the GPRS BSS Gateway Protocol

### 1.3.4 ctrl

#### Command

```
ctrl
```

#### Parameters

ctrl

Configure the Control Interface

### 1.3.5 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN 'enable' password string

---

### 1.3.6 enable password LINE

Command

```
enable password LINE
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.3.7 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

### 1.3.8 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

### 1.3.9 help

Command

```
help
```

Parameters

help

Description of the interactive help system

---

### 1.3.10 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.3.11 line vty

#### Command

```
line vty
```

#### Parameters

##### line

Configure a terminal line

##### vty

Virtual terminal

### 1.3.12 list

#### Command

```
list
```

#### Parameters

##### list

Print command list

### 1.3.13 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

##### log

Configure logging sub-system

##### alarms

Logging alarms to osmo\_strrb

##### <2-32700>

Maximum number of messages to log

---



### 1.3.14 log file .FILENAME

#### Command

```
log file .FILENAME
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.3.15 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.3.16 log stderr

#### Command

```
log stderr
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.3.17 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

### 1.3.18 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.3.19 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.3.20 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.3.21 no hostname [HOSTNAME]

Command

```
no hostname [HOSTNAME]
```

Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.3.22 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.3.23 no log file .FILENAME

#### Command

```
no log file .FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.3.24 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.3.25 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.3.26 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.3.27 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

---

### 1.3.28 no stats reporter log

#### Command

```
no stats reporter log
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.3.29 no stats reporter statsd

#### Command

```
no stats reporter statsd
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

### 1.3.30 ns

#### Command

```
ns
```

#### Parameters

ns

Configure the GPRS Network Service

---

### 1.3.31 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

##### password

Assign the terminal connection password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN line password string

### 1.3.32 password LINE

#### Command

```
password LINE
```

#### Parameters

##### password

Assign the terminal connection password

##### LINE

The UNENCRYPTED (cleartext) line password

### 1.3.33 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

### 1.3.34 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

<0-512>

Number of lines of VTY (0 means no line control)

### 1.3.35 sgsn

#### Command

```
sgsn
```

#### Parameters

sgsn

Configure the SGSN

### 1.3.36 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.3.37 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

---



### 1.3.38 stats interval <1-65535>

#### Command

```
stats interval <1-65535>
```

#### Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<1-65535>

Interval in seconds

### 1.3.39 stats reporter log

#### Command

```
stats reporter log
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.3.40 stats reporter statsd

#### Command

```
stats reporter statsd
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

### 1.3.41 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.3.42 write file

#### Command

```
write file
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.3.43 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.3.44 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

---

## 1.4

### 1.4.1 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

### 1.4.2 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

### 1.4.3 help

Command

```
help
```

Parameters

help

Description of the interactive help system

### 1.4.4 list

Command

```
list
```

Parameters

list

Print command list

---

### 1.4.5 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.4.6 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.4.7 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

### 1.4.8 logging filter nsvc (nsei|nsvci) <0-65535>

#### Command

```
logging filter nsvc (nsei|nsvci) <0-65535>
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### nsvc

Filter based on NS Virtual Connection

##### nsei

Identify NS-VC by NSEI

##### nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

## 1.4.9 logging level (all|mm|pag|meas|ref|gprs|ns|bssgp|llc|sndcp|slhc|ranap|sua|v42bis...

### Command

```
logging level (all|mm|pag|meas|ref|gprs|ns|bssgp|llc|sndcp|slhc|ranap|sua|v42bis| ↵  
lglobal|llapd|linp|lmux|lmi|lmib|lms|lctrl|lgtplstats) (everything|debug|info| ↵  
notice|error|fatal)
```

### Parameters

#### logging

Configure log message to this terminal

#### level

Set the log level for a specified category

#### all

Global setting for all subsystems

#### mm

Layer3 Mobility Management (MM)

#### pag

Paging Subsystem

#### meas

Radio Measurement Processing

#### ref

Reference Counting

#### gprs

GPRS Packet Service

#### ns

GPRS Network Service (NS)

#### bssgp

GPRS BSS Gateway Protocol (BSSGP)

#### llc

GPRS Logical Link Control Protocol (LLC)

#### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

#### slhc

RFC1144 TCP/IP Header compression (SLHC)

#### ranap

RAN Application Part (RANAP)

#### sua

SCCP User Adaptation (SUA)

---

v42bis  
V.42bis data compression (SNDCCP)

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

everything  
Don't use. It doesn't log anything

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.4.10 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.4.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn



### 1.4.12 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.4.13 show running-config

#### Command

```
show running-config
```

#### Parameters

##### show

Show running system information

##### running-config

running configuration

### 1.4.14 write

#### Command

```
write
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

---

### 1.4.15 write file

#### Command

```
write file
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### file

Write to configuration file

### 1.4.16 write memory

#### Command

```
write memory
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### memory

Write configuration to the file (same as write file)

### 1.4.17 write terminal

#### Command

```
write terminal
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### terminal

Write to terminal

## 1.5 E1/J1/T1 Configuration Node

This is the configuration for E1/J1/T1/IP configuration for mISDN, DAHDI or IP based connectivity.

---

### 1.5.1 bind A.B.C.D

#### Command

```
bind A.B.C.D
```

#### Parameters

##### bind

Accept VTY telnet connections on local interface

##### A.B.C.D

Local interface IP address (default: 127.0.0.1)

### 1.5.2 end

#### Command

```
end
```

#### Parameters

##### end

End current mode and change to enable mode.

### 1.5.3 exit

#### Command

```
exit
```

#### Parameters

##### exit

Exit current mode and down to previous mode

### 1.5.4 help

#### Command

```
help
```

#### Parameters

##### help

Description of the interactive help system

---

### 1.5.5 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.5.6 login

#### Command

```
login
```

#### Parameters

login

Enable password checking

### 1.5.7 no login

#### Command

```
no login
```

#### Parameters

no

Negate a command or set its defaults

login

Enable password checking

### 1.5.8 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

---

### 1.5.9 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.5.10 write file

#### Command

```
write file
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.5.11 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.5.12 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

---

## 1.6

### 1.6.1 encapsulation framerelay-gre enabled (1|0)

#### Command

```
encapsulation framerelay-gre enabled (1|0)
```

#### Parameters

##### encapsulation

NS encapsulation options

##### framerelay-gre

NS over Frame Relay over GRE Encapsulation

##### enabled

Enable or disable Frame Relay over GRE

1

Enable

0

Disable

### 1.6.2 encapsulation framerelay-gre local-ip A.B.C.D

#### Command

```
encapsulation framerelay-gre local-ip A.B.C.D
```

#### Parameters

##### encapsulation

NS encapsulation options

##### framerelay-gre

NS over Frame Relay over GRE Encapsulation

##### local-ip

Set the IP address on which we listen for NS/FR/GRE

A.B.C.D

IP Address

### 1.6.3 encapsulation udp dscp <0-255>

#### Command

```
encapsulation udp dscp <0-255>
```

#### Parameters

##### encapsulation

NS encapsulation options

##### udp

NS over UDP Encapsulation

##### dscp

Set DSCP/TOS on the UDP socket

##### <0-255>

DSCP Value

### 1.6.4 encapsulation udp local-ip A.B.C.D

#### Command

```
encapsulation udp local-ip A.B.C.D
```

#### Parameters

##### encapsulation

NS encapsulation options

##### udp

NS over UDP Encapsulation

##### local-ip

Set the IP address on which we listen for NS/UDP

##### A.B.C.D

IP Address

### 1.6.5 encapsulation udp local-port <0-65535>

#### Command

```
encapsulation udp local-port <0-65535>
```

#### Parameters

##### encapsulation

NS encapsulation options

udp

NS over UDP Encapsulation

local-port

Set the UDP port on which we listen for NS/UDP

<0-65535>

UDP port number

### 1.6.6 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

### 1.6.7 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

### 1.6.8 help

Command

```
help
```

Parameters

help

Description of the interactive help system

### 1.6.9 list

Command

```
list
```

Parameters

list

Print command list

---



### 1.6.10 no nse <0-65535>

#### Command

```
no nse <0-65535>
```

#### Parameters

no

Delete Persistent NS Entity

nse

Delete Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

### 1.6.11 nse <0-65535> encapsulation (udp|framerelay-gre)

#### Command

```
nse <0-65535> encapsulation (udp|framerelay-gre)
```

#### Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

encapsulation

Encapsulation for NS

udp

UDP/IP Encapsulation

framerelay-gre

Frame-Relay/GRE/IP Encapsulation

### 1.6.12 nse <0-65535> fr-dlci <16-1007>

#### Command

```
nse <0-65535> fr-dlci <16-1007>
```

#### Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

fr-dlci

Frame Relay DLCI

<16-1007>

Frame Relay DLCI Number

### 1.6.13 nse <0-65535> nsvci <0-65534>

Command

```
nse <0-65535> nsvci <0-65534>
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

nsvci

NS Virtual Connection

<0-65534>

NS Virtual Connection ID (NSVCI)

### 1.6.14 nse <0-65535> remote-ip A.B.C.D

Command

```
nse <0-65535> remote-ip A.B.C.D
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

remote-ip

Remote IP Address

A.B.C.D

Remote IP Address

### 1.6.15 nse <0-65535> remote-port <0-65535>

#### Command

```
nse <0-65535> remote-port <0-65535>
```

#### Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

remote-port

Remote UDP Port

<0-65535>

Remote UDP Port Number

### 1.6.16 nse <0-65535> remote-role (sgsn|bss)

#### Command

```
nse <0-65535> remote-role (sgsn|bss)
```

#### Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

remote-role

Remote NSE Role

sgsn

Remote Peer is SGSN

bss

Remote Peer is BSS

### 1.6.17 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

## 1.6.18 timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-aliv...

### Command

```
timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-alive|tns- ↵  
alive-retries) <0-65535>
```

### Parameters

#### timer

Network Service Timer

#### tns-block

(un)blocking Timer (Tns-block) timeout

#### tns-block-retries

(un)blocking Timer (Tns-block) number of retries

#### tns-reset

Reset Timer (Tns-reset) timeout

#### tns-reset-retries

Reset Timer (Tns-reset) number of retries

#### tns-test

Test Timer (Tns-test) timeout

#### tns-alive

Alive Timer (Tns-alive) timeout

#### tns-alive-retries

Alive Timer (Tns-alive) number of retries

#### <0-65535>

Timer Value

## 1.6.19 write

### Command

```
write
```

### Parameters

#### write

Write running configuration to memory, network, or terminal

### 1.6.20 write file

#### Command

```
write file
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### file

Write to configuration file

### 1.6.21 write memory

#### Command

```
write memory
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### memory

Write configuration to the file (same as write file)

### 1.6.22 write terminal

#### Command

```
write terminal
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### terminal

Write to terminal

## 1.7

### 1.7.1 end

#### Command

```
end
```

#### Parameters

##### end

End current mode and change to enable mode.

---

### 1.7.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.7.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.7.4 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.7.5 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

---

### 1.7.6 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.7.7 write file

#### Command

```
write file
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.7.8 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.7.9 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

---

## 1.8

### 1.8.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

bind

Set bind address to listen for Control connections

A.B.C.D

Local IP address (default 127.0.0.1)

## 1.9 SGSN Configuration Node

Configure the remote GGSN, access-control and other attributes of the SGSN

### 1.9.1 access-point-name NAME

Globally allow the given APN name for all subscribers.

Command

```
access-point-name NAME
```

Parameters

access-point-name

Configure a global list of allowed APNs

NAME

Add this NAME to the list

### 1.9.2 access-point-name NAME

Globally allow the given APN name for all subscribers.

Command

```
access-point-name NAME
```

Parameters

---



### 1.9.3 apn APNAME ggsn <0-255>

Map the given APN Name to the given GGSN number.

Command

```
apn APNAME ggsn <0-255>
```

Parameters

apn

Configure the information per APN

APNAME

The APN gateway name optionally prefixed by '\*' (wildcard)

ggsn

Select the GGSN to use when the APN gateway prefix matches

<0-255>

The GGSN id

### 1.9.4 apn APNAME ggsn <0-255>

Map the given APN Name to the given GGSN number.

Command

```
apn APNAME ggsn <0-255>
```

Parameters

### 1.9.5 apn APNAME imsi-prefix IMSIPRE ggsn <0-255>

Command

```
apn APNAME imsi-prefix IMSIPRE ggsn <0-255>
```

Parameters

apn

Configure the information per APN

APNAME

The APN gateway name optionally prefixed by '\*' (wildcard)

imsi-prefix

Restrict rule to a certain IMSI prefix

IMSIPRE

An IMSI prefix

ggsn

Select the GGSN to use when APN gateway and IMSI prefix match

<0-255>

The GGSN id

### 1.9.6 apn APNAME imsi-prefix IMSIPRE ggsn <0-255>

Map the given APN Name to the given GGSN number `_only_` if the IMSI matches the given prefix.

#### Command

```
apn APNAME imsi-prefix IMSIPRE ggsn <0-255>
```

#### Parameters

### 1.9.7 auth-policy (accept-all|closed|acl-only|remote)

Configure the Authorization policy of the SGSN. This setting determines which subscribers are permitted to register to the network.

#### Command

```
auth-policy (accept-all|closed|acl-only|remote)
```

#### Parameters

##### auth-policy

Authorization Policy of SGSN

##### accept-all

Accept all IMSIs (DANGEROUS)

##### closed

Accept only home network subscribers or those in the ACL

##### acl-only

Accept only subscribers in the ACL

##### remote

Use remote subscription data only (HLR)

### 1.9.8 auth-policy (accept-all|closed|acl-only|remote)

Configure the Authorization policy of the SGSN. This setting determines which subscribers are permitted to register to the network.

#### Command

```
auth-policy (accept-all|closed|acl-only|remote)
```

#### Parameters

---

### 1.9.9 cdr filename NAME

Set the file name for the call-data-record file, logging the data usage of each subscriber.

#### Command

```
cdr filename NAME
```

#### Parameters

cdr

CDR

filename

Set filename

NAME

name

### 1.9.10 cdr filename NAME

Set the file name for the call-data-record file, logging the data usage of each subscriber.

#### Command

```
cdr filename NAME
```

#### Parameters

### 1.9.11 cdr interval <1-2147483647>

Set the interval (in seconds) for the call-data-record file.

#### Command

```
cdr interval <1-2147483647>
```

#### Parameters

cdr

CDR

interval

PDP periodic log interval

<1-2147483647>

Seconds

---

### 1.9.12 cdr interval <1-2147483647>

Set the interval (in seconds) for the call-data-record file.

#### Command

```
cdr interval <1-2147483647>
```

#### Parameters

### 1.9.13 compression rfc1144 active slots <1-256>

#### Command

```
compression rfc1144 active slots <1-256>
```

#### Parameters

##### compression

Configure compression

##### rfc1144

RFC1144 Header compression scheme

##### active

Compression is actively proposed

##### slots

Number of compression state slots

##### <1-256>

Number of compression state slots

### 1.9.14 compression rfc1144 passive

#### Command

```
compression rfc1144 passive
```

#### Parameters

##### compression

Configure compression

##### rfc1144

RFC1144 Header compression scheme

##### passive

Compression is available on request

### 1.9.15 compression v42bis active direction (ms|sgsn|both) codewords <512-65535> strlen ...

#### Command

```
compression v42bis active direction (ms|sgsn|both) codewords <512-65535> strlen <6-250>
```

#### Parameters

##### compression

Configure compression

##### v42bis

V.42bis data compression scheme

##### active

Compression is actively proposed

##### direction

Direction in which the compression shall be active (p0)

##### ms

Compress ms->sgsn direction only

##### sgsn

Compress sgsn->ms direction only

##### both

Both directions

##### codewords

Number of codewords (p1)

##### <512-65535>

Number of codewords

##### strlen

Maximum string length (p2)

##### <6-250>

Maximum string length

### 1.9.16 compression v42bis passive

#### Command

```
compression v42bis passive
```

#### Parameters

##### compression

Configure compression

##### v42bis

V.42bis data compression scheme

##### passive

Compression is available on request

### 1.9.17 encryption (GEA0|GEA1|GEA2|GEA3|GEA4)

#### Command

```
encryption (GEA0|GEA1|GEA2|GEA3|GEA4)
```

#### Parameters

##### encryption

Set encryption algorithm for SGSN

##### GEA0

Use GEA0 (no encryption)

##### GEA1

Use GEA1

##### GEA2

Use GEA2

##### GEA3

Use GEA3

##### GEA4

Use GEA4

### 1.9.18 end

#### Command

```
end
```

#### Parameters

##### end

End current mode and change to enable mode.

### 1.9.19 exit

#### Command

```
exit
```

#### Parameters

##### exit

Exit current mode and down to previous mode

---

### 1.9.20 ggsn <0-255> gtp-version (0|1)

Configure whether to use GTPv0 or GTPv1 towards the specified GGSN number.

Command

```
ggsn <0-255> gtp-version (0|1)
```

Parameters

ggsn

Configure the GGSN information

<0-255>

GGSN Number

gtp-version

GTP Version

0

Version 0

1

Version 1

### 1.9.21 ggsn <0-255> gtp-version (0|1)

Configure whether to use GTPv0 or GTPv1 towards the specified GGSN number.

Command

```
ggsn <0-255> gtp-version (0|1)
```

Parameters

### 1.9.22 ggsn <0-255> remote-ip A.B.C.D

Configure a static GGSN with a given numeric identifier to use the specified remote IP address.

Command

```
ggsn <0-255> remote-ip A.B.C.D
```

Parameters

ggsn

Configure the GGSN information

<0-255>

GGSN Number

remote-ip

IP information

A.B.C.D

IPv4 Address

### 1.9.23 ggsn <0-255> remote-ip A.B.C.D

Configure a static GGSN with a given numeric identifier to use the specified remote IP address.

Command

```
ggsn <0-255> remote-ip A.B.C.D
```

Parameters

### 1.9.24 ggsn dynamic

Enable dynamic resolving of GGSNs based on DNS resolving the APN name like in a GRX-style setup. Changing this setting requires a re-start of the SGSN.

Command

```
ggsn dynamic
```

Parameters

ggsn

Configure the GGSN information

dynamic

Enable dynamic GRX based look-up (requires restart)

### 1.9.25 ggsn dynamic

Enable dynamic resolving of GGSNs based on DNS resolving the APN name like in a GRX-style setup. Changing this setting requires a re-start of the SGSN.

Command

```
ggsn dynamic
```

Parameters

### 1.9.26 grx-dns-add A.B.C.D

Use the specified IP address for DNS-resolving the AP names to GGSN IP addresses

Command

```
grx-dns-add A.B.C.D
```

Parameters

grx-dns-add

Add DNS server

A.B.C.D

IPv4 address



### 1.9.27 grx-dns-add A.B.C.D

Use the specified IP address for DNS-resolving the AP names to GGSN IP addresses

Command

```
grx-dns-add A.B.C.D
```

Parameters

### 1.9.28 gsup oap-id <0-65535>

Set the OAP client ID for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup oap-id <0-65535>
```

Parameters

gsup

GSUP Parameters

oap-id

Set the SGSN's OAP client ID

<0-65535>

OAP client ID (0 == disabled)

### 1.9.29 gsup oap-id <0-65535>

Set the OAP client ID for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup oap-id <0-65535>
```

Parameters

### 1.9.30 gsup oap-k K

Set the OAP shared secret key K for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup oap-k K
```

Parameters

gsup

GSUP Parameters

oap-k

Set the OAP shared secret K

K

K value (16 byte) hex

---

### 1.9.31 gsup oap-k K

Set the OAP shared secret key K for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup oap-k K
```

Parameters

### 1.9.32 gsup oap-opc OPC

Set the OAP shared secret OPC for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup oap-opc OPC
```

Parameters

gsup

GSUP Parameters

oap-opc

Set the OAP shared secret OPC

OPC

OPC value (16 byte) hex

### 1.9.33 gsup oap-opc OPC

Set the OAP shared secret OPC for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup oap-opc OPC
```

Parameters

### 1.9.34 gsup remote-ip A.B.C.D

Set the IP address of the HLR (gateway) for the GSUP protocol. This setting only applies if auth-policy remote is used.

Command

```
gsup remote-ip A.B.C.D
```

Parameters

gsup

GSUP Parameters

remote-ip

Set the IP address of the remote GSUP server

A.B.C.D

IPv4 Address

### 1.9.35 gsup remote-ip A.B.C.D

Set the IP address of the HLR (gateway) for the GSUP protocol. This setting only applies if auth-policy remote is used.

#### Command

```
gsup remote-ip A.B.C.D
```

#### Parameters

### 1.9.36 gsup remote-port <0-65535>

#### Command

```
gsup remote-port <0-65535>
```

#### Parameters

##### gsup

GSUP Parameters

##### remote-port

Set the TCP port of the remote GSUP server

##### <0-65535>

Remote TCP port

### 1.9.37 gtp local-ip A.B.C.D

Configure the local IP address to which the SGSN should bind for the Gp interface (towards the GGSNs). Please note that in case you would like to run the GGSN on the same machine as the SGSN, you can not run both on the same IP address. It is suggested to use 127.0.0.1 for the SGSN and 127.0.0.2 for the GGSN in such situations.

#### Command

```
gtp local-ip A.B.C.D
```

#### Parameters

##### gtp

GTP Parameters

##### local-ip

Set the IP address for the local GTP bind

##### A.B.C.D

IPv4 Address

---

### 1.9.38 gtp local-ip A.B.C.D

Configure the local IP address to which the SGSN should bind for the Gp interface (towards the GGSNs). Please note that in case you would like to run the GGSN on the same machine as the SGSN, you can not run both on the same IP address. It is suggested to use 127.0.0.1 for the SGSN and 127.0.0.2 for the GGSN in such situations.

Command

```
gtp local-ip A.B.C.D
```

Parameters

### 1.9.39 help

Command

```
help
```

Parameters

help

Description of the interactive help system

### 1.9.40 imsi-acl (add|del) IMSI

Add or delete the given IMSI to/from the global Access Control List.

Command

```
imsi-acl (add|del) IMSI
```

Parameters

imsi-acl

Access Control List of foreign IMSIs

add

Add IMSI to ACL

del

Remove IMSI from ACL

IMSI

IMSI of subscriber

### 1.9.41 imsi-acl (add|del) IMSI

Add or delete the given IMSI to/from the global Access Control List.

Command

```
imsi-acl (add|del) IMSI
```

Parameters

---

### 1.9.42 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.9.43 no access-point-name NAME

#### Command

```
no access-point-name NAME
```

#### Parameters

no

Negate a command or set its defaults

access-point-name

Configure a global list of allowed APNs

NAME

Remove entry with NAME

### 1.9.44 no cdr filename

#### Command

```
no cdr filename
```

#### Parameters

no

Negate a command or set its defaults

cdr

CDR

filename

Disable CDR generation

### 1.9.45 no compression rfc1144

#### Command

```
no compression rfc1144
```

#### Parameters

no

Negate a command or set its defaults

compression

Configure compression

rfc1144

disable rfc1144 TCP/IP header compression

### 1.9.46 no compression v42bis

#### Command

```
no compression v42bis
```

#### Parameters

no

Negate a command or set its defaults

compression

Configure compression

v42bis

disable V.42bis data compression

### 1.9.47 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.9.48 timer t3312 <0-65535>

#### Command

```
timer t3312 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3312

Periodic RA Update timer (s)

<0-65535>

Timer Value in seconds

### 1.9.49 timer t3313 <0-65535>

#### Command

```
timer t3313 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3313

Waiting for paging response timer (s)

<0-65535>

Timer Value in seconds

### 1.9.50 timer t3314 <0-65535>

#### Command

```
timer t3314 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3314

Force to STANDBY on expiry timer (s)

<0-65535>

Timer Value in seconds

### 1.9.51 timer t3316 <0-65535>

#### Command

```
timer t3316 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3316

AA-Ready timer (s)

<0-65535>

Timer Value in seconds

### 1.9.52 timer t3322 <0-65535>

#### Command

```
timer t3322 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3322

Detach request -> accept timer (s)

<0-65535>

Timer Value in seconds

### 1.9.53 timer t3350 <0-65535>

#### Command

```
timer t3350 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3350

Waiting for ATT/RAU/TMSI\_COMPL timer (s)

<0-65535>

Timer Value in seconds

---



### 1.9.54 timer t3360 <0-65535>

#### Command

```
timer t3360 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3360

Waiting for AUTH/CIPH response timer (s)

<0-65535>

Timer Value in seconds

### 1.9.55 timer t3370 <0-65535>

#### Command

```
timer t3370 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3370

Waiting for IDENTITY response timer (s)

<0-65535>

Timer Value in seconds

### 1.9.56 timer t3385 <0-65535>

#### Command

```
timer t3385 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3385

Wait for ACT PDP CTX REQ timer (s)

<0-65535>

Timer Value in seconds

### 1.9.57 timer t3386 <0-65535>

#### Command

```
timer t3386 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3386

Wait for MODIFY PDP CTX ACK timer (s)

<0-65535>

Timer Value in seconds

### 1.9.58 timer t3395 <0-65535>

#### Command

```
timer t3395 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3395

Wait for DEACT PDP CTX ACK timer (s)

<0-65535>

Timer Value in seconds

### 1.9.59 timer t3397 <0-65535>

#### Command

```
timer t3397 <0-65535>
```

#### Parameters

timer

Configure GPRS Timers

t3397

Wait for DEACT AA PDP CTX ACK timer (s)

<0-65535>

Timer Value in seconds

### 1.9.60 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

### 1.9.61 write file

Command

```
write file
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.9.62 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.9.63 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal