

# OsmoHLR VTY Reference

---

Copyright © 2017

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

---

**COLLABORATORS**

	<i>TITLE :</i> OsmoHLR VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		May 17, 2021	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v1	18th September 2017	Initial	nh

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list [with-flags]	2
1.1.5	show running-config	3
1.1.6	show vty-attributes	3
1.1.7	show vty-attributes (application library global)	3
1.1.8	write	4
1.1.9	write file [PATH]	4
1.1.10	write memory	4
1.1.11	write terminal	4
1.2	view	5
1.2.1	enable [expert-mode]	5
1.2.2	logging color (0 1)	5
1.2.3	logging disable	5
1.2.4	logging enable	6
1.2.5	logging filter all (0 1)	6
1.2.6	logging level (main db acl ssl mslookup lul dgsml global lapd linp mux mill mibl...	6
1.2.7	logging level force-all (debug info notice error fatal)	9
1.2.8	logging level set-all (debug info notice error fatal)	9
1.2.9	logging print category (0 1)	10
1.2.10	logging print category-hex (0 1)	10
1.2.11	logging print extended-timestamp (0 1)	11
1.2.12	logging print file (0 1 basename) [last]	11
1.2.13	logging print level (0 1)	12
1.2.14	logging print thread-id (0 1)	12
1.2.15	logging set-log-mask MASK	13
1.2.16	logging timestamp (0 1)	13

1.2.17	logp (mainldb lauc ss ms lookup pl ldg sm l global ll apd lin pl mux ll mill mibl ms lctr...	13
1.2.18	no logging level force-all	16
1.2.19	show alarms	16
1.2.20	show asciidoc counters	16
1.2.21	show cpu-sched threads	17
1.2.22	show gsup-connections	17
1.2.23	show history	17
1.2.24	show logging vty	18
1.2.25	show mslookup services	18
1.2.26	show online-help	18
1.2.27	show rate-counters	19
1.2.28	show stats	19
1.2.29	show stats level (global peer subscriber)	19
1.2.30	show subscriber (ims lms isd nl d lmei) IDENT	20
1.2.31	show subscribers (cs ps) (on off)	20
1.2.32	show subscribers (ime ilms lms isd n) FILTER	21
1.2.33	show subscribers all	21
1.2.34	show subscribers last-seen	21
1.2.35	show talloc-context (application all) (full brief DEPTH)	22
1.2.36	show talloc-context (application all) (full brief DEPTH) filter REGEXP	22
1.2.37	show talloc-context (application all) (full brief DEPTH) tree ADDRESS	23
1.2.38	show version	24
1.2.39	subscriber (ims lms isd nl d lmei) IDENT show	24
1.2.40	terminal length <0-512>	24
1.2.41	terminal no length	25
1.2.42	who	25
1.3	enable	25
1.3.1	configure terminal	25
1.3.2	copy running-config startup-config	26
1.3.3	disable	26
1.3.4	logging color (0 1)	26
1.3.5	logging disable	27
1.3.6	logging enable	27
1.3.7	logging filter all (0 1)	27
1.3.8	logging level (mainldb lauc ss ms lookup pl ldg sm l global ll apd lin pl mux ll mill mibl...	28
1.3.9	logging level force-all (debug info notice error fatal)	30
1.3.10	logging level set-all (debug info notice error fatal)	30
1.3.11	logging print category (0 1)	31
1.3.12	logging print category-hex (0 1)	31

1.3.13	logging print extended-timestamp (01)	32
1.3.14	logging print file (01 basename) [last]	32
1.3.15	logging print level (01)	33
1.3.16	logging print thread-id (01)	33
1.3.17	logging set-log-mask MASK	34
1.3.18	logging timestamp (01)	34
1.3.19	logp (main db acl ssl ms lookup l uld g sm l global l lapd lin pl mux l mi l mi bl s ms l ctr...	35
1.3.20	no logging level force-all	37
1.3.21	show alarms	37
1.3.22	show asciidoc counters	38
1.3.23	show cpu-sched threads	38
1.3.24	show gsup-connections	38
1.3.25	show history	39
1.3.26	show logging vty	39
1.3.27	show mslookup services	39
1.3.28	show online-help	40
1.3.29	show rate-counters	40
1.3.30	show startup-config	40
1.3.31	show stats	40
1.3.32	show stats level (global peer subscriber)	41
1.3.33	show subscriber (ims l ms isd n l d l ime ) IDENT	41
1.3.34	show subscribers (cs ps) (on off)	42
1.3.35	show subscribers (ime l ms isd n) FILTER	42
1.3.36	show subscribers all	43
1.3.37	show subscribers last-seen	43
1.3.38	show talloc-context (application all) (full brief DEPTH)	43
1.3.39	show talloc-context (application all) (full brief DEPTH) filter REGEXP	44
1.3.40	show talloc-context (application all) (full brief DEPTH) tree ADDRESS	45
1.3.41	show version	45
1.3.42	stats report	46
1.3.43	stats reset	46
1.3.44	subscriber (ims l ms isd n l d l ime ) IDENT delete	46
1.3.45	subscriber (ims l ms isd n l d l ime ) IDENT show	47
1.3.46	subscriber (ims l ms isd n l d l ime ) IDENT update aud2g (comp128v1 comp128v2 comp128...	47
1.3.47	subscriber (ims l ms isd n l d l ime ) IDENT update aud2g none	48
1.3.48	subscriber (ims l ms isd n l d l ime ) IDENT update aud3g milenage k K (op opc) OP_C [...	49
1.3.49	subscriber (ims l ms isd n l d l ime ) IDENT update aud3g none	50
1.3.50	subscriber (ims l ms isd n l d l ime ) IDENT update aud3g xor k K [ind-bitlen] [<0-28>...	50
1.3.51	subscriber (ims l ms isd n l d l ime ) IDENT update imei (none IMEI)	51

1.3.52	subscriber (imsilmsisdnlidlimei) IDENT update msisdn (none MSISDN)	52
1.3.53	subscriber (imsilmsisdnlidlimei) IDENT update network-access-mode (none cs ps cs...	53
1.3.54	subscriber imsi IDENT create	53
1.3.55	terminal length <0-512>	54
1.3.56	terminal monitor	54
1.3.57	terminal no length	54
1.3.58	terminal no monitor	55
1.3.59	who	55
1.4	config	55
1.4.1	banner motd default	55
1.4.2	banner motd file [FILE]	56
1.4.3	cpu-sched	56
1.4.4	ctrl	56
1.4.5	enable password (8l) WORD	57
1.4.6	enable password LINE	57
1.4.7	hlr	57
1.4.8	hostname WORD	58
1.4.9	line vty	58
1.4.10	log alarms <2-32700>	58
1.4.11	log file .FILENAME	59
1.4.12	log gsmtap [HOSTNAME]	59
1.4.13	log stderr	59
1.4.14	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	60
1.4.15	log syslog local <0-7>	60
1.4.16	log systemd-journal [raw]	61
1.4.17	mslookup	61
1.4.18	no banner motd	61
1.4.19	no enable password	62
1.4.20	no hostname [HOSTNAME]	62
1.4.21	no log alarms	62
1.4.22	no log file .FILENAME	63
1.4.23	no log stderr	63
1.4.24	no log syslog	63
1.4.25	no log systemd-journal	64
1.4.26	no service advanced-vty	64
1.4.27	no service terminal-length [<0-512>]	64
1.4.28	no stats reporter log	65
1.4.29	no stats reporter statsd	65
1.4.30	password (8l) WORD	65

---

1.4.31	password LINE . . . . .	66
1.4.32	service advanced-vty . . . . .	66
1.4.33	service terminal-length <0-512> . . . . .	66
1.4.34	show history . . . . .	67
1.4.35	stats interval <0-65535> . . . . .	67
1.4.36	stats reporter log . . . . .	67
1.4.37	stats reporter statsd . . . . .	68
1.5	config-log . . . . .	68
1.5.1	logging color (01) . . . . .	68
1.5.2	logging filter all (01) . . . . .	69
1.5.3	logging level (main db auc ss lms lookup pl uld gsm l global llap dl in pl mux l mill mb l... . . . .	69
1.5.4	logging level force-all (debug info notice error fatal) . . . . .	71
1.5.5	logging level set-all (debug info notice error fatal) . . . . .	72
1.5.6	logging print category (01) . . . . .	73
1.5.7	logging print category-hex (01) . . . . .	73
1.5.8	logging print extended-timestamp (01) . . . . .	74
1.5.9	logging print file (01 basename) [last] . . . . .	74
1.5.10	logging print level (01) . . . . .	75
1.5.11	logging print thread-id (01) . . . . .	75
1.5.12	logging timestamp (01) . . . . .	76
1.5.13	no logging level force-all . . . . .	76
1.6	config-stats . . . . .	76
1.6.1	disable . . . . .	76
1.6.2	enable . . . . .	77
1.6.3	flush-period <0-65535> . . . . .	77
1.6.4	level (global peer subscriber) . . . . .	77
1.6.5	local-ip ADDR . . . . .	78
1.6.6	mtu <100-65535> . . . . .	78
1.6.7	no local-ip . . . . .	78
1.6.8	no mtu . . . . .	78
1.6.9	no prefix . . . . .	79
1.6.10	prefix PREFIX . . . . .	79
1.6.11	remote-ip ADDR . . . . .	79
1.6.12	remote-port <1-65535> . . . . .	79
1.7	config-line . . . . .	80
1.7.1	bind A.B.C.D [<0-65535>] . . . . .	80
1.7.2	login . . . . .	80
1.7.3	no login . . . . .	80
1.8	config-ctrl . . . . .	81



---

1.8.1	bind A.B.C.D . . . . .	81
1.9	config-cpu-sched . . . . .	81
1.9.1	cpu-affinity (self all <0-4294967295> THREADNAME) CPUHEXMASK [delay] . . . . .	81
1.9.2	policy rr <1-32> . . . . .	82
1.10	config-hlr . . . . .	82
1.10.1	database PATH . . . . .	82
1.10.2	euse NAME . . . . .	82
1.10.3	gsup . . . . .	83
1.10.4	ncss-guard-timeout <0-255> . . . . .	83
1.10.5	no euse NAME . . . . .	83
1.10.6	no store-imei . . . . .	83
1.10.7	no subscriber-create-on-demand . . . . .	84
1.10.8	no ussd default-route . . . . .	84
1.10.9	no ussd route prefix PREFIX . . . . .	84
1.10.10	store-imei . . . . .	85
1.10.11	subscriber-create-on-demand (no-msisdnl<3-15>) (nonelcslpslcs+ps) . . . . .	85
1.10.12	ussd default-route external EUSE . . . . .	85
1.10.13	ussd route prefix PREFIX external EUSE . . . . .	86
1.10.14	ussd route prefix PREFIX internal (own-msisdnlown-imsiltest-idle) . . . . .	86
1.11	config-hlr-gsup . . . . .	87
1.11.1	bind ip A.B.C.D . . . . .	87
1.11.2	ipa-name NAME . . . . .	87
1.12	config-hlr-euse . . . . .	88
1.13	config-mslookup . . . . .	88
1.13.1	client . . . . .	88
1.13.2	mdns bind [IP] [<1-65535>] . . . . .	88
1.13.3	mdns domain-suffix DOMAIN_SUFFIX . . . . .	88
1.13.4	no client . . . . .	89
1.13.5	no mdns bind . . . . .	89
1.13.6	no server . . . . .	89
1.13.7	server . . . . .	90
1.14	config-mslookup-server . . . . .	90
1.14.1	mdns bind [IP] [<1-65535>] . . . . .	90
1.14.2	mdns domain-suffix DOMAIN_SUFFIX . . . . .	90
1.14.3	msc ipa-name .IPA_NAME . . . . .	91
1.14.4	no mdns bind . . . . .	91
1.14.5	no service NAME . . . . .	91
1.14.6	no service NAME at IP <1-65535> . . . . .	92
1.14.7	service NAME at IP <1-65535> . . . . .	92

---

---

1.15	config-mslookup-server-msc	93
1.15.1	no service NAME	93
1.15.2	no service NAME at IP <1-65535>	93
1.15.3	service NAME at IP <1-65535>	94
1.16	config-mslookup-client	94
1.16.1	gateway-proxy IP [<1-65535>]	94
1.16.2	mdns bind [IP] [<1-65535>]	94
1.16.3	mdns domain-suffix DOMAIN_SUFFIX	95
1.16.4	no gateway-proxy	95
1.16.5	no mdns bind	96
1.16.6	timeout <1-100000>	96

---

# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

---

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sismocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list [with-flags]

#### Command

```
list [with-flags]
```

#### Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

---

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.1.6 show vty-attributes

#### Command

```
show vty-attributes
```

#### Parameters

show

Show running system information

vtty-attributes

List of VTY attributes

### 1.1.7 show vty-attributes (application|library|global)

#### Command

```
show vty-attributes (application|library|global)
```

#### Parameters

show

Show running system information

vtty-attributes

List of VTY attributes

application

Application specific attributes only

library

Library specific attributes only

global

Global attributes only

---

### 1.1.8 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

### 1.1.9 write file [PATH]

Command

```
write file [PATH]
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

### 1.1.10 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.1.11 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable [expert-mode]

#### Command

```
enable [expert-mode]
```

#### Parameters

enable

Turn on privileged mode command

[expert-mode]

Enable the expert mode (show hidden commands)

### 1.2.2 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.3 logging disable

#### Command

```
logging disable
```

#### Parameters

logging

Configure logging

disable

Disables logging to this vty



## 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

### Command

```
logging enable
```

### Parameters

#### logging

Configure logging

#### enable

Enables logging to this vty

## 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

### Command

```
logging filter all (0|1)
```

### Parameters

#### logging

Configure logging

#### filter

Filter log messages

#### all

Do you want to log all messages?

#### 0

Only print messages matched by other filters

#### 1

Bypass filter and print all messages

## 1.2.6 logging level (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|...

### Command

```
logging level (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|lsms| ←
lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbsgpp| ←
lnsdata|lnssignal) (debug|info|notice|error|fatal)
```

---

Parameters

logging

Configure logging

level

Set the log level for a specified category

main

Main Program

db

Database Layer

auc

Authentication Center

ss

Supplementary Services

mslookup

Mobile Subscriber Lookup

lu

Location Updating

dgsm

Distributed GSM: MS lookup and proxy

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats

Statistics messages and logging

---

---

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

## 1.2.7 logging level force-all (debug|info|notice|error|fatal)

### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

### Parameters

#### logging

Configure logging

#### level

Set the log level for a specified category

#### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

#### debug

Log debug messages and higher levels

#### info

Log informational messages and higher levels

#### notice

Log noticeable messages and higher levels

#### error

Log error messages and higher levels

#### fatal

Log only fatal messages

## 1.2.8 logging level set-all (debug|info|notice|error|fatal)

### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

### Parameters

#### logging

Configure logging

#### level

Set the log level for a specified category

#### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

#### debug

Log debug messages and higher levels

---

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.9 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.2.10 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

---

### 1.2.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.12 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.13 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.2.14 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.2.15 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.16 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.17 logp (main|db|auc|ss|mslookup|lu|dgsm|lglobal||llapd|linp|lmux|lmi|lmib|lsms|lctr...

#### Command

```
logp (main|db|auc|ss|mslookup|lu|dgsm|lglobal||llapd|linp|lmux|lmi|lmib|lsms|lctr1|lgtp| ←  
lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ←  
lnssignal) (debug|info|notice|error|fatal) .LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs



---

main  
Main Program

db  
Database Layer

auc  
Authentication Center

ss  
Supplementary Services

mslookup  
Mobile Subscriber Lookup

lu  
Location Updating

dgsm  
Distributed GSM: MS lookup and proxy

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

---

---

lss7  
libosmo-sigtran Signalling System 7

lscpp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lndata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

---

### 1.2.18 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.19 show alarms

#### Command

```
show alarms
```

#### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.20 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.2.21 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

##### show

Show running system information

##### cpu-sched

Show Sched section information

##### threads

Show information about running threads)

### 1.2.22 show gsup-connections

#### Command

```
show gsup-connections
```

#### Parameters

##### show

Show running system information

##### gsup-connections

GSUP Connections from VLRs, SGSNs, EUSEs

### 1.2.23 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

---

### 1.2.24 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.2.25 show mslookup services

#### Command

```
show mslookup services
```

#### Parameters

##### show

Show running system information

##### mslookup

Distributed GSM / mslookup related information

##### services

List configured service addresses as sent to remote mslookup requests

### 1.2.26 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.2.27 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

### 1.2.28 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values

### 1.2.29 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

---

### 1.2.30 show subscriber (imsi|msisdn|id|imei) IDENT

#### Command

```
show subscriber (imsi|msisdn|id|imei) IDENT
```

#### Parameters

show

Show running system information

subscriber

Show subscriber information

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

### 1.2.31 show subscribers (cs|ps) (on|off)

#### Command

```
show subscribers (cs|ps) (on|off)
```

#### Parameters

show

Show running system information

subscribers

Show subscriber information

cs

Filter Subscribers by CS Network Access Mode

ps

Filter Subscribers by PS Network Access Mode

on

Authorised

off

Not Authorised

### 1.2.32 show subscribers (imei|imsi|msisdn) FILTER

#### Command

```
show subscribers (imei|imsi|msisdn) FILTER
```

#### Parameters

##### show

Show running system information

##### subscribers

Show all subscribers (with filter possibility)

##### imei

Filter Subscribers by IMEI

##### imsi

Filter Subscribers by IMSI

##### msisdn

Filter Subscribers by MSISDN

##### FILTER

String to match in imei, imsi or msisdn

### 1.2.33 show subscribers all

#### Command

```
show subscribers all
```

#### Parameters

##### show

Show running system information

##### subscribers

Show all subscribers (with filter possibility)

##### all

Show summary of all subscribers

### 1.2.34 show subscribers last-seen

#### Command

```
show subscribers last-seen
```

#### Parameters

---



show

Show running system information

subscribers

Show subscriber information

last-seen

Show Subscribers Ordered by Last Seen Time

### 1.2.35 show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.2.36 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

- application
  - Application's context
- all
  - All contexts, if NULL-context tracking is enabled
- full
  - Display a full talloc memory hierarchy
- brief
  - Display a brief talloc memory hierarchy
- DEPTH
  - Specify required maximal depth value
- filter
  - Filter chunks using regular expression
- REGEXP
  - Regular expression

### 1.2.37 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

- show
  - Show running system information
- talloc-context
  - Show talloc memory hierarchy
- application
  - Application's context
- all
  - All contexts, if NULL-context tracking is enabled
- full
  - Display a full talloc memory hierarchy
- brief
  - Display a brief talloc memory hierarchy
- DEPTH
  - Specify required maximal depth value
- tree
  - Display only a specific memory chunk
- ADDRESS
  - Chunk address (e.g. 0xdeadbeef)

### 1.2.38 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.2.39 subscriber (imsi|msisdn|id|imei) IDENT show

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT show
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### show

Show subscriber information

### 1.2.40 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

---

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

### 1.2.41 terminal no length

Command

```
terminal no length
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

length

Set number of lines on a screen

### 1.2.42 who

Command

```
who
```

Parameters

who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

### 1.3.1 configure terminal

Command

```
configure terminal
```

Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

### 1.3.2 copy running-config startup-config

#### Command

```
copy running-config startup-config
```

#### Parameters

##### copy

Copy configuration

##### running-config

Copy running config to...

##### startup-config

Copy running config to startup config (same as write file)

### 1.3.3 disable

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

### 1.3.4 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

##### 0

Don't use color for printing messages

##### 1

Use color for printing messages

---

### 1.3.5 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.3.8 logging level (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|...

#### Command

```
logging level (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|lsms| ←  
lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp| ←  
lndata|lnsignal) (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### main

Main Program

##### db

Database Layer

##### auc

Authentication Center

##### ss

Supplementary Services

##### mslookup

Mobile Subscriber Lookup

##### lu

Location Updating

##### dgsm

Distributed GSM: MS lookup and proxy

##### lglobal

Library-internal global log family

##### llapd

LAPD in libosmogsm

##### linp

A-bis Input Subsystem

##### lmux

A-bis B-Subchannel TRAU Frame Multiplex

##### lmi

A-bis Input Driver for Signalling

##### lmib

A-bis Input Driver for B-Channels (voice)

---

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lscpp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

---



notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.9 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.10 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.3.11 logging print category (0|1)

**Command**

```
logging print category (0|1)
```

**Parameters****logging**

Configure logging

**print**

Log output settings

**category**

Configure log message

**0**

Don't prefix each log message

**1**

Prefix each log message with category/subsystem name

### 1.3.12 logging print category-hex (0|1)

**Command**

```
logging print category-hex (0|1)
```

**Parameters**

**logging**

Configure logging

**print**

Log output settings

**category-hex**

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.13 logging print extended-timestamp (0|1)

**Command**

```
logging print extended-timestamp (0|1)
```

**Parameters****logging**

Configure logging

**print**

Log output settings

**extended-timestamp**

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.14 logging print file (0|1|basename) [last]

**Command**

```
logging print file (0|1|basename) [last]
```

**Parameters****logging**

Configure logging

**print**

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.15 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.3.16 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.3.17 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.18 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.3.19 logp (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctr...

#### Command

```
logp (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp| ←  
lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ←  
lnssignal) (debug|info|notice|error|fatal) .LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs

##### main

Main Program

##### db

Database Layer

##### auc

Authentication Center

##### ss

Supplementary Services

##### mslookup

Mobile Subscriber Lookup

##### lu

Location Updating

##### dgsm

Distributed GSM: MS lookup and proxy

##### lglobal

Library-internal global log family

##### llapd

LAPD in libosmogsm

##### linp

A-bis Input Subsystem

##### lmux

A-bis B-Subchannel TRAU Frame Multiplex

##### lmi

A-bis Input Driver for Signalling

##### lmib

A-bis Input Driver for B-Channels (voice)

##### lsms

Layer3 Short Message Service (SMS)

---

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

---

error

Log error messages and higher levels

fatal

Log only fatal messages

.LOGMESSAGE

Arbitrary message to log on given category and log level

### 1.3.20 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.21 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration



### 1.3.22 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.3.23 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.3.24 show gsup-connections

#### Command

```
show gsup-connections
```

#### Parameters

show

Show running system information

gsup-connections

GSUP Connections from VLRs, SGSNs, EUSEs

### 1.3.25 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.3.26 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

### 1.3.27 show mslookup services

#### Command

```
show mslookup services
```

#### Parameters

##### show

Show running system information

##### mslookup

Distributed GSM / mslookup related information

##### services

List configured service addresses as sent to remote mslookup requests

### 1.3.28 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.3.29 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

### 1.3.30 show startup-config

#### Command

```
show startup-config
```

#### Parameters

show

Show running system information

startup-config

Contentes of startup configuration

### 1.3.31 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values

### 1.3.32 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.3.33 show subscriber (imsi|msisdn|id|imei) IDENT

#### Command

```
show subscriber (imsi|msisdn|id|imei) IDENT
```

#### Parameters

show

Show running system information

subscriber

Show subscriber information

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

### 1.3.34 show subscribers (cs|ps) (on|off)

#### Command

```
show subscribers (cs|ps) (on|off)
```

#### Parameters

show

Show running system information

subscribers

Show subscriber information

cs

Filter Subscribers by CS Network Access Mode

ps

Filter Subscribers by PS Network Access Mode

on

Authorised

off

Not Authorised

### 1.3.35 show subscribers (imei|imsi|msisdn) FILTER

#### Command

```
show subscribers (imei|imsi|msisdn) FILTER
```

#### Parameters

show

Show running system information

subscribers

Show all subscribers (with filter possibility)

imei

Filter Subscribers by IMEI

imsi

Filter Subscribers by IMSI

msisdn

Filter Subscribers by MSISDN

FILTER

String to match in imei, imsi or msisdn

### 1.3.36 show subscribers all

#### Command

```
show subscribers all
```

#### Parameters

##### show

Show running system information

##### subscribers

Show all subscribers (with filter possibility)

##### all

Show summary of all subscribers

### 1.3.37 show subscribers last-seen

#### Command

```
show subscribers last-seen
```

#### Parameters

##### show

Show running system information

##### subscribers

Show subscriber information

##### last-seen

Show Subscribers Ordered by Last Seen Time

### 1.3.38 show talloc-context (application|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

- all  
All contexts, if NULL-context tracking is enabled
- full  
Display a full talloc memory hierarchy
- brief  
Display a brief talloc memory hierarchy
- DEPTH  
Specify required maximal depth value

### 1.3.39 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

- show  
Show running system information
  - talloc-context  
Show talloc memory hierarchy
  - application  
Application's context
  - all  
All contexts, if NULL-context tracking is enabled
  - full  
Display a full talloc memory hierarchy
  - brief  
Display a brief talloc memory hierarchy
  - DEPTH  
Specify required maximal depth value
  - filter  
Filter chunks using regular expression
  - REGEXP  
Regular expression
-

### 1.3.40 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### tree

Display only a specific memory chunk

##### ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.3.41 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version



### 1.3.42 stats report

#### Command

```
stats report
```

#### Parameters

stats

Stats related commands

report

Manurally trigger reporting of stats

### 1.3.43 stats reset

#### Command

```
stats reset
```

#### Parameters

stats

Stats related commands

reset

Reset all stats

### 1.3.44 subscriber (imsi|msisdn|id|imei) IDENT delete

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT delete
```

#### Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

delete

Delete subscriber from database

### 1.3.45 subscriber (imsi|msisdn|id|imei) IDENT show

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT show
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### show

Show subscriber information

### 1.3.46 subscriber (imsi|msisdn|id|imei) IDENT update aud2g (comp128v1|comp128v2|comp128...

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud2g (comp128v1|comp128v2|comp128v3|xor) ←  
ki KI
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

**IDENT**

IMSI/MSISDN/ID/IMEI of the subscriber

**update**

Set or update subscriber data

**aud2g**

Set 2G authentication data

**comp128v1**

Use COMP128v1 algorithm

**comp128v2**

Use COMP128v2 algorithm

**comp128v3**

Use COMP128v3 algorithm

**xor**

Use XOR algorithm

**ki**

Set Ki Encryption Key

**KI**

Ki as 32 hexadecimal characters

### 1.3.47 subscriber (imsi|msisdn|id|imei) IDENT update aud2g none

**Command**

```
subscriber (imsi|msisdn|id|imei) IDENT update aud2g none
```

**Parameters****subscriber**

Subscriber management commands

**imsi**

Identify subscriber by IMSI

**msisdn**

Identify subscriber by MSISDN (phone number)

**id**

Identify subscriber by database ID

**imei**

Identify subscriber by IMEI

**IDENT**

IMSI/MSISDN/ID/IMEI of the subscriber

**update**

Set or update subscriber data

---

aud2g

Set 2G authentication data

none

Delete 2G authentication data

### 1.3.48 subscriber (imsi|msisdn|id|imei) IDENT update aud3g milenage k K (op|opc) OP\_C [...

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g milenage k K (op|opc) OP_C [ind- ↵  
bitlen] [<0-28>]
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

aud3g

Set UMTS authentication data (3G, and 2G with UMTS AKA)

milenage

Use Milenage algorithm

k

Set Encryption Key K

K

K as 32 hexadecimal characters

op

Set OP key

opc

Set OPC key

**OP\_C**

OP or OPC as 32 hexadecimal characters

**[ind-bitlen]**

Set IND bit length

**[<0-28>]**

IND bit length value (default: 5)

**1.3.49 subscriber (imsi|msisdn|id|imei) IDENT update aud3g none****Command**

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g none
```

**Parameters****subscriber**

Subscriber management commands

**imsi**

Identify subscriber by IMSI

**msisdn**

Identify subscriber by MSISDN (phone number)

**id**

Identify subscriber by database ID

**imei**

Identify subscriber by IMEI

**IDENT**

IMSI/MSISDN/ID/IMEI of the subscriber

**update**

Set or update subscriber data

**aud3g**

Set UMTS authentication data (3G, and 2G with UMTS AKA)

**none**

Delete 3G authentication data

**1.3.50 subscriber (imsi|msisdn|id|imei) IDENT update aud3g xor k K [ind-bitlen] [<0-28>...****Command**

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g xor k K [ind-bitlen] [<0-28>...
```

**Parameters**

**subscriber**

Subscriber management commands

**imsi**

Identify subscriber by IMSI

**msisdn**

Identify subscriber by MSISDN (phone number)

**id**

Identify subscriber by database ID

**imei**

Identify subscriber by IMEI

**IDENT**

IMSI/MSISDN/ID/IMEI of the subscriber

**update**

Set or update subscriber data

**aud3g**

Set UMTS authentication data (3G, and 2G with UMTS AKA)

**xor**

Use XOR algorithm

**k**

Set Encryption Key K

**K**

K as 32 hexadecimal characters

**[ind-bitlen]**

Set IND bit length

**[<0-28>]**

IND bit length value (default: 5)

### 1.3.51 **subscriber (imsi|msisdn|id|imei) IDENT update imei (none|IMEI)**

**Command**

```
subscriber (imsi|msisdn|id|imei) IDENT update imei (none|IMEI)
```

**Parameters****subscriber**

Subscriber management commands

**imsi**

Identify subscriber by IMSI

**msisdn**

Identify subscriber by MSISDN (phone number)

---

**id**  
Identify subscriber by database ID

**imei**  
Identify subscriber by IMEI

**IDENT**  
IMSI/MSISDN/ID/IMEI of the subscriber

**update**  
Set or update subscriber data

**imei**  
Set IMEI of the subscriber (normally populated from MSC, no need to set this manually)

**none**  
Forget IMEI

**IMEI**  
Set IMEI (use for debug only!)

### 1.3.52 subscriber (imsi|msisdn|id|imei) IDENT update msisdn (none|MSISDN)

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update msisdn (none|MSISDN)
```

#### Parameters

**subscriber**  
Subscriber management commands

**imsi**  
Identify subscriber by IMSI

**msisdn**  
Identify subscriber by MSISDN (phone number)

**id**  
Identify subscriber by database ID

**imei**  
Identify subscriber by IMEI

**IDENT**  
IMSI/MSISDN/ID/IMEI of the subscriber

**update**  
Set or update subscriber data

**msisdn**  
Set MSISDN (phone number) of the subscriber

**none**  
Remove MSISDN (phone number)

**MSISDN**  
New MSISDN (phone number)

### 1.3.53 subscriber (imsi|msisdn|id|imei) IDENT update network-access-mode (none|cs|ps|cs...

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update network-access-mode (none|cs|ps|cs+ps)
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### update

Set or update subscriber data

##### network-access-mode

Set Network Access Mode (NAM) of the subscriber

##### none

Do not allow access to circuit switched or packet switched services

##### cs

Allow access to circuit switched services only

##### ps

Allow access to packet switched services only

##### cs+ps

Allow access to both circuit and packet switched services

### 1.3.54 subscriber imsi IDENT create

#### Command

```
subscriber imsi IDENT create
```

#### Parameters

##### subscriber

Subscriber management commands

---



imsi

Identify subscriber by IMSI

IDENT

IMSI/MSISDN/ID of the subscriber

create

Create subscriber by IMSI

### 1.3.55 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

### 1.3.56 terminal monitor

Command

```
terminal monitor
```

Parameters

terminal

Set terminal line parameters

monitor

Copy debug output to the current terminal line

### 1.3.57 terminal no length

Command

```
terminal no length
```

Parameters

terminal

Set terminal line parameters

no

Negate a command or set its defaults

length

Set number of lines on a screen

---

### 1.3.58 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.3.59 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

---

## 1.4.2 banner motd file [FILE]

### Command

```
banner motd file [FILE]
```

### Parameters

#### banner

Set banner

#### motd

Banner for motd

#### file

Banner from a file

#### [FILE]

Filename

## 1.4.3 cpu-sched

### Command

```
cpu-sched
```

### Parameters

#### cpu-sched

Configure CPU Scheduler related settings

## 1.4.4 ctrl

### Command

```
ctrl
```

### Parameters

#### ctrl

Configure the Control Interface

---

### 1.4.5 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN 'enable' password string

### 1.4.6 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.7 hlr

#### Command

```
hlr
```

#### Parameters

##### hlr

Configure the HLR

---

### 1.4.8 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.4.9 line vty

#### Command

```
line vty
```

#### Parameters

##### line

Configure a terminal line

##### vty

Virtual terminal

### 1.4.10 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

##### log

Configure logging sub-system

##### alarms

Logging alarms to osmo\_strrb

##### <2-32700>

Maximum number of messages to log

---

### 1.4.11 log file .FILENAME

#### Command

```
log file .FILENAME
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.12 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.13 log stderr

#### Command

```
log stderr
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.14 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

### 1.4.15 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.4.16 log systemd-journal [raw]

Command

```
log systemd-journal [raw]
```

Parameters

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

[raw]

Offload rendering of the meta information (location, category) to systemd

### 1.4.17 mslookup

Command

```
mslookup
```

Parameters

mslookup

Configure Distributed GSM mslookup

### 1.4.18 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd



### 1.4.19 no enable password

#### Command

```
no enable password
```

#### Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.20 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.21 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.22 no log file .FILENAME

#### Command

```
no log file .FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.23 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.24 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.25 no log systemd-journal

#### Command

```
no log systemd-journal
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

### 1.4.26 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.27 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

---

### 1.4.28 no stats reporter log

#### Command

```
no stats reporter log
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.29 no stats reporter statsd

#### Command

```
no stats reporter statsd
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

### 1.4.30 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

### 1.4.31 password LINE

#### Command

```
password LINE
```

#### Parameters

##### password

Assign the terminal connection password

##### LINE

The UNENCRYPTED (cleartext) line password

### 1.4.32 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

### 1.4.33 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

---

### 1.4.34 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.35 stats interval <0-65535>

#### Command

```
stats interval <0-65535>
```

#### Parameters

##### stats

Configure stats sub-system

##### interval

Set the reporting interval

##### <0-65535>

Interval in seconds (0 disables the reporting interval)

### 1.4.36 stats reporter log

#### Command

```
stats reporter log
```

#### Parameters

##### stats

Configure stats sub-system

##### reporter

Configure a stats reporter

##### log

Report to the logger

### 1.4.37 stats reporter statsd

#### Command

```
stats reporter statsd
```

#### Parameters

##### stats

Configure stats sub-system

##### reporter

Configure a stats reporter

##### statsd

Report to a STATSD server

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

##### 0

Don't use color for printing messages

##### 1

Use color for printing messages

---

## 1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

### Command

```
logging filter all (0|1)
```

### Parameters

#### logging

Configure logging

#### filter

Filter log messages

#### all

Do you want to log all messages?

#### 0

Only print messages matched by other filters

#### 1

Bypass filter and print all messages

## 1.5.3 logging level (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbsgp|lnsdata|lnsignal) (debug|info|notice|error|fatal)

### Command

```
logging level (main|db|auc|ss|mslookup|lu|dgsm|lglobal|llapd|linp|lmux|lmi|lmib|lsms| ←  
lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbsgp| ←  
lnsdata|lnsignal) (debug|info|notice|error|fatal)
```

### Parameters

#### logging

Configure logging

#### level

Set the log level for a specified category

#### main

Main Program

#### db

Database Layer

#### auc

Authentication Center



---

- ss
  - Supplementary Services
- mslookup
  - Mobile Subscriber Lookup
- lu
  - Location Updating
- dgsm
  - Distributed GSM: MS lookup and proxy
- lglobal
  - Library-internal global log family
- llapd
  - LAPD in libosmogsm
- linp
  - A-bis Input Subsystem
- lmux
  - A-bis B-Subchannel TRAU Frame Multiplex
- lmi
  - A-bis Input Driver for Signalling
- lmib
  - A-bis Input Driver for B-Channels (voice)
- lsms
  - Layer3 Short Message Service (SMS)
- lctrl
  - Control Interface
- lgtp
  - GPRS GTP library
- lstats
  - Statistics messages and logging
- lgsup
  - Generic Subscriber Update Protocol
- loap
  - Osmocom Authentication Protocol
- lss7
  - libosmo-sigtran Signalling System 7
- lsccp
  - libosmo-sigtran SCCP Implementation
- lsua
  - libosmo-sigtran SCCP User Adaptation

---

lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol
ljibuf	libosmo-netif Jitter Buffer
lrspro	Remote SIM protocol
lns	GPRS NS layer
lbssgp	GPRS BSSGP layer
lnsdata	GPRS NS layer data PDU
lnsignal	GPRS NS layer signal PDU
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

#### 1.5.4 logging level force-all (debug|info|notice|error|fatal)

##### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

##### Parameters

###### logging

Configure logging

###### level

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.5 logging level set-all (debug|info|notice|error|fatal)

**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.6 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.5.7 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.8 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.9 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.10 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.11 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

## 1.5.12 logging timestamp (0|1)

### Command

```
logging timestamp (0|1)
```

### Parameters

#### logging

Configure logging

#### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

## 1.5.13 no logging level force-all

### Command

```
no logging level force-all
```

### Parameters

no

Negate a command or set its defaults

#### logging

Configure logging

#### level

Set the log level for a specified category

#### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

### Command

```
disable
```

### Parameters

disable

Disable the reporter

## 1.6.2 enable

### Command

```
enable
```

### Parameters

enable

Enable the reporter

## 1.6.3 flush-period <0-65535>

### Command

```
flush-period <0-65535>
```

### Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush) every N-th reporting interval. Set to 0 to disable regular flush (default).

## 1.6.4 level (global|peer|subscriber)

### Command

```
level (global|peer|subscriber)
```

### Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

---



### 1.6.5 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.6 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

### 1.6.7 no local-ip

#### Command

```
no local-ip
```

#### Parameters

##### no

Negate a command or set its defaults

##### local-ip

Set the IP address to which we bind locally

### 1.6.8 no mtu

#### Command

```
no mtu
```

#### Parameters

##### no

Negate a command or set its defaults

##### mtu

Set the maximum packet size

---

### 1.6.9 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.10 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.11 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

### 1.6.12 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

---

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

##### bind

Accept VTY telnet connections on local interface

##### A.B.C.D

Local interface IP address (default: 127.0.0.1)

##### [<0-65535>]

Local TCP port number

### 1.7.2 login

#### Command

```
login
```

#### Parameters

##### login

Enable password checking

### 1.7.3 no login

#### Command

```
no login
```

#### Parameters

##### no

Negate a command or set its defaults

##### login

Enable password checking

---

## 1.8 config-ctrl

### 1.8.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

bind

Set bind address to listen for Control connections

A.B.C.D

Local IP address (default 127.0.0.1)

## 1.9 config-cpu-sched

### 1.9.1 cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]

Command

```
cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]
```

Global attributes

Flag: !

This command applies immediately

Parameters

cpu-affinity

Set CPU affinity mask on a (group of) thread(s)

self

Set CPU affinity mask on thread running the VTY

all

Set CPU affinity mask on all process' threads

<0-4294967295>

Set CPU affinity mask on a thread with specified PID

THREADNAME

Set CPU affinity mask on a thread with specified thread name

CPUHEXMASK

CPU affinity mask

[delay]

If set, delay applying the affinity mask now and let the app handle it at a later point

## 1.9.2 policy rr <1-32>

### Command

```
policy rr <1-32>
```

### Global attributes

#### Flag: !

This command applies immediately

### Parameters

#### policy

Set the scheduling policy to use for the process

#### rr

Use the SCHED\_RR real-time scheduling algorithm

#### <1-32>

Set the SCHED\_RR real-time priority

## 1.10 config-hlr

### 1.10.1 database PATH

#### Command

```
database PATH
```

### Parameters

#### database

Set the path to the HLR database file

#### PATH

Relative or absolute file system path to the database file (default is 'hr.db')

### 1.10.2 euse NAME

#### Command

```
euse NAME
```

### Parameters

#### euse

Configure a particular External USSD Entity

#### NAME

Alphanumeric name of the External USSD Entity

---

### 1.10.3 gsup

#### Command

```
gsup
```

#### Parameters

gsup

Configure GSUP options

### 1.10.4 ncss-guard-timeout <0-255>

#### Command

```
ncss-guard-timeout <0-255>
```

#### Parameters

ncss-guard-timeout

Set guard timer for NCSS (call independent SS) session activity

<0-255>

Guard timer value (sec.), or 0 to disable

### 1.10.5 no euse NAME

#### Command

```
no euse NAME
```

#### Parameters

no

Negate a command or set its defaults

euse

Remove a particular External USSD Entity

NAME

Alphanumeric name of the External USSD Entity

### 1.10.6 no store-imei

#### Command

```
no store-imei
```

#### Parameters

no

Do not save the IMEI in the database, when receiving Check IMEI requests.

store-imei

(null)

---

### 1.10.7 no subscriber-create-on-demand

#### Command

```
no subscriber-create-on-demand
```

#### Parameters

no

Do not make a new record when a subscriber is first seen.

subscriber-create-on-demand

(null)

### 1.10.8 no ussd default-route

#### Command

```
no ussd default-route
```

#### Parameters

no

Negate a command or set its defaults

ussd

USSD Configuration

default-route

Remove the default-route for all USSD to unknown destinations

### 1.10.9 no ussd route prefix PREFIX

#### Command

```
no ussd route prefix PREFIX
```

#### Parameters

no

Negate a command or set its defaults

ussd

USSD Configuration

route

Routing Configuration

prefix

Prefix-Matching Route

PREFIX

USSD Prefix

---

### 1.10.10 store-imei

#### Command

```
store-imei
```

#### Parameters

##### store-imei

Save the IMEI in the database when receiving Check IMEI requests. Note that an MSC does not necessarily send Check IMEI requests (for OsmoMSC, you may want to set 'check-imei-rqd 1').

### 1.10.11 subscriber-create-on-demand (no-msisdn|<3-15>) (none|cs|ps|cs+ps)

#### Command

```
subscriber-create-on-demand (no-msisdn|<3-15>) (none|cs|ps|cs+ps)
```

#### Parameters

##### subscriber-create-on-demand

Make a new record when a subscriber is first seen.

##### no-msisdn

Do not automatically assign MSISDN.

##### <3-15>

Length of an automatically assigned MSISDN.

##### none

Do not allow any NAM (Network Access Mode) by default.

##### cs

Allow access to circuit switched NAM by default.

##### ps

Allow access to packet switched NAM by default.

##### cs+ps

Allow access to circuit and packet switched NAM by default.

### 1.10.12 ussd default-route external EUSE

#### Command

```
ussd default-route external EUSE
```

#### Parameters

##### ussd

USSD Configuration



**default-route**

Configure default-route for all USSD to unknown destinations

**external**

External USSD Handler

**EUSE**

Name of External USSD Handler (IPA CCM ID)

**1.10.13 ussd route prefix PREFIX external EUSE****Command**

```
ussd route prefix PREFIX external EUSE
```

**Parameters****ussd**

USSD Configuration

**route**

Routing Configuration

**prefix**

Prefix-Matching Route

**PREFIX**

USSD Prefix

**external**

External USSD Handler

**EUSE**

Name of External USSD Handler (IPA CCM ID)

**1.10.14 ussd route prefix PREFIX internal (own-msisdn|own-imsi|test-idle)****Command**

```
ussd route prefix PREFIX internal (own-msisdn|own-imsi|test-idle)
```

**Parameters****ussd**

USSD Configuration

**route**

Routing Configuration

**prefix**

Prefix-Matching Route

**PREFIX**

USSD Prefix

**internal**

Internal USSD Handler

**own-msisdn**

Respond with subscribers' own MSISDN

**own-imsi**

Respond with subscribers' own IMSI

**test-idle**

Keep the session idle (useful for testing)

## 1.11 config-hlr-gsup

### 1.11.1 bind ip A.B.C.D

**Command**

```
bind ip A.B.C.D
```

**Parameters****bind**

Listen/Bind related socket option

**ip**

IP information

**A.B.C.D**

IPv4 Address to bind the GSUP interface to

### 1.11.2 ipa-name NAME

**Command**

```
ipa-name NAME
```

**Parameters****ipa-name**

Set the IPA name of this HLR, for proxying to remote HLRs

**NAME**

A globally unique name for this HLR. For example: PLMN + redundancy server number: HLR-901-70-0. This name is used for GSUP routing and must be set if multiple HLRs interconnect (e.g. mslookup for Distributed GSM).

## 1.12 config-hlr-euse

## 1.13 config-mslookup

### 1.13.1 client

#### Command

```
client
```

#### Parameters

##### client

Enable and configure Distributed GSM mslookup client

### 1.13.2 mdns bind [IP] [<1-65535>]

#### Command

```
mdns bind [IP] [<1-65535>]
```

#### Parameters

##### mdns

Multicast DNS related configuration

##### bind

Convenience shortcut: enable and configure both server and client for mDNS mslookup

##### [IP]

multicast IPv4 address like 239.192.23.42 or IPv6 address like ff08::23:42

##### [<1-65535>]

mDNS UDP Port number

### 1.13.3 mdns domain-suffix DOMAIN\_SUFFIX

#### Command

```
mdns domain-suffix DOMAIN_SUFFIX
```

#### Parameters

##### mdns

Multicast DNS related configuration

##### domain-suffix

mDNS domain suffix (default: mdns.osmocom.org). This is appended and stripped from mDNS packets during encoding/decoding, so we don't collide with top-level domains administrated by IANA

##### DOMAIN\_SUFFIX

mDNS domain suffix (default: mdns.osmocom.org). This is appended and stripped from mDNS packets during encoding/decoding, so we don't collide with top-level domains administrated by IANA

---

### 1.13.4 no client

#### Command

```
no client
```

#### Parameters

no

Negate a command or set its defaults

client

Disable Distributed GSM mslookup client

### 1.13.5 no mdns bind

#### Command

```
no mdns bind
```

#### Parameters

no

Negate a command or set its defaults

mdns

Disable both server and client for mDNS mslookup

bind

(null)

### 1.13.6 no server

#### Command

```
no server
```

#### Parameters

no

Negate a command or set its defaults

server

Disable Distributed GSM mslookup server

---

### 1.13.7 server

#### Command

```
server
```

#### Parameters

server

Enable and configure Distributed GSM mslookup server

## 1.14 config-mslookup-server

### 1.14.1 mdns bind [IP] [<1-65535>]

#### Command

```
mdns bind [IP] [<1-65535>]
```

#### Parameters

mdns

Multicast DNS related configuration

bind

Configure where the mDNS server listens for mslookup requests

[IP]

multicast IPv4 address like 239.192.23.42 or IPv6 address like ff08::23:42

[<1-65535>]

mDNS UDP Port number

### 1.14.2 mdns domain-suffix DOMAIN\_SUFFIX

#### Command

```
mdns domain-suffix DOMAIN_SUFFIX
```

#### Parameters

mdns

Multicast DNS related configuration

domain-suffix

mDNS domain suffix (default: mdns.osmocom.org). This is appended and stripped from mDNS packets during encoding/decoding, so we don't collide with top-level domains administrated by IANA

DOMAIN\_SUFFIX

mDNS domain suffix (default: mdns.osmocom.org). This is appended and stripped from mDNS packets during encoding/decoding, so we don't collide with top-level domains administrated by IANA

### 1.14.3 msc ipa-name .IPA\_NAME

#### Command

```
msc ipa-name .IPA_NAME
```

#### Parameters

msc

Configure services for individual local MSCs

ipa-name

Identify locally connected MSC by IPA Unit Name

.IPA\_NAME

IPA Unit Name of the local MSC to configure

### 1.14.4 no mdns bind

#### Command

```
no mdns bind
```

#### Parameters

no

Negate a command or set its defaults

mdns

Disable server for mDNS mslookup (do not answer remote requests)

bind

(null)

### 1.14.5 no service NAME

#### Command

```
no service NAME
```

#### Parameters

no

Negate a command or set its defaults

service

Remove one or more service address entries

NAME

mslookup service name, e.g. sip.voice or smpp.sms

---

### 1.14.6 no service NAME at IP <1-65535>

#### Command

```
no service NAME at IP <1-65535>
```

#### Parameters

no

Negate a command or set its defaults

service

Remove one or more service address entries

NAME

mslookup service name, e.g. sip.voice or smpp.sms

at

at

IP

IPv4 address like 1.2.3.4 or IPv6 address like a:b:c:d::1

<1-65535>

Service-specific port number

### 1.14.7 service NAME at IP <1-65535>

#### Command

```
service NAME at IP <1-65535>
```

#### Parameters

service

Configure addresses of local services, as sent in replies to remote mslookup requests.

NAME

mslookup service name, e.g. sip.voice or smpp.sms

at

at

IP

IPv4 address like 1.2.3.4 or IPv6 address like a:b:c:d::1

<1-65535>

Service-specific port number

---

## 1.15 config-mslookup-server-msc

### 1.15.1 no service NAME

#### Command

```
no service NAME
```

#### Parameters

no

Negate a command or set its defaults

service

Remove one or more service address entries

NAME

mslookup service name, e.g. sip.voice or smpp.sms

### 1.15.2 no service NAME at IP <1-65535>

#### Command

```
no service NAME at IP <1-65535>
```

#### Parameters

no

Negate a command or set its defaults

service

Remove one or more service address entries

NAME

mslookup service name, e.g. sip.voice or smpp.sms

at

at

IP

IPv4 address like 1.2.3.4 or IPv6 address like a:b:c:d::1

<1-65535>

Service-specific port number

---



### 1.15.3 service NAME at IP <1-65535>

#### Command

```
service NAME at IP <1-65535>
```

#### Parameters

##### service

Configure addresses of local services, as sent in replies to remote mslookup requests.

##### NAME

mslookup service name, e.g. sip.voice or smpp.sms

##### at

at

##### IP

IPv4 address like 1.2.3.4 or IPv6 address like a:b:c:d::1

##### <1-65535>

Service-specific port number

## 1.16 config-mslookup-client

### 1.16.1 gateway-proxy IP [<1-65535>]

#### Command

```
gateway-proxy IP [<1-65535>]
```

#### Parameters

##### gateway-proxy

Configure a fixed IP address to send all GSUP requests for unknown IMSIs to, without invoking a lookup for IMSI

##### IP

IP address of the remote HLR

##### [<1-65535>]

GSUP port number (omit for default 4222)

### 1.16.2 mdns bind [IP] [<1-65535>]

#### Command

```
mdns bind [IP] [<1-65535>]
```

#### Parameters

---

mdns

Multicast DNS related configuration

bind

Enable mDNS client, and configure multicast address to send mDNS mslookup requests to

[IP]

multicast IPv4 address like 239.192.23.42 or IPv6 address like ff08::23:42

[<1-65535>]

mDNS UDP Port number

### 1.16.3 mdns domain-suffix DOMAIN\_SUFFIX

Command

```
mdns domain-suffix DOMAIN_SUFFIX
```

Parameters

mdns

Multicast DNS related configuration

domain-suffix

mDNS domain suffix (default: mdns.osmocom.org). This is appended and stripped from mDNS packets during encoding/decoding, so we don't collide with top-level domains administrated by IANA

DOMAIN\_SUFFIX

mDNS domain suffix (default: mdns.osmocom.org). This is appended and stripped from mDNS packets during encoding/decoding, so we don't collide with top-level domains administrated by IANA

### 1.16.4 no gateway-proxy

Command

```
no gateway-proxy
```

Parameters

no

Negate a command or set its defaults

gateway-proxy

Disable gateway proxy for GSUP with unknown IMSIs

### 1.16.5 no mdns bind

#### Command

```
no mdns bind
```

#### Parameters

no

Negate a command or set its defaults

mdns

Disable mDNS client, do not query remote services by mDNS

bind

(null)

### 1.16.6 timeout <1-100000>

#### Command

```
timeout <1-100000>
```

#### Parameters

timeout

How long should the mslookup client wait for remote responses before evaluating received results

<1-100000>

timeout in milliseconds

---